



**SAFARI**

**OWNER'S MANUAL**



**TATA MOTORS**

Revision: Rev 01/AUG 2021

## CUSTOMER ASSISTANCE

---

In our constant endeavour to provide assistance and complete service backup, TATA MOTORS has established an all India customer assistance centre.

In case you have a query regarding any aspect of your vehicle, our Customer Assistance Centre will be glad to assist you on our Toll Free no. **1800 209 8282**

You can also approach nearest TATA MOTORS dealer.

A separate Dealer network address booklet is provided with the Owner's manual.

TATA MOTORS 24X7 Roadside Assistance Program offers technical help in the event of a breakdown. Call the toll-free Roadside Assistance.

For additional information, refer to "**24X7 Roadside Assistance**" section in the Owner's manual.



**Dear Customer,**

Welcome to the TATA MOTORS family.

We congratulate you on the purchase of your new vehicle and are privileged to have you as our valued customer.

We urge you to read this Owner's Manual carefully and familiarize yourself with the equipment descriptions and operating instructions before driving.

Always carry out prescribed service / maintenance work as well as any required repairs at an authorized TATA MOTORS Dealers or Authorized Service Centre's (TASCs). Use only genuine parts for continued reliability, safety and performance of your vehicle.

You are welcome to contact our dealer or Customer Assistance toll free no. **(1800 209 8282)** in case of any query or support required.

We wish you a safe and pleasant driving experience.

**TATA MOTORS**

Bombay House, 24, Homi Modi Street,  
Hutatma Chowk, Fort, Mumbai – 400001

## **IMPORTANT INFORMATION**

---

- Before driving, read this Owner's manual carefully and familiarize yourself with your vehicle. For your own safety and a longer vehicle life, follow the instructions, 'Warnings' and 'Notes' in this manual. Ignoring them could result in damage to the or personal injury to you or others.
- The Owner's manual and other booklets are important documents and should always be kept in the vehicle. If you sell the vehicle, always pass on the documents to the new owner.
- This Owner's Manual describes all variants of the model and all standard/optional equipment of your vehicle available at the time of printing. Please note that your vehicle may not be equipped with all features described.
- TATA MOTORS PASSENGER VEHICLE LIMITED reserves the right to introduce changes in the design, equipment and technical features without any obligation to install them on the vehicles previously sold. The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.
- Do not carry out any modification including fitment of non-genuine accessories on your vehicle. Safety, handling, performance and durability, may otherwise be adversely affected and may violate government regulations. TATA MOTORS PASSENGER VEHICLE LIMITED no liability for damage resulting from the modifications or use of non-genuine accessories.
- All rights reserved. The information in this manual shall not be copied, translated or otherwise reproduced, in whole or in part without written permission from TATA MOTORS.

## CONTENTS

### 01. SAFETY

Important Information	1
Seat Belts	4
Child Restraint System (CRS)	8
Supplementary Restraint System (SRS - Airbags) (if equipped)	12
Child Lock (if equipped)	18
Anti-theft Device Immobilizer / PEPS	20
Anti-lock Braking System (ABS) (if equipped)	21
Electronic Brake Force Distribution (EBD)	22
Additional Safety Features (as available)	22

### 02. OPENING AND CLOSING

Keys (as available)	25
Smart Key (PEPS)	27
Smart Key Features	29
Flip Key	30
Flip Key Features	31
Door	32
Windows	33

### Bonnet

Tailgate Opening (as available)	37
Fuel Lid	39
Power Sunroof (if available)	40

### 03. DASHBOARD AND FEATURES

Cockpit	47
Instrument Cluster (TFT Screen)	48
Instrument Cluster (LCD Screen)	70
Tell Tales	83
Audio Reminders (if available)	92
Combi-switch (RH Stalk)	93
Combi-switch (LH Stalk)	95
Fascia Switches	96
Steering Wheel Switches (LHS) (if available)	97
Steering Wheel Switches (RHS) (if available)	98
Mic (if available)	99
Infotainment System Display (if available)	99
Speakers & Tweeter (if available)	101
USB Charger (if available)	101

## CONTENTS

---

Power Socket	102
Antenna (if available)	103
Shark Fin Antenna (if available)	103
Roof Grab Handle (if available)	104
Front Fog Lamps (if available)	104
Rear Fog Lamps (if available)	105
Puddle / Ajar Lamp	105
Roof Lamp	105
Boot Lamp	107
Side Indicator Lamp On Orvm	107
Front Lamp	108
Tail Lamp	108
Ambient Lights (if available)	109
iRA (iNtelligent Real-time Assist) Connected Car Service	109
Wireless Power Charging	110

## 04. STOWAGE AREAS

Storage Compartment	119
---------------------	-----

## 05. CLIMATE CONTROL

Air Distribution	125
Air Vents	126
HVAC Controls (if available)	127
Fully Automatic Temperature Control (FATC) (if available)	132
Cabin Air Purification	139

## 06. STARTING AND DRIVING

Pre Driving Checks	141
Driving Tips	142
Seat Adjustments	145
Rear View Mirrors	157
Sun Visors	159
Steering Wheel Adjustment (if available)	159
Steering Lock And Ignition Switch (if available)	160
Starting And Stopping (without PEPS)	161
Starting And Stopping (PEPS) (if available)	171
Engine Passive Start - Conditions	172
Engine Passive Stop - Conditions	173

## CONTENTS

Manual Transmission (MT)	173
Driving	176
Stopping The Vehicle	177
Braking	177
Parking Brake	178
Automatic Vehicle Hold (if equipped)	184
Reverse Park Assist (if available)	186
Rear Park Assist With Camera (if available)	191
Drive Mode (if available)	197
Terrain Response Mode (if available)	198
<b>07. EMERGENCY AND BREAKDOWN ASSISTANCE</b>	
Emergency Equipment	201
Spare Wheel Removal Process	203
In Case Of Flat Tyre	205
Puncture Repair Kit (if available)	208
Jump Lead Starting	215
Towing	216
Fuses	219
Bulb Specification	229
24 X 7 Road Assistance	231
<b>08. MAINTENANCE AND SERVICES</b>	
Maintenance And Service	235
Engine Compartment	236
Tyres	242
Remote Key Battery Replacement (for Flip key)	245
Smart Key Battery Replacement (for PEPS variant)	246
On Board Diagnostic (OBD II) System	247
Diesel Particulate Filter (DPF)	248
Exhaust After Treatment System	249
Regeneration Process	250
Diesel Exhaust Fluid (DEF)	251
Service Instructions	256
Service Schedule	257
Vehicle Parking For Long Duration	264
<b>09. TECHNICAL INFORMATION</b>	
Fuel Specification	265

## **CONTENTS**

---

Lubricant Specification	266
Technical Specifications	267
Vehicle Dimensions	271
Aggregate Identification Numbers	272

### **10. CAR CARE**

Car Care	273
Fast Tag	275
Value Care - AMC	276
Extended Warranty	280
Value Added Services	282
Vehicle Exterior Enrichment	284
Vehicle Interior Enrichment	285

### **11. WARRANTY - TERMS AND CONDITIONS**

Vehicle Warranty: Terms And Conditions	287
--	-----

### **12. ENVIRONMENT SAFETY**

Environmental Safety	289
----------------------	-----

## **IMPORTANT INFORMATION**

In this Owner's Manual, you will find the text under the heading "WARNING" and "NOTE" which highlights important information. Pay particular attention to these highlighted messages.

### **(i) NOTE**

*Indicates additional information that will assist you in gaining the optimum benefit and care for your vehicle.*

### **⚠ WARNING**

Indicates procedures or information that must be followed precisely in order to avoid the possibility of severe personal injury and serious damage to the vehicle.

## **Safe Driving**

Safety consciousness not only ensures your safety and the safety of other road users, but it also helps to reduce the wear and tear on your vehicle.

### **Safe driving depends on:**

- How quickly you make decisions to avoid an accident.
- Your ability to concentrate.
- How well you can see and judge objects.
- How well familiar you are with your vehicle controls and its capabilities.

### **(i) NOTE**

*Fatigue is a result of physical or mental exertion that impairs judgment. Driver fatigue may be due to inadequate sleep, extended work hours, strenuous work or non-work activities or combination of other factors. Take rest at regular intervals.*

## **Safety Tips**

- Always take into account the road conditions, weather conditions, vehicle speed in order to prevent accidents.
- Turn 'ON' the side indicators at least 30 meters before taking a turn or changing the lane.
- Decelerate to a safe speed before taking turn. Do not apply brakes during cornering.
- When overtaking other vehicles, watch out for the oncoming vehicle.
- Never drive under the influence of alcohol or drugs.
- If your vehicle is equipped with infotainment/navigation system, set and make changes to your travel route only when the vehicle is parked.
- Program radio presets with the vehicle parked, and use your programmed presets to make radio use quicker and simpler.

## SAFETY

### Driving Through Water

Do not drive through flooded areas. Judge the depth of water before driving through it. Otherwise, water may enter the vehicle interior or the engine compartment.

If at all the situation demands that you have to drive through water then;

- Keep engine in higher RPM and crawl the vehicle in low gear.
- Flowing or rushing water creates strong forces. Driving through flowing water could cause the vehicle to about trying to drive through flowing water.
- Lightly apply the brake pedal to dry the liners until the brakes work normally once you are out of water.

#### **WARNING**

Do not attempt to start the engine if vehicle gets flooded due to water. Tow the vehicle to a safe place. Contact a nearest TATA MOTORS Authorised Service Centre

### Driving on a Rainy Day

- Check wiper blades, lights and brakes for proper functioning and condition.
- Check the tyre treads depth, the condition of the tread and tyre.
- Avoid harsh braking and sharp turns. It may cause loss of control and lead to a skid.
- For slowing down, shift to lower gears and brake gently.
- Keep lights 'ON' if visibility is poor.

### Driving on Wet Roads

On wet road or during light showers, "Aquaplaning" can occur. "Aquaplaning" is the loss of direct contact between the road surface and the vehicle's tires due to a water film forming between them. Steering or braking the vehicle can be very difficult, and loss of control can occur.

There is no hard and fast rule about aquaplaning. The best advice is to slow down when the road is wet.

### **NOTE**

*If you have driven for a long time in heavy rain without braking, there may be a delayed reaction from the brakes when braking for the first time. You have to press the brake pedal more firmly. Maintain a greater distance from the vehicle in front.*

### Driving on Snowy Roads

While driving in snow, it is advisable to use the snow chain on roads. Follow assembly and safety instruction provided by the snow chain manufacturers.

## **Night Driving**

- Ensure that all lights are working and windshield, window glasses are clean.
- Drive more slowly at night than in the daytime, as the visual range is restricted at night. Maintain a speed such that you can stop within illuminated distance of head lamps.
- Do not use the high beam unless inevitable. It may dazzle the driver of the oncoming vehicle, thus causing an accident.
- Use head lamp main/dip beam to alert other road users on turns/ cross roads etc.
- Use side indicators for lane change or turning.

## **Driving on Gradients**

When climbing gradient, the vehicle may begin to slow down and show a lack of power. If this happens, shift to a lower gear and apply power smoothly so that there is no loss of traction.

When driving down a hill, the engine braking should be used by shifting into a lower gear. Do not drive in neutral gear or switch off the engine.

### **WARNING**

On long and steep gradients you must reduce the load on the brakes by shifting early to a lower gear. This allows you to take advantage of the engine braking effect and helps avoid overheating of service brakes resulting in reduced braking efficiency.

## **Driving on Highway**

Stopping distance progressively, increases with vehicle speed. Maintain a sufficient distance between your vehicle and the vehicle ahead.

For long distance driving, perform safety checks before starting a trip and take rest at certain intervals to prevent fatigue.

# SAFETY

---

## SEAT BELTS

This section of user manual describes your vehicle seat belt, airbag and Child restraints system. Please read and follow all these instructions carefully to minimize risk of severe injury or death.

- Seat belts are the primary restraints system in the vehicle. All occupants, including the driver, should always wear their seat belts to minimize the risk of injury.
- Sit back and adjust (if equipped), the seat. Make sure that your seat is adjusted to a good driving position and the back of the seat is upright.

### Buckling the Shoulder Seat Belt

- Grasp the tongue then slowly pull out the seat belt over the shoulder and across the chest. When the seat belt is long enough to fit, insert the tongue into the lock buckle until you hear a “CLICK” which indicates that the seat belt is securely locked.
- Position the lap portion of seat belt across your thighs, below your abdomen. To remove slack, pull up a bit on the shoulder seat belt. To loosen the lap portion seat belt if it is too tight, tilt the tongue and pull on the lap seat belt. A snug seat belt reduces the risk of sliding under the seat belt in a collision. Ensure that the seat belt running over the body (shoulder segment and lap segment) does not have any twist. Twisted seat belt may not offer effective protection when required.

### Releasing the Seat Belt

To release the seat belt, push the red button on the lock buckle. The seat belt will automatically retract to its stowed position. If necessary, slide the tongue down the webbing to allow the seat belt to retract fully.



#### *(i)* NOTE

*The above image is for reference purpose only.*

## Fixed Rear Centre Lap Seat Belt

When buckling, make sure you hear a click confirming that the tab is latched into the seat belt lock. To tighten it, pull the loose end through the buckle until the seat belt is comfortably adjusted around the pelvic bone (hips).

### **WARNING**

- Each seating position and seat belt assembly must be used by one occupant. It is not recommended to put a seat belt around a child, being carried on an occupant's lap.
- Be careful not to damage or tamper the seat belt webbing or hardware. Inspect the seat belt system periodically, checking for cuts, frays, or loose parts. A frayed or torn seat belt could rip apart in a collision and leave you with no protection.
- If the seat belt webbing or hardware is damaged, get it replaced immediately at TATA Motors Authorized service centre.

- Do not insert any items such as coins, clips, etc. into the seat belt buckles, and be careful not to spill liquids into these parts. If foreign materials get into a seat belt buckle, the seat belt will not work properly.
- Do not wear seat belts over hard, sharp or fragile items in clothing, such as pens, keys, spectacles etc.
- Do not use any accessories on seat belts or modify in any way the seat belt system. Devices claiming to improve occupant comfort or repositioning the seat belt, can reduce the protection provided by the seat belt and increase the chance of serious injury in a collision.

## Seat Belts with Pre - Tensioner (if equipped)

You can use pre-tensioner seat belts in the same manner as ordinary seat belts.

The seat belt pre-tensioner system works in conjunction with the SUPPLEMENTARY RESTRAINTS SYSTEM (SRS-Airbags).

In the event of a collision, as may be necessary, pre-tensioner tightens the seat belt so that it fits the occupant's body more snugly. When pre-tensioner activates, there could be some noise and release of smoke. This is normal and there are no health hazards or fire risk.

### **WARNING**

In a collision, the pre-tensioner seat belt assembly mechanisms become hot during activation. Do not touch the pre-tensioner seat belt assemblies for several minutes after they have been activated.

If the vehicle has been involved in a collision, get it inspected immediately at authorized TATA MOTORS SERVICE Center.

## SAFETY

---

### Seat Belt with Load Limiter (if equipped)

You can use the load limiter seat belts in the same manner as ordinary seat belts.

The seat belt load limiter system works in conjunction with the SUPPLEMENTARY RESTRAINTS SYSTEM (SRS-Airbags).

In the event of a collision, as may be necessary, load limiter reduces the load on the rib cage region of the occupant.

If the vehicle has been involved in a collision, get it inspected immediately at Authorized TATA MOTORS SERVICE Center.

### Use of Seat Belts for Pregnant Woman

#### ⚠ WARNING

- Pregnant woman must wear a correctly positioned seat belt. It is safer for mother as well as unborn child.
- Pregnant woman should wear the lap part of the seat belt across the pelvic bone (hips) and as snug across the hips as possible. Keep the seat belt low so that it does not come across the abdomen. That way the strong bones of the hips will take the force if there is a collision.



## Seat Belt Warning Lamp



For Driver



For Front  
Passenger

The seat belt warning lamp reminds you to fasten the seat belt.

- If the driver does not fasten seat belt, seat belt reminder lamp will blink and a buzzer will sound for pre-defined duration until the driver's seat belt is buckled.
- If front passenger seat is occupied by adult and does not fasten seat belt, seat belt reminder lamp will blink and a buzzer will sound for pre-defined duration until the front passenger seat belt is buckled.
- If this system is also provided for other than Front row seats, applicable above warnings will appear until seat belts are buckled.

- If front passenger seat is occupied by child, system may detect occupancy and warn with front passenger seat belt warning. It is not taken to mean child can occupy front passenger seat and use seat belt. Please refer CRS section for recommended seating position.

### *(i)* NOTE

*Using unauthorized after-market seat cover may affect function of occupant sensor. TATA motors does not recommend any non-validated seat covers on seats.*

## SAFETY

### CHILD RESTRAINT SYSTEM (CRS)

TATA MOTORS strongly recommends the use of Child Restraint Systems (CRS) for all children up to age of 12 years and to be placed at recommended positions only. Children travelling without recommended CRS and seated at other positions may face serious injuries in case of a collision.

CRS can be installed in the vehicle using seat belts and/or ISOFIX only (if equipped) or ISOFIX with Top Tether (if equipped).

The harness system of CRS holds the child in place, and in a collision, acts to keep the child positioned in the seat and reduce the risk of injuries.


All children below age of one year must always ride in a rear-facing infant CRS.

Keep children above age of one year, in a forward-facing CRS with a harness until they reach the size or weight limit allowed by your CRS manufacturer.

Once your child outgrows the forward-facing CRS, your child is ready for a booster seat.

### Selection and Installation of CRS

Always select the CRS that complies with latest safety standards (AIS072 / ECE R44). The CRS are classified according to the child's size, height and weight. Select the appropriate CRS for your child. Ensure that the child fits properly in the CRS and it is securely installed in the vehicle. For installation, please refer CRS manufacturer's instruction manual.



#### *(i) NOTE*

*The above images are for reference purpose only.*

## Recommended CRS Position as Per the Vehicle Matrix

The suitability of seat position for carriage of children and recommended category of CRS is shown in the table below as per the child group.

**X** - Seat Position not suitable for children in this age group.

**U** - Suitable for “universal” category restraints approved for use in this age group.

Universal is a category in the AIS072 / ECE R44 norm

### ⚠ WARNING

If a child is seated in the front seat it may cause serious injury or even death during any collision.

Group	Mass Group	Age Group	Front Passenger	Rear Out-board (rh/lh)	Rear Center	Intermediate Out-board Second Row Lh/rh	Intermediate Centre
0	Up to 10 kg	Up to 9 months	X	X	X	U	NA
0+	Up to 13 kg	Up to 24 months	X	X	X	U	NA
I	9 tp 18 kg	9 months to 48 months	X	X	X	U	NA
II	15 to 25 kg	Approx. 3 to 7 years	X	X	X	U	NA
III	22 to 36 kg	Approx. 6 to 12 years	X	X	X	U	NA

## SAFETY

### **WARNING**

If your vehicle is equipped with a front passenger airbag (PAB) and does not have PAB deactivation switch, do not install a rear-facing CRS in the front passenger seat. If the PAB inflates, a child in a rear facing CRS could be seriously injured or killed.

If you install a CRS in the rear seat, slide the front seat far enough forward so that the child's feet do not touch the front seat-back. This will help avoid injury to the child in the event of a collision.

### **NOTE**

*Children could be endangered in a collision if their CRS is not properly secured in the vehicle. Be sure to secure the child in the restraint system according to the manufacturer's instructions.*

### **WARNING**

Do not use an infant carrier or a child safety seat that "hooks" over a seat

back, it will not provide adequate protection in a collision.

After a collision, we recommend to get seat belts, seats, ISOFIX and top-tether anchorages (as may be applicable) investigated at TATA MOTORS Authorized service center.

### **NOTE**

*A CRS in a closed vehicle can become very hot. To prevent burns, check the seating surface and buckles before placing your child in CRS.*

### **WARNING**

- Do not leave unattended children in your vehicle.
- Do not modify CRS in any way.

### **NOTE**

- *Do not install a booster seat or a booster cushion with only the lap strap of the seat belt.*

- *Do not install a booster seat or a booster cushion with a seat belt that is slack or twisted.*
- *Do not put the safety seat belt under your child's arm or behind its back.*
- *Do not use pillows, books or towels to boost your child's height.*
- *Make sure that your children sit in an upright position.*
- *Do not allow children to stand up or kneel on either the rear or the front seats. An unrestrained child could suffer serious or fatal injuries during a collision.*
- *Do not leave any toys or other objects loose in the CRS or on the seat while the vehicle is in motion.*

Each CRS should be used for one child only.

When PAB deactivation switch (if provided) is turned 'OFF', make sure 'PAB' operational status lamp illuminates with ignition 'ON', indicating that the passenger airbag is NOT operational. If the airbag SRS warning indicator in the instrument cluster illuminates continuously, it means that there is malfunction in the system. Remove the CRS from front passenger seat and contact your TATA MOTORS authorized service center.



*(i)* **NOTE**

*The above images are for reference purpose only.*

## SAFETY

### SUPPLEMENTARY RESTRAINT SYSTEM (SRS - Airbags) (if equipped)

The airbag 'SRS' system comprises of the following components depending upon the provided safety features in vehicle.

- Seat belt Pre-tensioners
- Seat belt with load limiters
- Driver Airbag
- Front Passenger Airbag
- Side Airbags (if equipped)
- Curtain Airbag (if equipped)
- Airbag 'SRS' ECU (Electronic Control Unit)
- Collision Sensors
- SRS wiring harness
- SRS Warning lamp

The System is active when ignition switch is in the "ON" position or the ignition mode is "ON". Airbags are designed to inflate in severe collisions. In the event of a collision, the collision sensors will detect signals, and if the Airbag ECU judges that the signals represent a severe collision, will


trigger the airbags. The inflated Airbags provide a cushion to the occupants. The Airbag inflates and deflates so quickly that you may not even realize that it has activated. The Airbag will neither hinder your view nor make it hurdle to exit the vehicle.

Airbag inflation is virtually instantaneous and occurs with considerable force, accompanied by loud noise and smoke, which is normal. The inflated airbag, together with seat belts, limit the movement of an occupant, thereby reducing the risk of injury.

When an airbag inflates, you may see some smoke-like particles. The particles are a normal by-product of the process that generates the non-toxic gas used for airbag inflation. These airborne particles may irritate the skin, eyes, nose, or throat. If you have skin or eye irritation, rinse the area with water. For nose or throat irritation, move to fresh air. Also sometimes the smoke can cause breathing problems, in such cases get fresh air promptly.

After inflation, airbag provides a gradual cushioning effect for the occupant there-

after deflates. It is not advisable to drive your vehicle after the airbags have been deployed. If you are involved in another collision, the airbags will not be in place to protect you.



#### *(i)* NOTE

*The above images are for reference purpose only.*

**(i) NOTE**

- Open your windows and doors as soon as possible after collision to reduce prolonged exposure to the smoke and powder released by the inflating airbag.
- Do not touch the airbag container's internal components immediately after an Airbag has inflated. The parts that come into contact with an inflating Airbag may be very hot.
- Always wash exposed skin areas thoroughly with lukewarm water and mild soap.

The driver airbag is mounted in the center of the steering wheel. The front passenger airbag is located inside the dashboard in front of the passenger seat. The vehicle fitted with the airbags have suitable indications on steering wheel and on dashboard. The word 'AIRBAG' is embossed on the airbag covers.

Side airbags (if equipped), are mounted in front row seats for outboard occupants only.

**(i) NOTE**

*The above image is for reference purpose only.*

Curtain airbags (if equipped), are mounted above the doors along the roof on both sides.

**(i) NOTE**

*The above image is for reference purpose only.*

## SAFETY

### **WARNING**

- Even in vehicles with Airbags, you and your passengers must always wear the seat belts provided. In order to minimize the risk and severity of injury in the event of a collision.
- **ALWAYS** use seat belts and CRS – during every trip and at all times. Even with airbags, you can be seriously injured or killed in a collision if you are not wearing seat belt properly or not wearing seat belt when airbag inflates.
- You and your passengers should never sit or lean unnecessarily close to the Airbags.
- Move your seat as far back as possible from front Airbags, while still maintaining control of the vehicle.
- All occupants should sit upright with the seatback in an upright position, centred on the seat cushion with their seat belt on, legs comfortably extended and their feet on the floor

until the vehicle is parked and the engine is turned off.

- If an occupant is out of position during collision, the rapidly deploying Airbag may forcefully contact the occupant causing serious or fatal injuries.
- Do not allow the front passenger to place their feet or legs on the dashboard.

### **Not Recommended Seating Position**





 **NOTE**

*The above images are for reference purpose only.*

## SAFETY

---

### **WARNING**

- Never place your arm over the airbag as a deploying airbag can result in serious arm fractures or other injuries.
- Do not allow the passengers to lean their heads or bodies onto doors or place objects between the doors and passengers when they are seated on seats equipped with side and/or curtain Airbags.
- Do not place or stick any item/s in the vehicle, except at designated locations (such as utility bins, cup/bottle holders, boot space etc). Loose items may act as a projectile during a collision and cause severe to fatal injuries.
- Please be aware that any unsecured item in your vehicle, such as your pet, unsecured CRS or a laptop, can become a potential hazard in the event of a collision or sudden stop, causing injuries to occupants in the vehicle.

- Coat hooks (if provided), must be used only for that purpose. Never hang other items on to those hooks. This could affect deployment of the Airbags, and may lead to severe to fatal injuries.
- **ALWAYS** contact your TATA MOTORS authorized service center if the vehicle is damaged, even if airbag has not inflated.
- **ALWAYS** contact your TATA MOTORS authorized service center if any part of an airbag module cover shows sign of cracking or damage.

### **WARNING**

If your SRS malfunctions, the Airbag may not inflate properly during a collision thereby increasing risk of serious injury or death. If any of the following conditions occur, your SRS is malfunctioning:

- The SRS warning lamp does not turn 'ON' when the ignition switch is placed in the 'ON' position for few seconds.
- The SRS warning lamp stays 'ON' after illuminating.
- The SRS warning lamp comes 'ON'/stays 'ON' while the vehicle is in motion.
- The SRS warning lamp blinks when the engine is running.

We recommend the customer to immediately visit TATA MOTORS authorized service center and get the SRS system inspected if any of the above conditions occur.

**⚠ WARNING**

- Never make any modifications to your vehicle. The modifications carried out, but not limited to the vehicle frame, bumpers, front fenders, ride height, suspension, seat belts, interior trims, steering wheel (especially holders), are not acceptable. This will affect the intended performance of SRS system.
- Fitment of bull bars, seat covers on seats with airbags etc, is strictly prohibited, unless authorised by TATA MOTORS. This will affect the intended performance of SRS system.
- If you need to make any modifications to accommodate any disability you may have, please contact your Authorized TATA MOTORS Dealer for necessary guidance.
- Do not tamper with SRS in any way. This will lead to unexpected performance of system and may cause serious injury or death.

**Airbag Warning Sticker on Front Passenger Sun Visor**

The Airbag Warning Symbol on sun visor reminds extreme hazards associated with the use of rearward-facing child restraint on front passenger seat during airbag deployment.

It is not taken to mean child can occupy front passenger seat and use seat belt. Please refer CRS section for recommended seating position for children.

**⚠ WARNING**

Never use a rearward facing child restraint on a seat protected by an active Airbag in front of it, Death or serious injury to the child can occur.

**Airbag Deployment Conditions****When front airbags should not deploy?**

**Minor frontal collision:** Seat belt (if worn) offers adequate occupant protection in low severity collisions. The airbags are triggered only when there is a collision severe enough to trigger the airbags. Deployment of frontal airbags is not beneficial in low severity collisions.

**Side collision:** During a side collision, occupants tend to move sideways. Therefore, deploying frontal airbags in such situations will not benefit the occupants. Side airbags and side curtain airbags (if equipped) are specifically designed to reduce the injuries that can occur in side collision.

## SAFETY

---

**Rear collision:** During a rear collision, occupants tend to move (rearwards) away from frontal airbags. Therefore, deploying frontal airbags in such situations will not protect the occupant. Head restraints and seat belts provide occupant protection during a rear collision.

**Rollovers collision:** During a rollover collision, unbelted occupants may float inside the passenger compartment. This will increase the risk of injuries and may prove to be fatal. Wearing seat belts provide highly effective occupant protection during rollover collision. Front airbags, are not designed to deploy in a rollover as frontal airbags cannot offer any protection in rollover collision.

**When front airbags/side airbags/side curtain airbags (if equipped) deploy with minor or no visible vehicle damage?**


The airbags are triggered only when there is a collision severe enough to trigger the airbags. The extent of vehicle damage is not always the correct indicator for airbag deployment. In some extreme/rare conditions;

of rough road driving, running into a curb or hitting other fixed objects; the airbags may deploy depending upon the severity of collision. In some of these conditions, damage to the vehicle may be minor or not be readily visible.

**When front airbags/side airbags/side curtain airbags (if equipped) may not deploy, even with exterior visible vehicle damage?**

The airbags are triggered only when there is a collision severe enough to trigger the airbags. The amount of visible vehicle damage is not always the correct indicator for airbag deployment. Some collisions can result in visible damage but with no airbag deployment, because the airbags would not have been needed or would not have provided protection even if they had deployed. Seat belts, if worn, offer adequate occupant protection in such cases.

### CHILD LOCK (if equipped)



Both the rear doors of the vehicle are provided with a child proof lock. Push the lock lever located on vertical face of the door downward before closing the door. The door which has been closed by activating the child lock cannot be opened from inside, it can be opened only from the outside.

**① NOTE**

- *Lift the lock lever upward to deactivate the childproof lock when not required.*
- *Child safety lever to be used for safety of child for preventing them to open rear door while seating in passenger seat to avoid accident while vehicle is running.*

## SAFETY

### ANTI-THEFT DEVICE IMMOBILIZER / PEPS

Immobilizer system is designed to prevent vehicle theft by electronically disabling the engine ignition system. The engine can be started only with vehicle's original Immobilizer ignition key which has an electronic identification programmed code.

#### *(i) NOTE*

*Use only Flip key, the other should be kept in a safe location. Note down "key Tag no." information (and keep it safe) which is required while getting new/spare keys. Remember that it is not possible to prepare new/spare keys without the "key Tag number." Take precaution about Flip key, as without Flip key vehicle cannot be started.*

Vehicle Condition	Immobilizer Lamp Status	Vehicle State	Meaning / Function Of The State
Ignition OFF	Blinking	Locked	Vehicle Immobilized and awaiting electronic key
Ignition ON	OFF	Unlocked	Normal condition and ready to start the vehicle
Ignition ON	ON	Locked	<ul style="list-style-type: none"><li>• Problem with key (Wrong key used to start vehicle)</li><li>• Problem with Immobilizer system. Contact a TATA MOTORS Authorized Service Centre.</li></ul>
Ignition ON	Blinking	Unlocked	Contact a TATA MOTORS Authorized Service Centre immediately.

## ANTI-LOCK BRAKING SYSTEM (ABS) (if equipped)

ABS regulates brake pressure in such a way that the wheels do not lock when you brake. This allows you to continue steering the vehicle when braking.

The ABS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes off after 2-3 seconds if system is healthy.



### ⚠ WARNING

- If ABS is faulty, the wheels could lock when braking. The steer ability and braking characteristics may be severely impaired. There is an increased danger of skidding and accidents.
- Drive on carefully. Have ABS checked immediately at the TATA MOTORS Authorized Service Centre as soon as possible.

### While Braking

- In an emergency situation take your foot off the accelerator and press the brake pedal fully. This allows the ABS to regulate braking for you and have steering control along with maximum possible braking.
- When ABS is active driver will feel brake pedal pulsating and very low motor (ABS) activation noise from engine compartment which is normal during ABS braking.

### ⚠ WARNING

- On certain surfaces, such as gravel or firm ground covered by snow, the standard ABS system may have the effect of increasing the stopping distance, but ABS will still offer the advantage of helping you to maintain directional control of vehicle.
- However, remember that ABS will not compensate for bad road or weather conditions or poor driver judgment. Drive within safety margin taking into consideration prevail

ing weather and traffic conditions.

## SAFETY

---

### ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

EBD monitors and controls the brake pressure on the rear wheels to improve driving stability while braking.



EBD provides optimal braking pressure distribution between front and rear wheels to optimize braking distance and to ensure vehicle stability by means of lowering braking pressure increase at rear wheels.

#### WARNING

- If EBD is malfunctioning, the rear wheels can lock, e.g. under full braking. This increases the risk of skidding and an accident.
- You should therefore adapt your driving style to the different handling characteristics. Have the brake system checked immediately at a TATA MOTORS Authorized Service Centre as soon as possible.

### ADDITIONAL SAFETY FEATURES (as available)

#### Cornering Stability Control (CSC)

Corner stability Control supports / stabilizes vehicle during partial braking on curves by reducing pressure at required inner wheel of the vehicle.

This helps to reduce probability of vehicle over steering during cornering.

#### OFF Road ABS

Based on wheel speed information off road ABS helps to avoid wheel lock on uneven surfaces like loose gravel, pot holes by reducing the stopping distance compared to standard ABS.

#### Electronic Traction Control (ETC)

The Electronic Traction Control system function (ETC) is designed as a slip control system to prevent the driven wheels of a vehicle from excessive wheel slip.

#### Roll Over Mitigation (ROM)

The main feature of the Roll over Mitigation function is the detection of a rollover critical situation and to prevent the vehicle

rollover. This is done by active brake interventions on selected wheels, thereby reducing the forces that cause a roll-over situation.

#### Brake Disc Wiping (BDW)

Water on the brake disc leads to a delay in brake response time. The purpose of the function Brake Disc wiping is to remove moisture when driving in wet conditions automatically. To get quick response form Brake and better deceleration.

#### Electronic Brake Pre-fill (EBP)

The Electronic Brake Prefill (EBP) function reduces the air gap of the brake pad and the brake disc. The function is triggered after a sudden release of the accelerator pedal due to an unexpected emergency brake situation. By actively pre-filling the brake-system the brake response time is reduced and results in a shorter stopping distance.

#### Hydraulic Brake Assist (HBA)

In a dangerous emergency situation, most drivers don't use the full available performance of the brake system, because they

---

brake too soft. The HBA function detects the critical situation and builds up additional brake pressure to reduce the braking distance.

### **Hydraulic Fading Compensation (HFC)**

In dangerous fading situations most drivers operate the brake pedal with a small or regular braking force and they never reach to the maximum possible vehicle deceleration. The HFC function improve the stopping distance by eliminating required pressure build-up lag by the driver.

### **Dynamic Wheel Torque by Brake (DWT-B)**

The main goal of the function is to improve the agility of a vehicle and to enable a more direct steering. This is mainly achieved by braking interventions at the inner wheels during turning. DWT-B reduces understeer tendency of the car and a higher curve speed can be achieved.

### **Engine Drag Torque Control (EDTC)**

On slippery road conditions during in- gear Braking or Shift down of gear or sudden throttle release on a curve road.

This causes high Engine drag on the driven wheel resulting into brake slip situations without any brake application.

This makes vehicle highly under steerable. EDTC controls such brake slip on the driven wheels by increasing the engine torque to makes the vehicle stable and steerable.


### **Hill Hold Control (HHC)**

Hill Hold Control is a comfort function. The main intend is to prevent the vehicle from rolling backwards while driving off up-hill on an inclined surface.



## OPENING AND CLOSING

### KEYS (as available)

Sn	Name	Remote Key	Description
1	Flip key with remote		<ol style="list-style-type: none"><li>1. Unlocking all doors</li><li>2. Approach light/Tail gate opening</li><li>3. Locking all doors</li><li>4. Folding key blade in/out</li></ol>
2	Mechanical key		<ol style="list-style-type: none"><li>1. Locking all doors</li><li>2. Unlocking all doors</li></ol>
3	Smart key (PEPS)		<ol style="list-style-type: none"><li>1. Locking all doors</li><li>2. Approach light</li><li>3. Tail gate opening</li><li>4. Unlocking all doors</li></ol>

## OPENING AND CLOSING

---

### Keys

A key is an electronic access and authorization system which is provided as a standard feature on your vehicle.

### Unlocking Principle

The transponder which is built into the ignition key carries a unique identification code. The vehicle unlocks when the code on the key matches with the code on the Engine Management System (EMS). In case of PEPS variant, Immobilizer function is provided by PEPS.

### Engine Starting

When the key is inserted and the ignition is switched 'ON', all codes are communicated within key, Immobilizer and EMS. The engine will start only if all the codes match.

### Loss of Keys

If one of the key is lost, contact your nearest TATA MOTORS authorized dealer immediately.

### WARNING

- Do not turn 'ON' ignition switch by using key with any type of metal wound around its grip or in contact with it. This may be detected as abnormal condition by immobilizer and prevent engine from starting.
- Do not leave the key in areas of high temperature. The transponder in it will behave abnormally when reused.
- Do not try to start the vehicle when the Immobilizer indicator lamp  on the instrument cluster is glowing. In this condition the vehicle will not start and the vehicle's battery will also be drained due to frequent cranking.

### SMART KEY (PEPS)



Keep the smart key with user to perform the passive access. It is used for locking, unlocking and starting the vehicle.

1. Locking all doors
2. Approach Light
3. Tail gate opening
4. Unlocking all doors

#### Locking all Door

Pressing the Lock button (1) once, remote locks all the doors of the vehicle.

#### Approach Light

Press approach light button (2) once, low beam and position lamp will turn 'ON'. This feature helps to find and reach the parked vehicle or to reach home in dark/ cloudy condition. To switch 'OFF' the approach lights, press and release the same button or it automatically turns 'OFF' after certain time.

#### Tail Gate Opening

To open the Tail gate press the button (3) once on the smart key, Tail gate will unlatch. Please refer section starting and driving for more information.

#### Unlocking all Doors

Pressing the unlock button (4) once, remote will unlock all the Doors. Please refer section starting and driving for more information.

#### NOTE

If smart key battery is low/drained or vehicle battery is low/drained, user can unlock and enter into vehicle by using Emergency key blade. Provision is given on driver door handle only.

#### Emergency Key Blade In / Out




Slide the knob (1) to unlatch the key. Pull the key blade (2) out.

## OPENING AND CLOSING

### Unlocking Door with Emergency Key


- Slot is provided below driver door handle.



- Insert the key blade in slot and press.



- Outer cover of door handle will be unlock first.
- Remove the cover to access the door lock slot.



- Insert the key blade in slot and turn clockwise to unlock the door.

### SMART KEY FEATURES

#### Force Panic On Operation

When vehicle is in OFF condition, if we press lock button and unlock button simultaneously, Force panic operation gets activated. In this case, turn indicators of vehicle start flashing and horn will blow automatically.

#### Force Panic Off Operation

By pressing any button of smart key, Force panic operation gets deactivated.

#### Vehicle Search

In vehicle locked condition, if lock button on smart key is pressed, the turn indicators of vehicle flashes 4 times.

#### Automatic Activation Of Immobilizer

If smart key is not found within the passenger compartment, engine will be immobilized and vehicle cannot start.

#### Auto Locking / Unlocking Of Doors /

#### Auto Relock

In PEPS variants, door will get unlocked when ignition is OFF by pressing Start Stop switch.

#### Anti-grab / Anti-scan Coding

The remote control set of this security system is protected against the use of devices called 'scanners' and 'grabbers' which can record and reproduce some types of remote codes.

#### Important

- Don't operate Unlock button of remote in the vicinity of your vehicle, as it could lead to an unintentional unlocking your vehicle.
- For battery, replacement procedure refer 'MAINTENANCE' section.
- Do not remove the battery connection of the vehicle while the vehicle has been locked by remote.

#### Smart Key Precautions

1. If smart key is close to radio transmitter such as radio station or an airport which can interfere with normal operation of the transmitter.
2. If smart key is near a mobile two way radio system or a cellular phone, then it will not work properly.
3. If another vehicle's smart key is being


operated close to your vehicle, signal will fluctuate.

#### WARNING

Keep smart key away from electromagnetic materials that blocks electromagnetic waves to the key surface.

## OPENING AND CLOSING

### FLIP KEY



1. Unlocking all doors
2. Approach Light/Tail gate unlatch
3. Locking all doors
4. Folding key blade IN/OUT

#### Unlocking all Doors

Pressing the unlock button (1) of remote will unlock all the Doors. One flash is coming on side indicators.

#### Approach Light

Press approach light button (2) once, low beam and positon lamp will turn 'ON'. This

feature helps to find and reach the parked vehicle or to reach home in dark/ cloudy condition after parking. Red LED will be flashing on the remote. To switch 'OFF' the approach lights, press and release the same button or it automatically turns 'OFF' after certain time.

#### Tail Gate Unlatch

To unlatch the Tail gate, long press the approach light button (2) on remote for more than 2 sec.

#### *(i) NOTE*

*Tail gate once unlatched will not get lock automatically with doors. It will get locked by slamming.*

#### Locking all Doors

Pressing the Lock button (3) once, remote locks all the doors of the vehicle.

#### Folding Key Blade IN / OUT

Press button (4) to flip out the key blade. For folding, press the button (4) and fold the key blade inside.



#### *(i) NOTE*

*Do not fold the key blade without pressing the button. Also, it should not be forced in any direction apart from folding direction to avoid damage to flip mechanism.*

### FLIP KEY FEATURES

#### Force Panic ON Operation

When vehicle is in OFF condition, if we press lock button and unlock button simultaneously, Force panic operation gets activated. In this case, turn indicators of vehicle start flashing and horn will blow automatically.

#### Force Panic OFF Operation

By pressing any button of smart key, Force panic operation gets deactivated.

#### Vehicle Search

In vehicle, locked condition if lock button on remote key is pressed the turn indicators of vehicle flashes for 4 times.

#### Automatic Activation of Immobilizer

If key is removed from ignition switch, the engine will be immobilized automatically even if you forget to lock the vehicle.

For few variant, Ignition off is required to immobilize the vehicle.

#### Auto Locking / Unlocking of Doors / Auto Relock

- Vehicle doors are automatically locked

when all doors are closed and the vehicle speed crosses 10 kmph.

- When key is taken out all the doors get automatically unlocked.
- For few variant, when ignition is turned off all the doors get automatically unlocked.

Also, when unlocked with remote key and if no door is opened within 30 seconds, vehicle doors get automatically locked.

#### Anti-grab / Anti-scan Coding

The remote control set of this security system is protected against the use of devices called 'scanners' and 'grabbers' which can record and reproduce some types of remote codes.

#### *(i)* NOTE

*In case any button of the key is accidentally pressed for more than 20 seconds, the remote stops functioning till the time the button is pressed. The LED on the Remote also stops glowing. The function of the remote gets reinstated immediately when the user stops pressing*

*the push button of remote.*

#### Vehicle Alarm & Security

To prevent automobile thefts, the anti-theft system makes use of an anti-theft alarm (ATA). On detection of any unauthorized access, the BCM triggers the horn (acoustic alarm) and flashes the turn indicators.

## OPENING AND CLOSING

### DOOR

#### Option 1: Door Lock and Unlock with Key


Driver / front passenger doors can be locked or unlocked from outside using the key blade.



Insert the key and turn it clockwise to lock and anticlockwise to unlock the door.

#### Option 2: Door Locking / Unlocking using Door Handle Switch (DHS)

To lock/unlock all the doors without operating smart key button/ key blade. Press the door handle switch (DHS) provided on the driver door to lock/unlock all the four doors except tailgate.



#### Horn Honking when Door Locking using Door Handle Switch (DHS)

If vehicle is in unlock condition and smart key is not available, (i.e. Smart Key is present away from authentication range) and if you try to lock the vehicle through door handle switch then vehicle horn honking gets activated for 9 sec.

If vehicle is in unlock condition and Smart key is present inside the vehicle. If you try to press the door handle switch then vehicle horn honking gets activated for 9 sec.

#### *(i)* NOTE

- *Authentication range for smart key shall be 1 to 1.5 meter from outside the respective door or Tail gate.*
- *Passive entry only works during ignition off.*

### Locking without a Key from Inside



All the doors can also be locked from inside by pressing knob on driver door and independently on other doors respectively.

### Unlocking the Doors from Inside



1. Door opening knob
2. Door opening Lever


All doors can be opened from inside. To open, pull the door opening knob (1) and then opening lever (2).

#### *(i)* NOTE

*There is a single pull override feature on driver door. All door can be unlocked by inner handle without operating lock knob of inner handle.*

### WINDOWS

#### Power Windows (if available)



1. Front Window Winding Switch (Right)
2. Front Window Winding Switch (Left)
3. Rear Window Winding Switch (Right)
4. Rear Window Winding Switch (Left)
5. Inhibit Switch

Window glasses on all four doors can be operated by switches provided on the main control panel located on the driver's arm rest. They work only when the key is in the 'IGN ON' position.

## OPENING AND CLOSING

### *(i)* NOTE

Power windows can be operated for 30 sec. in 'IGN OFF' and 'KEY OUT' position, provided doors are not open.

### Express Down (if available)

Window glasses can be opened by a single long press of the switch. Express down feature is provided for the driver's door only.

### Anti-pinch Function (if available)



The Anti-pinch module is provided. It will stop window upward movement if any ob-

struction or resistance detected.

Thus, it gives full and reliable protection for hand, neck and any obstacles as well. Anti-pinch function is provided for driver door only.

### Individual Switches

Individual window winding switches have been provided for front passenger and rear passengers.




Glasses are wound up by pulling the switch and are lowered by pressing.

### **WARNING**

While raising the glass, take care to avoid fingers/hands getting trapped between glass and the door frame.

### Inhibit Switch (if available)



### Inhibit Switch ON

When switch is pressed, red light turns 'OFF'. The individual switches provided on rear and front passenger door cannot be operated. Still it can be operated from the switches on driver's arm rest.



### Inhibit Switch OFF

When switch is pressed, red light turns 'ON'. The individual switches provided on rear and front passenger door can be operated. It can also be operated from the switches on driver's arm rest.



#### ⚠ WARNING

- If children operate the windows they could be get trapped, particularly if they are left unsupervised. There is a risk of injury.
- Activate the window inhibit feature when children are travelling. While leaving the vehicle, always take the

key with you and lock the vehicle. Never leave children unsupervised in the vehicle.

### BONNET


#### Opening the Bonnet

1. Ensure that the vehicle is in neutral gear with the parking brake applied.
2. Pull the bonnet release lever. The bonnet will pop up slightly.



3. Raise the bonnet slightly and with your finger lift (up) the secondary lock lever located under the bonnet center.

## OPENING AND CLOSING



### *(i)* NOTE

*Make sure that the wiper arms are not raised before you lift up the bonnet to avoid damaging the wiper arms and the bonnet.*

4. Lift the bonnet up. Pull the bonnet stay rod from its clip and insert the free end into the slot provided on frame.



*Engine Bonnet Stay rod*

### WARNING

- The stay rod can be hot enough to burn your finger right after driving. To avoid this, use rubber packing given on stay rod.
- Touch the rod after it becomes cool enough.
- Insert the stay rod into the hole securely. If the rod drops off, your body may be caught below the bonnet.

### Closing

1. To close the bonnet, hold the bonnet by one hand, disengage the stay rod and clamp it back properly.
2. Lower the bonnet close to the bumper, then let it drop down.

### WARNING

Ensure that the bonnet is properly locked before driving or it can fly up unexpectedly during driving.

### TAILGATE OPENING (as available)

#### *(i)* NOTE

Some variants may have multiple options.

#### Option I



Remote operated Tail gate unlatching can be done through long press (2 sec) approach light button on remote key.

#### Option II




When user press the Tail gate button on remote, Tail gate gets unlatched.

#### *(i)* NOTE

Press the tail gate button on smart key and press the tail gate door handle switch within 30 seconds to open it.

#### Option III



If vehicle is locked and tail gate is closed. Tail gate switch is pressed with valid smart key in the authentication range, Tail gate gets unlatched.

#### WARNING

- After unlatching, tailgate doesn't get opened automatically.
- Tailgate should not be opened holding tailgate garnish, this might damage the part. It is suggested to open through tailgate edge.

## OPENING AND CLOSING

On closing the tail gate door, Tail gates gets locked.

### ⓘ NOTE

- During closing Tail gate if doors are in locked condition and valid smart key is inside the trunk, then Tail gate can be unlocked by pressing tailgate switch.
- Tail gate once unlatch it will not get locked automatically with other doors.
- For Tail gate unlatch remote operation, vehicle shall be in OFF mode.
- If doors are in unlocked condition, Tail gate can be unlocked via Tail gate handle switch independent of smart key.
- Avoid keeping smart key inside the boot space area while closing Tail gate.

### ⚠ WARNING

Tail gate can't be locked using mechanical key/ flip key/ smart key. It can be locked by slamming it.

### Option IV (Emergency Tailgate Opening)



In emergency situation like key or vehicle battery is discharged or electrical malfunctioning, you can unlock the tailgate from inside as per procedure given below:

1. Open driver door using mechanical

key.

2. Open the rear door.
3. Fold the rear seat.
4. And access the tailgate opening lever from inside.
5. Turn the lever clockwise to unlatch and open the tailgate.

### ⓘ NOTE

This can be used in emergency when you are inside the vehicle.


### FUEL LID

1. To open the fuel flap, gently press on fuel flap. Make sure the smart key should be in authentication range and the vehicle is in unlock condition.

#### *(i)* NOTE

*For mechanical/flip key (without smart key), to open the fuel flap. Make sure that vehicle is in unlock condition. Then gently press the fuel flap.*

2. Open the fuel flap by gently pressing flap.



3. To open the fuel cap by turning it in counter clockwise for fuel filling.
4. For closing, close the fuel cap and gently push the fuel flap till it gets locked.

#### WARNING

- Fuel vapour is extremely hazardous. Always switch 'OFF' the engine before refueling and never refill near sparks or open flames. Do not use cell phone while refueling.
- Do not continue adding fuel after the automatic shut 'OFF' function is operated if it is equipped on the fuel station. Overfilling the fuel tank could damage the fuel system.

#### *(i)* NOTE


- Remove the fuel filler cap slowly, and wait for any hissing to stop. The fuel may be under pressure and may spray out.
- When smart key is inside the car, fuel flap can be open by pressing

*the flap.*

If fuel cap needs replacement, ensure that it is replaced by a genuine cap at the TATA MOTORS Authorized Service Centre only.

## OPENING AND CLOSING


### POWER SUNROOF (if available)



A Sunroof will make the driving experience more enjoyable by bringing light and sunshine into the vehicle. It provides a real open air feeling along with pure driving fun. With fresh air, your driving experience automatically becomes significantly more relaxed.

A sunroof allows air to flow evenly from above the driver, which is much quieter and less intrusive than wind blowing through a side window.

### Location Of Controls And Their Functions



#### Power Sunroof Switches

1. Sunroof Open
2. Sunroof Close
3. Tilt Up
4. Tilt Down
5. Sunshade Open
6. Sunshade Close

To operate the sliding sunroof and Rollo shade. Push the switch as shown in above fig. after every operation switch goes to

Home position automatically.

#### **WARNING**

You must switch on the ignition to operate the power sunroof. After switching off the ignition, You can still open or close the power sun-roof for 3 minutes as long as the driver or front passenger door has not been opened.

#### 1. Sunshade Open Position



## OPENING AND CLOSING



Push the switch (5) to open the Sunshade.

Express (one touch) open to open Sunshade completely.

Manual (long press) open and stop at desired position.

### 2. Sunshade Close Position



Push the switch (6) to close the Sunshade.

Express (one touch) close to close Sunshade completely.

Manual (long press) Close and stop at desired position

### 3. Sunroof Open Position



## OPENING AND CLOSING

---

Push the switch (1) to open the Sunroof.

Express (one touch) open to open Sunroof completely.

Manual (long press) open and stop at desired position.

### *(i)* NOTE

*During sliding sunroof Express (one touch) open operation, Sunshade will also open in synchronization with sliding sunroof (**Express Complete Open Feature**).*

### 4. Sunroof Close Position



Push the switch (2) to close the Sunroof.

Express (one touch) close to close sunroof completely.

Manual (long press) close and stop at desired position.

### 5. Sunroof Tilt Open/close Position



Push the switch (3) for Sunroof Tilt Open.

Push the switch (4) for Sunroof Tilt Close.

Express (one touch) Tilt Open / Close sunroof completely.

Manual (long press) Tilt Open / Close and stop at desired position.

### Auto Sunroof Close

Sliding Sunroof will automatically close under following conditions:

- Rain detection- As soon as rain detected & Wiper speed is slow/high based on Rain, the Sunroof will close.
- Ignition off and driver came out of the

vehicle by carrying the Remote key and driver locking the vehicle through remotely or through driver door.

### NOTE

*If the power sunroof malfunctions, pinch protection may not function properly. Visit an authorized TATA Motors dealer or an authorized TATA Motors Service Facility for assistance.*

### WARNING

- Without pinch protection, the power sunroof will close with enough force to cause serious personal injury.
- Always be careful when closing the power sunroof.
- Pinch protection cannot prevent fingers or other parts of the body from being pressed against the edge of the roof; may result in injuries.

### Emergency Close Feature

If Express (One Touch) / Manual (long press) Sunroof and Sunshade close func-

tion did not work due to:

- Consecutive several attempts to Open / close Sunroof and Sun-shade.
- Excessive Ice / Dirt accumulation on the Sunroof Glass / guiderails.

### Follow The Emergency Close Command As Below:

Emergency close feature can be used, if Sliding sunroof or Sunshade consecutive reversal movement observed 3 times within 10 sec then follow the steps given below:

- On the 4th attempt continuously press the sunroof close switch - position (2) or Sunshade close switch - position (6) until it closes completely to ensure occupant privacy, safety & theft prevention from Sunroof open window. **This is Emergency Close Feature.**

### WARNING

*Never keep your hands or head in the Sunroof window while performing this operation it may cause severe injury, since Anti-pinch function will not work at this 4th attempt.*

- Once the sunroof or Sunshade is completely closed, release the switch.
- Alternatively, User may wait for min. 30 secs before operating Sunroof and Sunshade, then Sunroof can be operated with Normal Functions.

### NOTE

*If the Sunroof doesn't operate as above, Visit an authorized TATA Motors dealer or an authorized TATA Motors Service Facility for assistance.*

### Initializing The Power Sunroof

#### Condition for initializing the sunroof

If the vehicle battery is disconnected and reconnected during Sunroof / Sunshade movement or while replacing the dead

## OPENING AND CLOSING

fuse, the sunroof/ Sunshade must be initialized.

Otherwise Express (one touch) function (open/close/tilt) and pinch protection function will be deactivated.

### Initializing command procedure:

To initialize the sliding sunroof and Sunshade, use the following procedure:

1. Turn ON the ignition.
2. Close the sunroof fully by pressing 'sunroof close switch' and keep the switch pressed for 1-2 seconds after the roof is fully closed, till clicking sound comes from Sunroof.
3. Close the Sunshade fully by pressing 'Sunshade close switch' and keep the switch pressed for 1-2 seconds after the Sunshade is fully closed, till clicking sound comes from Sun-shade.
4. The Initializing command is complete, Check if the Express open/close features are working.

### NOTE

*If the initializing procedure is not completely performed, then it has to be run again from step 2.*

### Self-learning procedure of Sunroof

5. Sliding sunroof and Sunshade shall be in open position within 4 mm to 200 mm from the cutout.
6. Close the sunroof fully by pressing 'sunroof close switch' and keep the switch pressed continuously. Do not release the switch and wait for following actions to perform.
7. Sliding sunroof will start opening after 5 sec pause and close automatically. Release the Switch to complete the procedure.
8. Close the sunshade fully by pressing 'Sunshade close switch' and keep the switch pressed continuously. Do not release the switch and wait for following actions to perform.
9. Sunshade will start opening after 5 sec pause and close automatically. Re-

lease the Switch to complete the procedure.

10. The self-learning command is complete.

### NOTE

*Incase Sunroof and Sunshade Close switch is released in the middle of procedure, repeat from step 1.*

### NOTE

- You can still open or close the power sunroof for 3 minutes after you switch off the ignition, as long as the driver or front passenger door has not been opened.
- To help prevent damage, remove ice and snow from the sunroof before opening or tilting it in winter season.
- Always close the sunroof before leaving the vehicle or if it begins to rain. If the sunroof is open or tilted, rain could enter the vehicle interior and cause extensive damage to the

*electrical system. This could result in further vehicle damage.*

- *Remove leaves and other objects from the sunroof guiderails regularly either by hand or using a vacuum cleaner.*
- *If the power sunroof malfunctions, pinch protection may not function properly. See an authorized TATA Motors dealer or an authorized TATA Motors Service Facility.*
- *The Sunshade can be opened and closed independently when the sliding sunroof is in closed position but will not operate in case sliding sunroof is open or in tilt position.*
- *Always close the sunroof while washing the vehicle.*

*roof when it is Closing OR Opening*

- *Always take the key with you while leaving the vehicle.*
- *Never leave children or disabled persons in the vehicle particularly, if they have access to the vehicle key. Unsupervised use of the remote control vehicle key makes it possible to lock the vehicle, start the engine, turn on the ignition and operate the sunroof.*

### **WARNING**


Improper use of the power sunroof can result in serious personal injury.

- *Always make sure that no one is in the Path/Cutout of the power sun*



## DASHBOARD AND FEATURES

### COCKPIT




**NOTE: All location shown may not be applicable to your vehicle / Variants.**

1	A.C. Air vent
2	Airbag (PAB)
3	Infotainment Display (if available)
4	Combi-Switch
5	Horn pad
6	Start/Stop switch (if available)
7	Airbag (DAB)
8	Steering Wheel Switches (if available)
9	Controls
10	Foot Rest
11	Terrain Response Knob (if available)
12	Cooled storage box
13	Parking Brake Lever
14	Gear Shift Lever
15	HVAC Control panel
16	Fascia switches
17	Center Air Vent
18	Glove Box

## DASHBOARD AND FEATURES

### INSTRUMENT CLUSTER (TFT Screen)



**NOTE:** All indicators shown may not be applicable to your vehicle.

### Speedometer



Speedometer indicates the vehicle speed in km/h.

#### *(i) NOTE*

*Whenever you turn the ignition ON, the instrument cluster needles and gauges move to maximum value and return to '0' position. This is a welcome strategy and a self-check feature.*

### Tachometer



Tachometer indicates engine speed in revolutions per min (rpm).

#### **⚠ WARNING**

Never drive the vehicle with high engine rpm. This may cause severe engine damage.

### Fuel Gauge

When the ignition switch is in "ON" position, fuel gauge gives an approximate indication of the amount of fuel in the fuel tank. In indication window, "F" stands for full and "E" stands for empty.



When fuel in the tank is near to empty position, low fuel warning telltale turns Amber. Refill the tank as soon as possible.

## DASHBOARD AND FEATURES

### NOTE

- *Check the fuel level when the vehicle is stationary on a level road.*
- *The fuel level displayed can vary when you drive on inclines, curves, brake and accelerate suddenly. This is due to the movement of fuel in the tank. The low fuel warning lamp may turn to ON or OFF earlier or later than usual.*

### WARNING

If there is any fault in the system, the low fuel warning symbol will blink. Take your vehicle to the nearest TATA MOTORS Authorized service centre.

### Temperature Gauge

When the ignition switch is in the "ON" position, this gauge indicates the engine coolant temperature.



The indicator should be within the normal, acceptable temperature range i.e. between "H" and "C". If the indicator approaches "H", overheating is indicated by red progress bar.

If the coolant temperature is very high, the engine coolant temperature telltale flashes with an audio warning. In this case, stop the vehicle, switch 'OFF' the engine and allow it to cool down for some time. Contact the nearest TATA MOTORS authorized service center immediately for rectification.

### WARNING

The red progress bar on high coolant temperature indicates overheating that may damage the engine. Continuing to drive the vehicle when engine overheating is indicated can result in severe engine damage or fire.

### DEF Gauge

When the ignition switch is in the "ON" position, arrow in the gauge indicates level of DEF left in the tank.



The Indicator should be within the acceptable range. i.e., between "E" and "F". When DEF in tank is near to empty position, DEF telltale near to gauge will glow with subsequent Text alert on DIS Screen. If DEF level reaches to critically low level, then DEF Gauge will be replaced by the permanent text alert along with buzzer.

Similarly for Low DEF Quality & SCR Fault there are featured text and warnings present to alert the driver regarding condition of DEF System.

### ⚠ WARNING

- If DEF Level or DEF Quality or SCR Fault becomes Critical after sufficient alerts, warnings, Buzzers & If not rectified then Text alert will be displayed permanently on DIC Screen stating vehicle will not restart in next key ON & Vehicle will not start.
- If any problem comes then, Take your vehicle to the nearest TATA MOTORS Authorized service center.

*suddenly. This is due to the movement of DEF in the tank.*





- *If SCR Fault issue comes the take your vehicle to the nearest TATA MOTORS Authorized service center.*

### ⓘ NOTE

- *Check the DEF Level when the vehicle is on level road.*
- *DEF Level Displayed may vary when you drive on inclines, declines, curves, brakes & accelerate*

## DASHBOARD AND FEATURES

### Driver Information System

Driver Information	System Image	Description
Odometer		Indicates distance travelled by a vehicle. The odometer reading does not return to "0" when maximum value is reached, the display will freeze to maximum value.
Trip meter A & B		The trip meter can be used to measure the distance travelled on short trips or between fuel stops. It can be reset to "0". The Trip meter reading becomes "0.0" after it crosses 9999.9 km.
Clock		Indicates current time in AM/PM mode. Whenever the battery terminals or related fuses are connected, you must reset the clock time. This feature is available when ignition switch is in 'ON' position. <b>NOTE:</b> Clock settings can also be changed through infotainment system. For more information, refer infotainment manual.
Power and Torque		Indicates the value of Power and Torque delivered by engine in the particular driving condition.

## DASHBOARD AND FEATURES

Driver Information	System Image	Description
Service reminder		<p>Indicates the number of days/kilometers in which service is due. If service is overdue, it will display "0" km or "0" days and spanner symbol will blink at every ignition ON for few seconds. Never reset the display between service intervals otherwise this may result in incorrect readings. Information is retained in the service interval display even after the vehicle battery is disconnected.</p> <p><b>NOTE:</b> <i>This option is for indicative purpose only. Keep track of your odometer reading and follow the maintenance schedule.</i></p>
Door Ajar		<p>Respective door open display pop up comes up for 5 sec and then minimize telltale glows with respective door open will displayed.</p>
Current gear position (indicator) (for MT & AT- Manual Mode)		<p>Current gear engaged by the transmission shall be displayed on DIS.</p> <p><b>NOTE:</b> If "Fault" is displayed it means a 'Fault' condition. Contact the TATA MOTORS authorized service centre.</p> <p><i>In case of Manual Transmission, the gear number shall be displayed when the clutch is fully released.</i></p>

## DASHBOARD AND FEATURES

Driver Information	System Image	Description
Current gear position (indicator) (for AT)		<p>Current gear engaged by the transmission shall be displayed on DIS.</p> <p><b>NOTE:</b> If "Fault" is displayed it means 'Fault' condition. Contact the TATA MOTORS Authorised Service Centre.</p> <p><i>In case of Automatic Transmission, the gear type P-Park, D-Drive, N-Neutral and R-Reverse will be displayed as per automatic gear selected.</i></p>
Gear Recommendation (for MT)		<p>Up or down arrow shall be displayed on DIS whenever a gear should be shifted up or down.</p> <p>No arrow shall be displayed when the selected gear is as per the vehicle dynamics.</p>
Driver Control Shift Denied		<p>This message displayed when gear shift is denied in manual mode.</p> <p>User has to drive the vehicle in recommended speed to change the gear.</p>
Electronic Brake Distribution Fault		<p>Electronic Brake Distribution (EBD) System Fault</p> <p>User has to take the vehicle to Authorized Tata motors service station.</p>
Transmission Oil Temperature High		<p>This message displayed when transmission oil temperature is higher than allowable limit.</p> <p>User has to take the vehicle to Authorized Tata motors service station.</p>

## DASHBOARD AND FEATURES

Driver Information	System Image	Description
Transmission Failure Drive Cautiously Visit Service Centre	 <b>Transmission Malfunction</b> <b>Drive Cautiously</b> Contact Customer Center	This message displayed when transmission related failure is present. User has to take the vehicle to Authorized Tata motors service station.
Transmission failure Malfunction detected contact service center	 <b>Transmission Malfunction</b> <b>Malfunction Detected</b> Contact Customer Center	This message displayed when transmission related failure is present. User has to take the vehicle to Authorized Tata Motors service station.
Shift to Park to Exit	 <b>Transmission Alert</b> <b>Shift to Park (P)</b> to Exit	This message displayed when shift lever not in P (park) mode.
Shift to Park or Neutral to start the Engine	 <b>Transmission Alert</b> <b>Shift to Park or Neutral</b> to Start Engine	This message displayed when shift lever not in P (park) or N (neutral) mode while starting the engine.

## DASHBOARD AND FEATURES

### Instantaneous Fuel Economy (IFE)



It indicates fuel economy of current drive when Ignition is turned 'ON'.

To reach the Instant Fuel Economy in the Instrument cluster. Press the **▲** **▼** switch, which is on the RHS steering switch.

The display does not show actual value unless vehicle is moving.

#### **NOTE**

- *IFE will vary frequently as per driving pattern.*
- *IFE display does not show Fuel Economy of last drive.*

### Power and Torque



Indicates the amount of power and torque delivered by engine in the particular driving condition.

### Average Fuel Economy (AFE)



#### *Trip A*



#### *Trip B*

AFE value is estimate of fuel economy. It may vary significantly based upon driving conditions, driving habits and condition of the vehicle.

To see the Average fuel economy in the Instrument cluster. Press the  switch on the RHS of the steering switch.

Trip time, Average speed and Trip distance will reset to '0' when respective Trip meter is reset.

### NOTE

- *Average Fuel Economy, Trip time and Average speed will get reset to '0' when Battery is removed and re-fitted.*
- *Average Fuel Economy will be displayed as '—.—' for initial 0.5 km of respective trip. Once 0.5 km distance is covered, Average Fuel Economy will be displayed.*
- *Even after 0.5 km distance covered for particular trip, if Average Fuel Economy is displayed as '—.—', then take your vehicle to TATA MOTORS Authorized Service Centre.*

### Distance To Empty (DTE)



The above DTE screen indicates approximate distance in 'km' that your vehicle can travel with available fuel in the tank.

To reach the Distance to empty in the Instrument cluster. Press the  switch, which is on RHS steering switch.

DTE values may vary significantly based on driving conditions, driving habits, and condition of the vehicle. It is an estimate value of the available driving distance.

If low fuel warning light turns 'ON', fill the fuel tank immediately regardless the value of displayed DTE.

### NOTE

- *If DTE is displayed as '—.—', then take your vehicle to the TATA MOTORS Authorized Service Centre.*
- *The DTE will update with new value when fuel is added for more than 7 Litres at a time.*

### Infotainment Information on Instrument Cluster Display unit



The Instrument Cluster will display the Infotainment information like Media, Navigation and FM.

## DASHBOARD AND FEATURES

### Setting Screen



You can enter into setting screen by pressing select button while being in setting screen.

Following options are displayed in the setting screen:



To change the option from unit to service reminder reset by pressing on the RHS of steering switch.

### Illumination Screen

You can select illumination setting by scroll down using up or down on the RHS steering switch and by pressing select button.

You can increase the illumination from (20% to 100%) in 5 steps by pressing on the RHS of steering switch.

Following screen gets displayed:



### Service Reminder Reset

You can select Service reminder reset screen by scroll down & pressing set button in settings screen.

You can select Yes or No option by up or down arrows & set button.



### NOTE

*In setting menu if there is no user input for 10 sec, previous screen shall be displayed.*

## About Screen

You can select about option by scroll up or down   and pressing set button on RHS steering switches. It displays open source license disclosure.



**(i) NOTE**

*Pressing select button while in about screen, the screen will close and go to previous screen.*

### Outside Ambient Temperature



This displays outside ambient temperature in units of °C with the resolution of 1 °C.

The temperature sensor is located on the front bumper of the vehicle, therefore the temperature reading can be affected by heat reflection from the road surface, engine heat and the exhaust from surrounding traffic.

**NOTE**

*For an accurate temperature reading, make sure the vehicle speed is above 30 kmph.*

**WARNING**

If display shows OAT temp as “- -”, take your car to a TATA authorized service Centre.

## Tire Pressure Monitoring System (TPMS)

You can select TPMS screen by pressing up or down   on the RHS of the steering switch.

**(i) NOTE**

When start the vehicle or make ignition ON it may happen Pressure & Temp value show “—”. Driver has to drive the vehicle for some time with particular Speed to update the TPMS pressure and Temperature value's If value's not updated and display shows “—” with

## DASHBOARD AND FEATURES

---

warning message then take vehicle to service center.

TPMS screen with no fault:



TPMS screen with low tire pressure:



### ⓘ NOTE

*If tyre pressure is low, then you will get to see the red hollow mark on that tyre in the Instrument Cluster.*

TPMS screen with high tire pressure:



### ⓘ NOTE

*If tyre pressure is high, then you will get to see the red filled mark on that tyre in the Instrument Cluster.*

TPMS screen with combination of failures in tires:



TPMS screen with TPMS ECU Malfunction:



TPMS screen with Air leakage:



## DASHBOARD AND FEATURES

---

### Display Messages on Instrument Cluster

Below messages can be displayed in the screen for 3 sec based on the priority.

#### Warning Messages (messages displayed within the Red border)



**NOTE: All messages may not be applicable to your vehicle**

Sn	Warning / Information Title	Warning Message Title	Warning Message On Instrument Cluster
1	Fasten Seat Belt - Driver	Seat Belt Reminder	Fasten Driver Seat Belt
2	Speed Limit Warning	Speed Limit Warning	Over Speeding Detected Slow Down
3	Transmission Failure Drive Cautiously Visit Service Center	Transmission Malfunction	Drive Cautiously Contact Service Center
4	Drive Control Shift Denied	Drive Mode Warning	Drive Control Shift Denied
5	Hill Hold Control Failure	Hill Hold Control	Malfunction Detected Contact Service Center
6	Hill Decent Control Failure	Hill Decent Control	Malfunction Detected Contact Service Center

## DASHBOARD AND FEATURES

Sn	Warning / Information Title	Warning Message Title	Warning Message On Instrument Cluster
7	Fuel Level Low State	Fuel Level Warning	Fuel Level Low
8	Fasten seat belt front passenger	Seat Belt Reminder	Fasten Front passenger Seat Belt
9	Transmission Failure Limp home Activated Visit Service Center	Transmission System	Malfunction Detected Contact Service Center
10	DEF level warning 1	DEF Level Low	DEF Level Low Refill Soon
11	DEF level warning 2	DEF Level Low	Engine Stops in "Value" Km Refill DEF
12	DEF level warning 3	DEF Level Low	Engine Stops in "Value" Km Refill DEF
13	DEF level warning 4	DEF Level Low	Engine Stops in "Value" Km Refill DEF
14	DEF level warning 5	DEF Level Low	Engine Stops in "Value" Km Refill DEF
15	DEF level warning 6	DEF Level Low	Engine Will Not Restart In Next Key On
16	DEF level warning 7	DEF Level Low	Engine Stop DEF Tank Empty
17	DEF quality warning 1	DEF Quality Low	DEF Quality Low Check DEF System
18	DEF quality warning 2	DEF Quality Low	Engine Stops in "Value" Km Check DEF System
19	DEF quality warning 3	DEF Quality Low	Engine Stops in "Value" Km Check DEF System

## DASHBOARD AND FEATURES

---

Sn	Warning / Information Title	Warning Message Title	Warning Message On Instrument Cluster
20	DEF quality warning 4	DEF Quality Low	Engine Stops in "Value" Km Check DEF System
21	DEF quality warning 5	DEF Quality Low	Engine Stops in "Value" Km Check DEF System
22	DEF quality warning 6	DEF Quality Low	Engine Will Not Restart In Next Key On
23	DEF quality warning 7	DEF Quality Low	Engine Stop Check DEF System
24	DEF fault warning 1	SCR System Fault	SCR System Fault Contact Service Centre
25	DEF fault warning 2	DEF System Fault	Engine Stops in "Value" Km Contact Service Centre
26	DEF fault warning 3	DEF System Fault	Engine Stops in "Value" Km Contact Service Centre
27	DEF fault warning 4	DEF System Fault	Engine Stops in "Value" Km Contact Service Centre
28	DEF fault warning 5	DEF System Fault	Engine Stops in "Value" Km Contact Service Centre
29	DEF fault warning 6	DEF System Fault	Engine Will Not Restart In Next Key On
30	DEF fault warning 7	DEF System Fault	Engine Stop Contact Service Centre
31	Park Brake Fault	Park Brake Fault	Malfunction Detected Contact Service Centre

## Alert Messages (messages displayed within Grey border)



*NOTE: All messages may not be applicable to your vehicle.*

Sn	Alert / Information Title	Alert Message Title	Action To Be Taken
1	HDC Deactivation Due To Speed Above Set Value	Hill Decent Control	System Deactivated Speed Crossed Set Limit
2	Park Brake Engaged	Brake Alert	Park Brake Engaged
3	Electronic Stability Off	Electronic Stability System	ESP Turned Off
4	Traction Control Off	Traction Control System	TCS Turned Off
5	Hill Descent Control Active	Hill Descent Control	HDC Activated
6	Auto Headlamp	Lamp Alert	Auto Headlamp Activated
7	Resume to Target Speed Not Possible in Current Gear	Cruise Control	Change gear to resume Cruise Speed

## DASHBOARD AND FEATURES

---

Sn	Alert / Information Title	Alert Message Title	Action To Be Taken
8	Cruise Override	Cruise Control	Cruise Override
9	Hill Descent Control Switched On	Hill Descent Control	HDC Turned ON
10	Shift to Park (P/N) - vehicle Start function for AT vehicle	Transmission Alert	Shift to Park or Neutral to Start Engine
11	Park Brake Alert	Park Brake Alert	Park Brake Applied
12	Park Brake Alert	Park Brake Alert	Park Brake Not Applied
13	AVH Malfunction	Auto Hold	Malfunction Detected Contact Service Centre

### Drive Alert



Drive the vehicle below 10km/hr in 1st Gear.

#### NOTE

- This Message is not related to any issue or fault in vehicle. It is just Pre-alert customer from clutch malfunction.*
- When User drive the vehicle in higher gear than 1st gear & vehicle speed is below 10 Kmph.*
- When vehicle is launched from standstill condition in 2nd Gear.*

#### NOTE

- This alerts is for Manual Trans-mission (MT) vehicle.*
- The warnings are generated post faulty drive event and is not the live event.*
- The fault is logged after the clutch pedal is fully released and gear information received.*

### Sticker for Drive Alert



RH of Cockpit

## DASHBOARD AND FEATURES

---

### Interrupt Messages



**NOTE: All messages may not be applicable to your vehicle.**


Sn	Alert / Information Title	Action To Be Taken
1	Rotate steering wheel (In ESCL jam condition)	Press Start Button while Turning Wheel
2	Smart key out of range	Smart Key Out of Range
3	Drive Alert - Tea Break	Take a Break
4	Steering Failure-Visit Garage	Steering Failure Contact Service Center
5	Steering Failure-Stop Driving	Steering Failure Stop the Vehicle Safely
6	Door Ajar	Door open
7	TPMS No Fault	Tire Pressure
8	TPMS Low Pressure	Low Tire Pressure - Inflate Tire

## DASHBOARD AND FEATURES

Sn	Alert / Information Title	Action To Be Taken
9	TPMS High Pressure	High Tire Pressure - Deflate Tire
10	TPMS High Temperature	Tire Overheated Slow Down
11	Combination alerts	Check Tires
12	Malfunction	TPMS Malfunction - Contact Service Centre
13	Air Leak	Leakage Detected Check Tires
14	Fault	TPMS Error - Check Tires
15	ESCL	Press Start Button While Turning Wheel
16	No Key	Smart Key Out of Range
17	Low Key Battery	Smart Key Battery Low Replace Battery
18	Press Clutch Pedal	Press Clutch Pedal to Start Engine
19	Press Brake Pedal	Press Brake Pedal to Start Engine
20	Drive Modes	Respective drive mode
21	Tea Break	Take a Break
22	Release Park Brake	Press Brake Pedal to Release Park Brake
23	Happy Birthday	Happy Birthday


## DASHBOARD AND FEATURES

## INSTRUMENT CLUSTER (LCD SCREEN)



**NOTE: All indicators shown may not be applicable to your vehicle**

### Speedometer



Speedometer indicates the vehicle speed in km/h.

#### *i* NOTE

*Whenever you turn the ignition ON, the instrument cluster needles and gauges move to maximum value and return to '0' position. This is a welcome strategy and a self-check feature.*

### Tachometer



Tachometer indicates engine speed in revolutions per min (rpm).

#### WARNING

*Never drive the vehicle with high engine 'rpm'. This may cause severe engine damage.*

### Fuel Gauge

When the ignition switch is in "ON" position, fuel gauge gives an approximate indication of the amount of fuel in the fuel tank. "F" stands for full and "E" stands for empty.



When fuel in the tank is near to empty position, low fuel warning telltale turns Amber. Refill the tank as soon as possible.

#### *i* NOTE

- Check the fuel level when the vehicle on a level road.*
- The fuel level displayed can vary when you drive on inclines, curves, brake and accelerate suddenly. This is due to the movement of fuel in the tank. The low fuel warning lamp may turn to ON or OFF earlier or later than usual.*

## DASHBOARD AND FEATURES

### **WARNING**

If there is any fault in the system, the low fuel warning symbol will start blinking. Take your vehicle to the nearest TATA MOTORS authorized service centre.

### **Temperature Gauge**

When the ignition switch is in the "ON" position, this gauge indicates the engine coolant temperature.



The indicator should stay within the normal, acceptable temperature range between "H" and "C". If the indicator approaches "H", overheating is indicated by a red bar.

If the coolant temperature reading is very high, the engine coolant temperature tell-tale flashes with an audible buzzer. In this case, stop the vehicle, switch 'OFF' the engine and cool it down for some time. Contact the nearest TATA MOTORS Authorized Service Centre immediately for rectification.

### **WARNING**

The Red bar on high coolant temperature warning indicates overheating that may damage the engine. Continuing to drive the vehicle when engine overheating is indicated can result in severe engine damage or fire.

### **IFE Gauge**



It indicates fuel economy of current drive when Ignition is turned 'ON'.

To reach the Instant Fuel Economy in the Instrument cluster. Press the SET and MODE button.

The display does not show actual value unless vehicle is moving.

### *(i)* NOTE

- IFE will vary frequently as per driving pattern.
- IFE display does not show Fuel Economy of last drive.

### DEF Gauge

When the ignition switch is in the “ON” position, this gauge indicates level of DEF left in the tank.



The Indicator should be within the acceptable range. i.e., between “E” and “F”. When DEF in tank is near to empty position, DEF tell tale near to gauge will glow with subsequent text messages on LCD screen. To change screen over from IFE to DEF Gauge press mode button. If DEF level reaches to critically low level, only DEF gauge will be displayed. Screen will

not change over to IFE in that case.

Similarly for Low DEF Quality & SCR Fault there are featured text and warnings present to alert the driver regarding condition of DEF System.

### **WARNING**

- If DEF Level or DEF Quality or SCR Fault becomes critical after defined interval of warnings text alert will be displayed permanently on LCD screen stating vehicle will not restart in next key ON.
- On getting defined text messages related to Quality and SCR Fault, take your vehicle to the nearest TATA MOTORS Authorized service center.

### *(i)* NOTE

- Check the DEF Level when the vehicle is on level road.
- DEF Level Displayed may vary when you drive on inclines, de

clines, curves, brakes & accelerate suddenly. This is due to the movement of DEF in the tank.

- If SCR Fault issue comes then take your vehicle to the nearest TATA MOTORS Authorized service centre.
- IFE gauge and DEF Gauge can be display in rotation with all combinations when DEF level in vehicle is not critical.

## DASHBOARD AND FEATURES


### Driver Information System

Driver Information	System Image	Description
Odometer		Indicates distance travelled by a vehicle. The Odometer reading does not return to "0" when maximum value is reached, the display will freeze to maximum value.
Trip meter A & B	 	The trip meter can be used to measure the distance travelled on short trips or between fuel stops. It can be reset to "0". The Trip meter reading becomes "0.0" after it crosses 9999.9 km.
Clock		Indicates current time in AM/PM mode. Clock time can be changed using 'SET' & 'MODE' knob. Whenever the battery terminals or related fuses are connected, you must reset the clock time. This feature is available when ignition switch is in ON' position. <b>NOTE:</b> Clock settings can also be changed through infotainment system. For more information, refer infotainment manual.
Door Ajar		This warning will be indicated when driver door is open. <b>NOTE:</b> If any other door is open, the roof lamp will be 'ON'.

## DASHBOARD AND FEATURES

Driver Information	System Image	Description
Service reminder		<p>Indicates the number of days/kilometers in which service is due. If service is overdue, it will display "0" km or "0" days and spanner symbol will blink at every ignition ON for few seconds. Never reset the display between service intervals otherwise this may result in to incorrect readings. Information is retained in the service interval display even after the vehicle battery is disconnected.</p> <p><b>NOTE:</b> <i>This option is for indicative purpose only. Keep track of your odometer reading and follow the maintenance schedule.</i></p>
Current gear position indicator (For MT)		<p>Current gear engaged by the transmission shall be displayed on Driver Information System.</p> <p><b>NOTE:</b> If "F" is displayed it means a 'Fault' condition. Contact the TATA MOTORS authorized service centre.</p> <p><i>In case of Manual Transmission, the gear number shall be displayed when the clutch is fully released.</i></p>
Gear Recommendation		<p>Up or down arrow shall be displayed on DIS whenever a gear should be shifted up or down.</p> <p>No arrow shall be displayed when the selected gear is as per the vehicle dynamics.</p>

## DASHBOARD AND FEATURES

Driver Information	System Image	Description
Current gear position indicator (For AT)	 The image shows a vertical stack of four black squares, each containing a white letter: 'P' (Park), 'R' (Reverse), 'N' (Neutral), and 'D' (Drive). To the left of this stack, the number '2' is displayed in a large, bold, black font. <p>P Park R Reverse N Neutral D Drive</p>	<p>Current gear engaged by the transmission shall be displayed on DIS.</p> <p><b>NOTE:</b> If "F" is displayed it means 'Fault' condition. Contact the TATA MOTORS Authorised Service Centre.</p> <p><i>In case of Automatic Transmission, the Gear numbers shall be displayed as per automatic gear selected.</i></p>

### Average Fuel Economy (AFE)



Trip time, Average speed and Trip distance will reset to '0' when respective Trip meter is reset.

Average Fuel Economy will be displayed as '—.—' for initial 0.5 km of respective trip. Once 0.5 km distance is covered, Average Fuel Economy will be displayed.

Even after 0.5 km distance covered for particular trip, if Average fuel economy is displayed as '—.—', then take your vehicle to TATA MOTORS Authorized Service Centre.

#### NOTE

- *AFE value is an estimate of fuel economy. It may vary significantly based upon driving conditions, driv*

*ing habits and condition of vehicle.*

- *Average Fuel Consumption will get Reset to '0' when Battery is removed and refitted.*

### Distance To Empty (DTE)



The above image indicates an approximate distance in 'km' that your vehicle can travel with available fuel in tank.

DTE values may vary significantly based on driving conditions, driving habits, and condition of the vehicle. It is an estimate value of the available driving distance.

The DTE will update with new value when fuel is added more than 7 litres at a time.

If low fuel warning light turns 'ON', fill the fuel tank immediately regardless the value of displayed DTE.

#### NOTE

*If DTE is displayed as '—.—', then take your vehicle to the TATA MOTORS authorized service centre.*

### Instrument Cluster Illumination



Instrument cluster illumination & backlight illumination will turn on after Park lamp is ON.

Illumination can be changed by SET button short press (less than 1.5 seconds).

## DASHBOARD AND FEATURES

### ⚠ WARNING

The clock and instrument cluster illumination settings should be changed only when the vehicle is in stationary condition for safety purposes.

### Outside Ambient Temperature



This displays outside ambient temperature in units of °C with the resolution of 1 °C.

The temperature sensor is located on the front bumper of the vehicle, therefore the temperature reading can be affected by heat reflection from the road surface, engine heat and the exhaust from surrounding traffic.

### ⓘ NOTE

- *If temperature fault is present then screen changes automatically for every IGN cycle to show temperature readings.*
- *Do not use any type of liquid solutions or chemical solutions to avoid failure in sensor functionality.*

### TPMS Screens

### ⓘ NOTE

*When start the vehicle or make ignition ON it may happen Pressure & Temp value show “—”. Driver has to drive the vehicle for some time with particular Speed to update the TPMS pressure and Temperature value's If value's not updated and display shows “—” with warning message then take vehicle to service center.*

TPMS screen with no fault



## DASHBOARD AND FEATURES

TPMS screen with low tire pressure



TPMS screen with combination of failures in tires




TPMS screen with high tire pressure



TPMS screen with Error



TPMS screen with Malfunction



TPMS screen with leakage



## DASHBOARD AND FEATURES

### Display Messages on Instrument Cluster



Sn	Warning Title / Title	Warning Messages On Instrument Cluster
1	Speed Limit Warning	OVER SPEED
2	HDC Deactivation Due To Speed Above Set Value	HDC DEACTIVE
3	Engine Is Locked	ENGINE LOCKED
4	Low Brake Fluid	LOW BRAKE FLUID
5	Electronic Stability Off	ESP OFF
6	Hill Decent Control Active	HDC ACTIVE
7	Service Reminder Days	SERVICE DUE
8	Service Reminder Kms	SERVICE DUE
9	Fuel Level Low State	LOW FUEL
10	Drive Alert1 - Tea Break	TAKE A BREAK
11	Smart key out of range	KEY OUT OF RANGE
12	Rotate steering wheel (In ESCL jam condition)	ROTATE STEERING
13	Resume to Target Speed Not Possible in Current Gear	UNABLE TO RESUME
14	Cruise off	CRUISE OFF
15	Cruise deactivated/cancel	CRUISE CANCELLED

**NOTE:** All messages may not be applicable to your vehicle.

## DASHBOARD AND FEATURES

Sn	Warning Title/ Title	Warning Messages On Instrument Cluster
16	Cruise is Resuming to set speed	CRUISE RESUMED
17	Press Clutch for MT	PRESS CLUTCH
18	Press Brake for MT	PRESS BRAKE
19	Transmission Failure Limp home Activated Visit Service Center	AT FAULT
20	Shift to Park (P) - vehicle Stop function for AT vehicle	SHIFT-> P
21	Shift to Park (P/N) - vehicle Start function for AT vehicle	SHIFT->P/N
22	TPMS Error	TPMS ERROR
23	TPMS Pressure Warning	CHECK TIRE PRESSURE
24	Jet Pump Fault	FUEL SYS FAULT
25	Transmission oil temp high	AT TEMP HIGH
26	DEF Level Low Level 1	DEF LOW REFILL SOON
27	DEF Level Low Level 2	ENG NOT START AFTER "VALUE" KM

Sn	Warning Title/ Title	Warning Messages On Instrument Cluster
28	DEF Level Low Level 3	ENG NOT START AFTER "VALUE" KM
29	DEF Level Low Level 4	ENG NOT START AFTER "VALUE" KM
30	DEF Level Low Level 5	ENG NOT START AFTER "VALUE" KM
31	DEF Level Low Level 6	ENG NOT START NEXT KEY ON
32	DEF Level Low Level 7	ENG STOP DEF EMPTY
33	DEF Quality Low Level 1	LOW DEF QLTY
34	DEF Quality Low Level 2	LOW DEF QLTY ENG OFF "VALUE" KM
35	DEF Quality Low Level 3	LOW DEF QLTY ENG OFF "VALUE" KM
36	DEF Quality Low Level 4	LOW DEF QLTY ENG OFF "VALUE" KM
37	DEF Quality Low Level 5	LOW DEF QLTY ENG OFF "VALUE" KM
38	DEF Quality Low Level 6	LOW DEF QLTY ENG NOT START
39	DEF Quality Low Level 7	LOW DEF QLTY ENG STOP

## DASHBOARD AND FEATURES

---

Sn	Warning Title/ Title	Warning Messages On Instrument Cluster
40	SCR Fault Level 1	SCR FAULT
41	SCR Fault Level 2	SCR FAULT ENG OFF "VALUE" KM
42	SCR Fault Level 3	SCR FAULT ENG OFF "VALUE" KM
43	SCR Fault Level 4	SCR FAULT ENG OFF "VALUE" KM
44	SCR Fault Level 5	SCR FAULT ENG OFF "VALUE" KM
45	SCR Fault Level 6	SCR FAULT ENG NOT START
46	SCR Fault Level 7	SCR FAULT ENG STOP
47	Happy Birthday	Happy Birthday

## TELL TALES

Warning Lamps	Color	Indicator	Remarks
Malfunction Indication Lamp (MIL)	Amber		<ol style="list-style-type: none"> <li>1. This lamp comes on when ignition is switched 'ON'. Once engine is started, it turns 'OFF'.</li> <li>2. It remains 'ON' for any engine related fault that may increase emission levels of the vehicle beyond the regulatory norms. Contact the TATA MOTORS Authorized Service Centre for rectification.</li> </ol>
Check Engine Lamp	Amber		<ol style="list-style-type: none"> <li>1. This lamp comes on when ignition is switched 'ON'. Once engine is started, it turns 'OFF'.</li> <li>2. This lamp comes on continuously if a fault arises in Engine Management System. Contact the TATA MOTORS authorized service center.</li> </ol>
Immobilizer	Red		<ol style="list-style-type: none"> <li>1. This lamp comes on when the system disables engine start if the original key is not used.</li> <li>2. Lamp blinks: Vehicle is in immobilized condition when key is not inserted.</li> <li>3. Lamp ON: Problem with key/system. Contact a TATA MOTORS Authorized Service Center.</li> <li>4. Lamp OFF: Normal condition (Authenticated user) and engine will start.</li> </ol>
Pre-Heat indicator / Glow Plug indicator (Diesel)	Amber		<ol style="list-style-type: none"> <li>1. This lamp comes on when ignition key is in 'ON' position.</li> <li>2. Engine shall be started only after this indicator goes 'OFF'.</li> </ol>

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
Turn Signal	Green		Indicates direction indicated by the turn signal. Blinks along with buzzer while operating left/right turn indicator only when ignition is switched 'ON'. The direction indicator arrow on Instrument Cluster flashes along with external indicator lights as selected. Both Tell tales shall blink simultaneously when Hazard switch is pressed irrespective of Ignition ON and the Tick-Tock sound shall be given when any one or both the Tell tales are ON.
High Beam	Blue		This lamp comes on when the high beam headlamps are switched 'ON' or flashed.
Low Oil Pressure indicator	Red		<ol style="list-style-type: none"> <li>1. This lamp comes on when ignition is switched 'ON' and goes 'OFF' once required engine oil pressure is developed after starting the engine.</li> <li>2. If the low oil pressure indicator does not glow or remains 'ON' with the 'IGN' 'ON' and engine is running, it indicates a fault in the electrical circuit / lubrication system. Contact the TATA MOTORS Authorized service center.</li> </ol>
Battery charging	Red		This lamp comes on when ignition is switched 'ON' however it will be switched OFF after pre check of 4sec. If it remains 'ON' while the engine is running, it indicates that the battery is not getting charged. Switch off all unnecessary electrical equipment and contact the TATA MOTORS Authorized service center.
Driver seat belt warning	Red		Seat belt warning indicator comes 'ON' for 4 seconds, when ignition is turned 'ON'. If seat belt is not fastened and speed is less than 15 Kmph, then seat belt tell-tale will turn ON as initial warning.

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
			<p>If seat belt is not fastened and vehicle speed goes above 15 Kmph, then final warning will start with telltale flashing and Audio chime for 90 seconds. After 90 seconds, telltale will be ON and Audio chime will be OFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Telltale will turn off either when seatbelt is buckled or Reverse gear is engaged when it is in initial warning stage.</li> <li>• When it is in final warning with Chime ON, the telltale will be OFF on fastening the seat belt or engaging the reverse gear.</li> </ul>
HHC Warning lamp (if available)	Amber		<p>In case of HHC malfunction HHC warning lamp will remain continuously ON. Please take your vehicle to nearest TATA authorized service center at the earliest.</p>
Airbag status (if available)	Red		<p>This lamp comes on when ignition is switched 'ON' and goes 'OFF' in approx. 4 seconds. If it continuously remains on or blinks then contact the TATA MOTORS Authorized service center immediately.</p>
Park Brake / Brake Fluid Low / EBD malfunction	Red		<p>This lamp comes on momentarily when ignition is switched 'ON'. Once parking brake is released, it turns 'OFF'. If it remains 'ON', it indicates</p> <ol style="list-style-type: none"> <li>1. Brake fluid level is low.</li> <li>2. Park brake is applied &amp; turns 'OFF' when it is released.</li> <li>3. EBD malfunctioning.</li> </ol>

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
High Coolant Temperature	Red		<p>Illuminates when ignition is switched 'ON' and goes 'OFF' in approx. 4 seconds.</p> <p>If the engine is overheating, this indicator blinks along with an audible buzzer at this stage. Contact the TATA MOTORS Authorized Service Centre immediately. This symbol blinks along with audible buzzer when engine coolant temperature is more than normal. When engine coolant temp increases to hazardous level, Tell tale shall blink with RED color and it is accompanied by audio warning.</p> <p><b>Note:</b> Never remove the radiator pressure cap from the radiator when the engine is hot. Do not restart the engine until the problem has been duly attended.</p>
ABS	Amber		<p>The lamps comes on when ignition is switched 'ON' and goes 'OFF' in 3 seconds. The lamps remains on continuously if there is any malfunction in ABS. Normal braking system will be operational without assistance of ABS. Contact the TATA MOTORS Authorized service center.</p>
Low Fuel indicator	Amber		<p>Illuminates momentarily when ignition is switched 'ON'.</p> <p>The symbol lights up continuously if fuel level in the tank is low. Fuel needs to be filled immediately.</p> <p><b>IMPORTANT:</b> The telltale warning lamp will start flashing if there is any fault in the fuel system. Contact the TATA MOTORS Authorized service center immediately.</p>

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
Cruise Control lamp (if available)	Green		This symbol lights up when the 'IGN' is turned 'ON' and shall go 'OFF' after 4 sec. The Cruise Control is used to indicate the status of cruise control system to the driver. Lamp ON indicates cruise control feature is present and it is activated.
Press Clutch Pedal to Start Engine (if available)	Amber		Press Clutch: The lamps comes on ON with IGN ON till user presses the clutch pedal to start the engine.
Water in fuel indicator (Diesel)	Amber		The lamp remains on continuously if excess water is accumulated in the fuel filter. Contact the TATA MOTORS Authorized service center to drain the water immediately to avoid serious damage to the fuel injection system.
Daytime running lamps (DRL) (if available)	Green		DRL are used to increase the visibility of the vehicle to other drivers during daytime. This lamps comes on when the Day Time Running lamp is 'ON'.
Door Ajar lamp	Red		All four door and Tail gate are indicated independently when the respective door or tail gate is open.
HDC ON lamp (if available)	Green		The lamps comes on if Hill Decent Control System is activated. If continuously ON then HDC system is at fault condition, Please take your vehicle to nearest TATA authorized service center at the earliest.

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
Rear Fog Lamp (if available)	Amber		The lamps comes on when the rear fog lamp is 'ON'.
Front Fog Lamp (if available)	Green		The lamps comes on when the front fog lamp is 'ON'.
Key Not Detected (if available)	Amber		This lamps comes on when the Valid Smart key is not detected inside the vehicle. <b>Note:</b> Refer PEPS section more details.
HDC fault indicator (if available)	Amber		The lamps comes on if Hill Decent Control System is activated In case of malfunction in HDC system this indicator will glow. It will remain ON until fault recovers. Please take your vehicle to nearest TATA authorized service center at the earliest.
Electronic Stability Program (ESP) (if available)	Amber		This lamp will flicker in the event of active ESP or TCS interventions. If continuously ON then ESP system is at fault condition, Please take your vehicle to nearest TATA authorized service center at the earliest.
Automatic parking Brake	Red		The Lamp comes ON once APB switch is pulled and APB is engaged along with single chime on instrument cluster. "Park Brake Engaged" text message will also appear in instrument cluster.

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
Front passenger Seat Belt Indicator	Red		<p>The Front passenger seatbelt warning indicator turns ON when ignition is turned ON.</p> <p>If front passenger seat is occupied by adult, the warning lamp remains ON as long as the co-driver seatbelt is not fastened.</p> <p>If seatbelt remains unbuckled and vehicle goes above 15 kmph, then final audio warning will go on for 90 seconds.</p> <p><b>Note:</b> Once the seatbelt is fastened the buzzer and warning lamp turns OFF. Seatbelt reminder remains OFF when reverse gear is engaged.</p>
Speed limit warning indicator	Amber		<p>This lamps comes on when ignition is switched 'ON' and goes 'OFF' after 4 Seconds.</p> <p>When the vehicle speed cross 80 kmph, then speed limit warning indicator turns 'ON' along with audio chime for every 2 minute chime (Audible warning).</p> <p>If vehicle speed crosses 120 kmph, the speed limit warning indicator turns 'ON' along with an audio chime (audio warning) continuously, until the vehicle speed is above 120 kmph.</p> <p>If vehicle speed is between 80 kmph and 120 kmph, then the audio chime (audio warning) will become less frequent but the speed limit warning indicator will remain 'ON' continuously. When the vehicle speed is reduced below 80kmph, then the speed limit warning indicator and the audio chime (audio warning) will turn off.</p>
DPF Lamp	Amber		The lamp blinks constantly to indicate that the DPF needs to eliminate the trapped pollutants (particulate matter) through the regeneration process, it

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
			<p>therefore does not indicate a malfunction. The lamp remains off during the entire DPF regeneration and it lamp up only when driving conditions require the driver to be notified. To switch off the lamp, keep the car running until regeneration is complete (ideally at 3<sup>rd</sup> gear, 60 kmph. with engine speed over 2000 rpm). The process normally takes about 20 minutes.</p> <p><b>Note:</b></p> <p><i>Failure to obey the correct procedure for long distance when the DPF lamp comes ON can cause the warning lamp (MIL) to come ON. In that case, please contact nearest TATA authorized service center to restore correct DPF operation.</i></p>
ECO (if available)	Green		ECO lamp ON indicates Economy drive. This mode is used to achieve better fuel economy.
SPORT (if available)	Amber		SPORT lamp ON indicates Sport drive mode. This mode is used to when more torque is required.
CITY (if available)	White		CITY lamp ON indicates City drive mode. This mode is used to achieve optimum torque with fuel economy.
DEF level	Amber		This Telltale warns the driver once DEF level is detected to be low. This TT monitors for emission issues.

## DASHBOARD AND FEATURES

Warning Lamps	Color	Indicator	Remarks
SCR Fault	Amber		This features monitors the catalyst health & warns the user if there is a malfunction.
TPMS (If applicable)	Amber		To give tire low pressure, high pressure & pressure leakage warnings to user.
Electric Park Brake (If applicable)	Amber		In case of malfunction in Electric Park brake this indicator will glow, it will remain ON Until Fault recovers.
Automatic Hold Failure	Amber		In case of malfunction in Auto Hold Function this indicator will glow, it will remain ON Until Fault recovers.
Automatic Hold Active	Green		This Tell-tale will glow whenever Automatic Hold Function is in Active state.
Automatic Hold ON	White		This Tell-Tale will become ON whenever auto hold function is in On state.

## DASHBOARD AND FEATURES

---

### AUDIO REMINDERS (if available)

#### Key-in Reminder/audio Warning

While leaving the vehicle, if you forget the key inside the vehicle in ignition 'OFF' position, an audio warning will sound. Remove key to stop the warning.

#### Park Lamp 'ON' Reminder

While leaving the vehicle, if you forget to turn 'OFF' the headlamps, buzzer will sound. Switch 'OFF' lamps to stop the warning sound. Do not forget to turn 'OFF' your lamps as it may drain the vehicle battery.

#### Park Brake 'ON' Reminder

If park brake is applied and vehicle is driven, Telltale lamp will turn 'ON' and buzzer will provide audio warning continuously. Disengage the park brake to stop audio warning.

#### Reverse Gear Reminder

If reverse gear is engaged, the buzzer sound will alert you.

#### Driver Seat Belt Reminder

If seatbelt is not fastened and vehicle goes

above 15 kmph, then final audio warning will go on for 90 seconds. Seat belt tell-tale lamp will remain continuously ON when audio alarm is active.

#### NOTE

*Fasten the seatbelt to stop audio warning.*

#### Front Passenger Seat Belt Reminder

If front passenger has not fastened seatbelt and if vehicle speed goes above 15 kmph, then final audio warning will go on for 90 seconds. Seat belt tell-tale lamp will remain continuously ON when audio alarm is active.

#### NOTE

*Fasten the seatbelt to stop audio warning.*

### ESCL Chime

If electronic steering column lock gets inadvertently engaged, this chimes sounds and informs user to rotate steering wheel.

### Electric Park Brake Chime

There are multiple chimes like single tone, Soft cyclic, strong cyclic chime present in this chime. Appropriate chime will sound whenever recommended condition occurs.

### Drive Mode Chime

If you change drive modes from city to eco or eco to sports one time drive mode chime sounds.

### DEF System Chimes

If DEF Level or DEF Quality or SCR Fault becomes critical low then continuous periodic chime will sound.

### AT Chimes

- Whenever Driver try to switch off ignition while gear lever not in Park position then single chime will sound to remind driver to move gear level to Park position and then switch off ignition.

- Whenever Gear level not in Neutral or Park position & if driver tries to start the vehicle then single chime will sound to remind driver to take gear level in Park or Neutral position and then start the vehicle.

### TPMS Chime

If TPMS alert condition occurs, TPMS chimes shall sound for 4 secs and for TPMS fault conditions TPMS chime shall sound for 20 sec.


### High Coolant Temperature Reminder

Engine Coolant Temperature High Chime feature monitor the Engine coolant temperature input and when the temperature is high it gives continuous audio warning.

### BSVI Chime

Whenever DEF Level will be low or SCR fault will occur then one time chime will sound for level 1 and level 2. For level 3 to level 7 there will be a continuous chime until fault recovers.

### COMBI-SWITCH (RH Stalk)



#### 1. Left Turn Signal

Move the lever fully upward.

#### 2. Right Turn Signal

Move the lever fully downward.

#### NOTE

*When the turn is completed, the signal will cancel and the lever will return to its normal position*

### 3. High Beam

Move the lever forward to select the high beam function.

Pull the lever back to normal for low beam.

### 4. High Beam Flash (spring return)

To flash the high beam, pull the lever towards you from the normal position. It will return to its normal position when you release it.

### 5. Headlamp Rotary Switch

#### OFF Position

All lamps will remain 'OFF'



#### Parking Lamp

Rotate stalk to turn 'ON' the



Parking lamps.

#### Day Time Running Lamps (DRL) (if Available)

Day time running lamp are used to increase the visibility of the vehicle to others drivers during daytime.



- To activate and deactivate DRL, keep the ignition switch in 'ON' position and switch ON-OFF parking lamp twice

## DASHBOARD AND FEATURES

---

within approximately three sec.

2. Activation and deactivation of DRL can be done by DRL soft switch which is available on head unit display.

### Low Beam

Rotate stalk to turn 'ON'  the Low Beam function.


### Auto Light

The headlights will be automatically switched ON  depending on ambient light conditions (while entering a tunnel or when it is twilight).

### 6. Lane Change Signal


To signal a lane change, move the lever slightly up or down to the point where the turn signal light begins to flash for six times, but the lever does not latch. The turn signal will flash six times automatically.

### 7. Head Lamp Levelling Rotary Switch



Inner rotary switch on right hand stalk is provided for head lamp leveling. With the inner rotary switch, Head lamp leveling can be done with head lamp in Low Beam and in 'ON' position. Select correct position before start of trip when the vehicle is stationary. Depending on the number of passengers and luggage in the vehicle headlamp focus may change. This can be adjusted by rotating the knob to one of the 3 level positions.

### COMBI-SWITCH (LH STALK)



#### 0. 'OFF' Position

The wiper is switched 'OFF'.

#### 1. Intermittent Wipe

Push the stalk upwards to operate intermittent wipe.



Inner rotary switch on left hand stalk is provided for intermittent front wiper delay. The switch has 5 delay timers.

#### 2. Slow Wipe

Push the stalk towards position (2) for continuous slow wipe.

#### 3. Fast Wipe

Push the stalk towards position (3) for continuous fast wipe.

#### 4. Flick Wipe (spring return)

Pull the stalk downwards and hold it for continuous wipe, the wiper continuously wipes across the windshield at low speed till the stalk is released.



#### 5. Front Windshield Washer

- Pull the lever little longer, to spray the washer fluid on the windshield.
- The windshield wipers operate for 3 cycles after the lever is released and 1 more cycle after 5 seconds.




#### Auto Front Wipe (if available)

If your vehicle is fitted with rain and light sensor, the wipers will automatically wipe the windscreens, if it senses rainfall. Make sure that the wiper stalk is in Auto position.

#### (i) NOTE

*When you crank the engine, the supply to washer motor is momentarily cut off.*

#### 6. Rear Wash And Wipe (if available)



#### Rear Windshield / Wiper And Washer

Turn the rotary knob clockwise and release to operate rear windshield wash and wipe. The windshield wipers operate for 3 cycles.



## DASHBOARD AND FEATURES

### Rear Wipe

Turn the rotary knob counter clockwise such that it aligns its positions with arrow mark to operate rear windshield wiper continuously.



#### NOTE

*Rear wiper will not work as long as tailgate is open.*

### Rear Windshield / Wiper And Washer Switch

Turn the rotary knob counter clockwise such that it aligns its positions with arrow mark and hold it to operate rear windshield wash and wipe function. It will return to 'Rear wipe' position as soon as it released and continue to wipe.



#### WARNING

If you operate wash and wipe function for more than 15 seconds the controller cuts off the supply to the washer motors to avoid overheating.


### Rain / Light Sensor (if available)

Rain & light sensor is integrated sensor & mounted on front windshield glass to sense rain & light.

As per the input from sensor, the wipe and light function will work automatically.


### FASCIA SWITCHES

Fascia switches are provided on the center console below HVAC control panel.



1. Rear fog lamp switch (if available)
2. Front fog lamp switch (if available)
3. Hazard warning switch
4. Economy mode switch (if available)
5. Sports mode switch (if available)

### STEERING WHEEL SWITCHES (LHS) (if available)



#### Volume

Press above switch to increase or decrease volume of music system / radio.



#### Seek Forward / Backward

Press above switch to change radio channels.



#### Phone Receive / PTT (Push to Talk)

Press above switch to accept incoming call when a cell phone



is connected via Bluetooth.

#### Voice Recognition

To start, long press the voice activation button provided on the steering wheel. The system mutes/ pauses the currently played audio and you will hear a beep sound to indicate the activation of the voice recognition feature. The system also display the icon on the top right corner of the screen to indicate activation of voice recognition.

#### *(i) NOTE*

*The system will start recognizing your voice command only after the beep. So, speak your command only after you hear the voice activation beep.*

#### Source

Press above switch to select the required source in the infotainment system i.e. USB, AUX, AM, FM and Bluetooth.



#### Mute / Phone Reject

Press above switch to reject or hang up a phone call. It is also used to mute the volume of music system / radio.




#### *(i) NOTE*

*For more information of steering wheel switches refer infotainment manual. ((Refer link <http://service.tatamotors.com/content/owners-manual> )if available).*

## DASHBOARD AND FEATURES

### STEERING WHEEL SWITCHES (RHS) (if available)



#### Instrumentation Controls(IC) Up

#### Instrumentation Controls Scroll Up

Press above switch to scroll up on Instrument Cluster display.



#### Instrumentation Controls Scroll Down

Press above switch to scroll down on Instrument Cluster display.



#### OK / Select & Long Press for Setting

Press above switch to select the option and also press long (ap-



prox. 3) to go directly to Instrument cluster settings.

#### Cruise Resetting/setting Speed Increasing/decreasing Switch

- Press the cruise control master switch on steering wheel.
- Accelerate the vehicle to the desired speed.
- Press the 'SET' button on steering wheel switch to set the desired cruise speed. The cruise control indicator on instrument cluster will turn 'ON'.
- Remove your foot from the accelerator pedal.



Once Cruise control is activated the vehicle automatically maintains the stored speed.

#### Changing the Set Cruise Speed

The set cruise speed can be adjusted (i.e. increased or decreased) using '+' (to increase) or '-' (to decrease) switches on steering wheel. The speed increases and decreases on a single press. The changed speed will be



shown on the speedometer. Keeping the switch pressed increases or decreases the speed continuously till the switch is released. The set speed can also be increased by pressing the accelerator pedal till the desired speed is achieved and then pressing the 'SET' button. The set speed can also be decreased by pressing the brake pedal (The cruise indicator will turn OFF) and slowing down to desired speed and then pressing the 'SET' button (The cruise control indicator will turn 'ON' again).

#### Cruise Control Master Switch

Cruise speed can be resumed only if cruise control is deactivated by depressing Brake Pedal. To resume the previously set cruise speed, accelerate the vehicle to a speed above approx. 32 kmph and press reset ('RES') switch.



#### Cruise Control Deactivating Switch

There are several ways to deactivate cruise control:



- Applying brake / clutch.

- Press deactivation switch on Steering Wheel.
- Activation of ESP/ TCS system.

### MIC (if available)



Mics are provided on roof near the roof lamp.

### INFOTAINMENT SYSTEM DISPLAY (if available)



#### *(i)* NOTE

For more information, refer infotainment manual.

- ((Refer link - <https://cars.tatamotors.com/service/owners/owners-manual>) if available).
- For IOP listed phones, Refer refer: <https://cars.tatamotors.com/service/owners/phone-bluetooth-compatibility-with-car-infotainment-system>

## DASHBOARD AND FEATURES

### Reset Infotainment System

For your safety and convenience, the system has self-healing process by self-rebooting itself without hampering the driving experience.

However, in any rare case, where the system does not self-heal by reboot itself, then the system can be recovered by performing master/force reset.



#### Procedure for Master / force reset

1. Press both the knobs (1 and 2) simultaneously for more than 5 seconds until system restarts.
2. After System reboots, take the key out.
3. Put key in again and Switch ON Ignition to turn the system on.

### NOTE

- *It is preferable to do one Ignition OFF to ON cycle after Master/Force reset to synchronize vehicle settings with the TATA Infotainment System.*
- *If the reboot does not work or master/force resets are required on a weekly or daily basis, vehicle shall be taken to dealership. There, the dealer can update your firmware or inspect the system for hardware problem.*
- *Force/Master reset keeps the stored data, such as call history, text message information, and previously paired phones as it is.*

### WARNING

- The vehicle sound system is capable of delivering loud sounds at higher volume levels. Continued exposure to such a higher volume levels may affect / damage hearing.


- Prolonged use of vehicle sound system at higher volume levels may overheat the electronics in-side. To avoid any permanent damage, a self-protection mechanism within the system reduces the sound output until it reaches to the acceptable temperature and then the sound output restores automatically.
- Use of vehicle sound system at higher volume levels for a long time in Engine OFF condition might drain vehicle battery.

### SPEAKERS & TWEETER (if available)



*Speaker*

Speakers and tweeters are provided on models with infotainment system. Provisions are given for music system and speakers on versions without infotainment system.



### USB CHARGER (if available) In Chiller Box



## DASHBOARD AND FEATURES

---

### In 3rd Row Passenger



Connect your portable digital music players, pen drives etc. to this socket for playing music tracks through the vehicles music system.

### Smart Charger/usb For Second Row (if available)



Smart charger (dual) is available be-tween the front passenger seats below the rear stowage area for second row passengers.

It is used to charge the mobile phone, Power Bank etc.

### POWER SOCKET




Power socket is available inside the cooled storage box on the center console. The power socket will work when the ignition switch is in the "ACC" or "ON" position. This socket can be used to provide 12V (10A) power for electrical accessories.

### ① NOTE


*Use of inappropriate electrical accessories can cause damage to your vehicle's electrical system. Make sure that any electrical accessories you use are designed to plug into this type of socket and rating.*

### ANTENNA (if available)



Antenna is located on the roof. Turn antenna anticlockwise to remove from vehicle, if required.


### SHARK FIN ANTENNA (if available)



Shark fin antenna is provided on the roof at rear end.

## DASHBOARD AND FEATURES

### ROOF GRAB HANDLE (if available)



Grab handles are installed on the roof for all seats except for the driver's seat. These help the passengers to position themselves comfortably during the journey.

### FRONT FOG LAMPS (if available)

Front fog lamp is located on front bumper. When visibility is poor due to fog, snow or rain, use the fog lamps to improve visibility as well as making it easier for other road users to see you.



For switching 'ON' the Fog lamps, either the Head Lamp or Parking lamp must be 'ON'.

Operate the front fog lamp switch provided on fascia to 'ON' or 'OFF' the fog lamp.

An indicator on the switch will be illuminated when the front fog light is 'ON'.

#### Cornering Feature

For front fog lamp cornering feature the Head Lamp must be 'ON'.

As you turn steering wheel to left or right, the corresponding fog lamp will automatically get 'ON'.

### REAR FOG LAMPS (if available)

Rear Fog Lamp is provided on rear bumper to improved visibility in adverse weather conditions to vehicles behind you.




For switching 'ON' the rear fog lamps, front fog lamp must be 'ON'.

Operate the rear fog lamp switch provided on fascia to 'ON' or 'OFF' the fog lamp.

An indicator on the switch will be illuminated when the rear fog light is 'ON'.

### PUDDLE / AJAR LAMP




Puddle / Ajar Lamp is provided on driver, front passenger & rear doors trim. It will be ON only when particular door is in open condition.

### ROOF LAMP

Interior roof lighting lamp is provided on the roof with inbuilt switch.

#### Front Roof Lamp

##### Option 1




1. Spot / Reading Lamp for Front passenger side
2. OFF
3. DOOR
4. ON
5. Spot / Reading Lamp for Driver side


## DASHBOARD AND FEATURES

---

### Option 2



### Rear Roof Lamp (if available)



The switches has below functions:

#### Spot / Reading Lamp For Front Passenger Side

The front row interior lamp has separate switches to operate the spot / reading lamp for Front passenger side.

#### OFF

In this position, the lamp will remain 'OFF'.



### DOOR

In this position, the lamp turns 'ON' with dimming when either of the doors are opened. When the last door is closed, the lamp will turn 'OFF' with dimming. This helps settling in the seat and inserting the key in the ignition switch. When the key is turned to the 'IGN' position, the lamp goes 'OFF' immediately.



#### ON

The lamp will turn 'ON' as long as the switch is in this position.




#### Spot / Reading Lamp for Driver Side

The front row interior lamp has separate switches to operate the spot / reading lamp for Driver side.



### Side Reading Lamps (if available)



Side reading lamps (applicable for variants with Sunroof) are provided above second row seat passenger doors.

The lamps will operate independently & without any connectivity with door.

Inbuilt switches are also provided on both lamps to operate manually (Switch 'ON' or 'OFF') the lamps when required.

### BOOT LAMP



Boot lamp is available in the rear luggage compartment to light up the luggage area. Boot lamp is without switch type. It will be ON only when tailgate is open.


### SIDE INDICATOR LAMP ON ORVM



It is provided on outer part of ORVM. It will turn ON when the turn signal indicator switch is ON and Hazard Warning indicator switch is ON.

## DASHBOARD AND FEATURES

### FRONT LAMP



1. Position / DRL / Turn indicator lamp (if available)
2. High beam lamp
3. Front fog lamp (if available)
4. Low beam lamp

### Lamp Condensation / Fogging Condition


Condensation is a natural phenomenon in Lamp. This occurs mainly because of atmospheric condition/weather change. During normal condensation, thin film of mist is visible on the inside surface of the exterior lens. Generally, this condition is con-

sidered normal and will be eliminated by turning on the respective lamp with engine running or during normal driving conditions. By doing this if the condensation has began to clear after the drying time it indicates that the lamp sealing has NOT been breached and will eventually clear. The lamp must NOT be replaced.

#### ① NOTE

- *All Exterior lamp fogging / condensation is natural occurrence and respective lamp assembly replacement will not necessary to resolve the issue.*
- *High-pressure washer jet direct on vent system of lamp are not recommended, there might be possibility of water ingress causing for heavy fogging.*
- *Presence of condensation / mist in non-functional area is normal and acceptable, no action is recommended.*

### TAIL LAMP



1. Turn indicator
2. Reverse lamp
3. Parking lamp
4. Stop lamp

### AMBIENT LIGHTS (if available)

#### Ambient Light function

Interior ambient lighting comforts user by illuminating the vehicle interiors at defined locations. Single colored LEDs are fixed at various locations of the vehicle interiors.

#### Turning Ambient lighting on and off:

- Ambient Lights turn on in Blue color whenever parking light is turned to ON.
- Ambient Lights turn off whenever parking light is turned to OFF.

#### Ambient Lights (Entry/Exit):

- Ambient Lights turn on in Blue color whenever roof lamp made active by removing the ignition key from key slot and opening any door.
- Once the opened door is closed, the Ambient lights dims off after approximately 25 seconds.
- If door is left open, ambient lights will turn OFF after set battery saver time.

### iRA (INTELLIGENT REAL-TIME ASSIST) Connected Car Service

Car is equipped with iRA - Connected car Technology which offers a host of features to the users through the "iRA - Connected car" Mobile Application (APP). The Vehicle is equipped with an Electronic Control unit which monitors & records the data from various vehicle systems like Engine, Transmission, Brake, Battery & other electrical systems. This data is then processed & used for providing the connected Car features (For details & list of features, please refer the connected car brochure provided to you along with this manual). (Refer the app tour section of the mobile app.)

The Connected Car module records the following information:

#### Vehicle Telematics

This includes the periodic transmission of data from other vehicle ECUs & Electronic systems like EMS, ABS, Air Bag,

BMS, BCM etc. along with the geographical location of the vehicle.

#### Vehicle driving behavior

This includes the location, speed, acceleration, trip details, charging etc.

#### Event based recording

This includes data generated during specific events like vehicle collision, intrusion, un-authorized entry etc.

The Data collected through Connected Car module is used by TATA MOTORS PASSENGER VEHICLE LIMITED for various purposes, including, but not limited to,

Providing Connected Car features through Mobile APP.

- Evaluation of Vehicle performance.
- Research & improvement of current & future vehicle designs.
- Troubleshooting & diagnostics of the vehicle.

TATA MOTORS does not disclose the data recorded from your vehicle to any third party except:

- After obtaining a written consent from the Car Owner.
- Upon request from Law enforcing

## DASHBOARD AND FEATURES

---

- agencies and regulatory bodies.
- Used for research purpose without the Personal Verifiable information (anonymized).
- Used as defence of TATA MOTORS in a Lawsuit.

### WIRELESS POWER CHARGING (if applicable)

#### WPC System Description

Wireless Power Charging (WPC) is a convenience feature to charge the smart mobile phone using wireless charging technology, without a need to plugin wire in the device.

The WPC system is powered with vehicle battery and the wireless power charging function is enabled with Ignition

#### *(i)* NOTE

*The WPC would support only those smart phones which are Qi compatible. Please refer the Owner's manual of smart phone /phone setting to check weather support to Qi function.*

#### Location Of Wireless Charger

**Location:** The location of the WPC in vehicle is in the Centre console area as below.



#### Function Of Each Component Of WPC

- Wireless Power Charging (WPC) ECU:** Generates power up to 15W and transfer power through wireless media by magnetic induction.
- Anti-skid Mat:** Hold the position of smart phone placed on it against any jerk and acts a charging contact surface for the smart phone.
- Infotainment unit:** It is a unit which displays the status of wireless power charger with Status symbol and text display. Wireless charger status dis-

played on infotainment in text and symbol form.

### Functions Of WPC System

#### A. Charging function: Charge smart phone

Following all the conditions are applicable to function correctly

- Ignition ON (Engine OFF)
- Engine ON
- Smart phone placed in correct orientation on the antiskid mat as below



Figure1: Phone Placement Area

WPC system detects the presence of phone and starts charging as per the Qi standard protocol. The charging status is updated and displayed on the Infotainment unit.

#### B. Charging Status display function: Displays the real time status of WPC system.

Following all the various conditions that are detected by WPC system and displayed on infotainment Unit.

1. WPC system in standby mode
2. Smart phone charging ON
3. Foreign object on the antiskid mat
4. Smart phone battery is full/Charging completed

#### Conditions To Charge Phone Effectively / Properly

1. Keep the charging pad area / surface clear of any objects (coins, credit cards, smart cards, keys etc.)
2. Place the smart phone on the marked area as shown - for best results place the smart phone at the center of the charging pad / mat.

3. Do not use thicker phone cover or cover with metal parts to avoid charging interruption.
4. Ensure that phone is placed with displayed facing upwards and back cover is touching the pad surface.
5. Turn ON the ignition to start the charging.

### INFORMATION

- The wireless charging function is supported to charge smart phones which are Qi compatible. Certain features may not function as not supported by the smart phone manufacturer and not a malfunction of the wireless charging.
- Wireless charging stops with Ignition OFF.
- Wireless charging stops when the smart phone is not completely in touch with the charging pad surface or not positioned correctly on charging pad.

## DASHBOARD AND FEATURES

---

### Do's And Don't

#### **WARNING**

1. If any metallic object such as coin/keys are located between wireless charging pad and phone back cover, the charging may get disrupted. Also, this may results in heat up of metallic objects.

#### **Dos:**

1. Please ensure that the phone is compatible to the charging standard "Qi".
2. If there is any metallic object between smartphone and wireless charger pad, immediately remove smart phone and metallic object after it has completely cooled down. Once any metallic object is detected on wireless charger post charging it displays its warning message on Infotainment unit, first remove smart phone then remove foreign object from the charging pad and place the smart phone again on charging pad.
3. In case of water/Liquid spillage on charging pad, dry out the pad surface area properly & clean the ECU surface area by removing Anti-skid mat. Do not charge the smart phone until surface is completely dry.
4. The Phone charging status is information by phone and not charger.
5. Wireless charger works on principle of magnetic induction, i.e. it converts electrical energy into magnetic energy to transfer energy from charging pad to phone. Please maintain safe distance from the charger most of the time as it may cause irritation to sensory organs or active implants if implemented in the body. Please consult medical specialist in case implant organ in the body of the user.
6. Place the smart phone on the center of the charging pad for effective charging with best results (refer Figure 1).
7. It is recommended to turn on Engine while charging phone on wireless charger to avoid vehicle battery drain.
8. User shall clean charging pad/mat periodically to avoid dust accumulation.
9. It is recommended to keep Vehicle AC at least 23 Deg Cel with Fan speed above 2 level as cool environment support efficient charging of the phone.
10. It is recommended to keep mobile phone at center of charging pad for effective charging. In case small phone kept at corner do not start charging or Foreign object detection message pop-up, please move phone to center

---

of pad.

11. Always use TATA MOTORS PASSENGER VEHICLE LIMITED approved charging pad for efficient charging.

### Don'ts:

1. Do not use metallic smart phone covers as it would halt the wireless charging function. The wireless charging may not function properly when there is a heavy & thick (more than 1 mm thick) accessory cover on the smart phone.
2. Do not place smart phone up-side down (screen face) on charging pad or do not misalign mobile phone on charging pad in such case smartphone will not charge.
3. During phone charging, the wireless charger and phone may become warm. In this case, charging will stop due to phone's internal protection function. Charging may resume after phone cools down.
4. Please do not put any liquid (e.g. water, cold drink, and sanitizer), dust particles or flammable object on anti-

skid mat.

5. Do not cover the wireless charger with a cloth or other object while charging. It may heat up the device and reduce the charging efficiency.
6. Do not disassemble, modify or remove the wireless charger. Also do not apply force or impact to the wireless charger.

### Information

1. Small noise may be heard when a smart phone which does not support wireless charging or any foreign object is placed on the charging pad. This small sound is due to the vehicle discerning compatibility of the object placed on the charging pad. It does not affect the vehicle performance or the smartphone in any way.
2. For certain cellular phones with their own protection, the wireless charging speed may decrease and the wireless charging may stop.
3. When the interior temperature of the wireless charger rises above a set temperature, the wireless charging will cease / stop to charging function. After the interior temperature drops below set threshold, the wireless charging function will resume.
4. Wireless charging will stop when the vehicle is Ignition OFF.
5. Wireless charging will stop when the smartphone is not in complete contact with the wireless charging pad.
6. When charging certain smart phones, the charging full message on head unit may not display when the smart phone is fully charged. It depends on smart phone manufacturer characteristics/ configurations.
7. Smartphone of some manufacturers may display messages on weak current. This is due to particular characteristic of smartphone and does not imply a malfunction on wireless charger.
8. Smaller smartphone users (ex. iPhone 8) may face intermittent charging issues due to its smaller size. (To avoid this, place the smartphone at center of the charging pad). Small mobile phones may not be able to charge in

## DASHBOARD AND FEATURES

any/ every position as kept on charging pad.

9. The wireless charger may not operate correctly when the vehicle is near a TV tower, electric power plant, gas station, large display, airport, or other facility that generates strong magnetic field radio waves or electrical disturbance / noise.

10. If FOD is message pop-up then after lifting the phone FOD message may disappear or remains till metal object is also removed. This depend of wireless charging support feature of smart phone.

11. When "Place phone properly or Remove metallic object if any on charging pad" then, realign phone at the center.

12. When "Place phone properly Or Remove metallic object if any on charging pad" and phone not charging even after sliding at center then, lift the phone and place it again on charging pad.

13. Some phones have internal calibration because of which it may take 6-10 sec

to initiate charging.

14. If phone, having internal calibration, is placed along with metallic object and then, phone is removed from charging pad then, FOD error message remains on charging pad till metallic object is removed from charging pad.

### WPC ECU In Standby Mode

The infotainment system displays no warning message/ indication in this mode.

This mode represents that the charging function is halted and not functional. The charging function could halt because of below reasons like:


1. Phone is not properly aligned with the charging pad or not positioned correctly on wireless charger pad in standby mode
2. Phone is kept in upside down (screen face) position wireless charger in standby mode
3. Phone is fully charged, and phone does not demand power wireless charger in standby mode



*Stand by Mode on Display*

### Smart Phone Charging ON Mode

When the smart phone is placed correctly and the conditions are favorable to perform the function of wireless charging, the infotainment system shows following messages. After Popup (refer below image), The charging symbol stays ON until the phone is fully charged.



*Charging Mode On - Popup*



Charging Mode On – All Time Display

### Foreign Object Detection Mode

The charging gets interrupted/stopped due to metal object placed on the charging pad. The infotainment head unit displays following message. Check if there are any foreign objects between the smart phone and the charging pad, please clean if so. Smartphone shall be lifted for removing foreign objects and place it back on charging pad.



Foreign Objects

#### NOTE

- *Delay in restarting of mobile charging will be observed if foreign objects are removed without lifting smartphone.*
- *After removing the foreign objects, if smart phone do not resume charging immediately lift the phone and place on charging pad to start the charging.*
- *In case of Foreign objects detection on charging Pad; Lift the phone & remove the foreign object. Place the smart phone again on charging Pad to restart the charging.*

## DASHBOARD AND FEATURES



Foreign Object Detected - Popup



Foreign Object Detection Mode- All time Display

### Smart Phone Battery Is Full/ Charging Completed

The smart phone fully charged status is indicated on the infotainment display screen with following message. This Indication depends on phone profile whether it communicate the battery full charge status to WPC System.



Charging Complete Indication - Popup

#### *NOTE*

*When charging certain smart phones, the charging full message on head unit may not display when the cell phone is fully charged. It depends on smart phone manufacturer characteristics/configurations.*

### WPC System Error Mode

The error in the WPC with fan system may cause the error message to get displayed on the infotainment screen.

Some of errors that can occur while charging which halt/interrupt charging can be covered with this indication are:

- WPC fan internal fault which lead to permanent failure in charger functionality
- WPC Fan stuck/jam is detected
- WPC fan Charging coil failure/damage
- WPC fan temperature sensor failure/damage



System Error Mode - Pop up

 **NOTE**


*If error message is pop up on head unit then stop/ avoid charging the smart phone and visit the nearby service station.*



### STORAGE COMPARTMENT

#### Glove Box

##### Opening and Closing



**To Open**— Pull the lever to open the glove box flap.

**To Close** - Lift glove box flap until it engages.

### Glove Box Illumination




The glove box lamp illuminates when the glove box is opened.

#### NOTE

*Make sure that glove box flap is closed while driving.*

### Stowage Detail




Following items can be stowed in glove box.

1. Owner's manual and other vehicle document,
2. First aid kit, Visiting card, Pen, Receipts etc.


## STOWAGE AREAS

### Cooling Facility (if available)



On selected models cooling facility is provided below driver foldable arm rest. It cools only when the A/C is ON. Close the vent by rotating the knob, whenever cooling is not required.

### Google Holder (if available)



Goggle holder is provided near the roof lamp.

### Utility Pockets on Front Doors




Utility pockets are provided on front doors and it can be used to keep following items.

1. Magazine/ paper
2. Umbrella holder
3. Water bottle

#### *(i)* NOTE

*Remove the water from umbrella and fold it properly before storing it in umbrella holder.*


### Utility Pockets on Rear Doors



Utility pockets are provided on rear doors and it can be used to keep following items.

1. Mobile holder
2. Magazines/books
3. Water bottles etc.

### Utility Pockets on 3<sup>rd</sup> Row



Utility pockets are provided on 3<sup>rd</sup> row. It can be used to keep following items.

1. Mobile holder, Magazines/books
2. Water bottles etc.

### Mobile / Wallet Stowage



Place for keeping wallet / mobile is provided in front of Gear shifter lever.

## STOWAGE AREAS


---

### Cup Holder for Front Passenger



Space for cup holder are provided in center console.

### Stowage for Rear Passenger (if available)



Stowage for rear passenger is provided on rear side of floor console between the front passenger seats. It can be used to keep mobile charger, mobile and small items like wallet, Power bank etc.

### Stowage Below Arm Rest



Stowage below front arm rest with chiller is provided on center console between the front passenger seats. It can be used to keep small items.

### Foldable Arm Rest (if available)



A foldable arm rest has been provided in the rear seat. It also has two cup holders, which can be accessed by opening the cover. When not required, fold the armrest back into the seat.

#### *(i)* NOTE

- Remove all items and cups before folding the cup holders.
- Use cups, containers, bottles of right size and which have lids. The content could otherwise spill.

### Tailgate Compartment



Store the luggage in tailgate compartment. You can keep suitcase bag etc.

Luggage cover is designed only for hiding the luggage compartment.

#### WARNING

- Distribute the items of luggage as evenly as possible.
- Position heavy loads as far forwards as possible and as low down in the trunk as possible.
- Never allow occupants to travel in the luggage compartment.
- Do not place anything on luggage cover as it could obstruct driver's rear view. Also in case of an accident or sudden braking, it could cause an injury to occupants.
- The luggage cover can be lifted.


## STOWAGE AREAS

### Stowage Below Load Floor



Store the suitable luggage below the load floor in tailgate compartment. It can be used to keep small items.

### Hooks-coat Hanger (if available)



Coat hanger is provided for rear passenger near grab handle.

#### **WARNING**

- The coat hook cannot restrain heavy objects or items.
- Do not hang objects on coat hooks which can obstruct the curtain airbag deployment during impact.
- Never hang hard, sharp-edged or fragile objects on the coat hook.

### Front Seat Back Pockets (if available)



Rear pockets are provided behind the front seats for keeping small magazines /Note-book etc.

### AIR DISTRIBUTION

The Climate Control regulates the temperature inside the vehicle and filter the dust particles in cabin based on the user set temperature settings.

The air is distributed through the vents in the passenger compartment as shown below:



## CLIMATE CONTROL

---


### AIR VENTS

#### Centre Vent

Centre air vents are provided on dashboard. Air flow and its direction can be adjusted with the help of knob provided on respective vent.



Centre Air Vents (Front)




Side Air Vents (Front)

#### Side Vent For Rear Passenger (if available)

#### For Second Row Passenger

Side air vents are provided on both side of B pillar for rear passenger.

Air flow and its direction can be adjusted with the help of knob provided on respective vent.



Side Air Vents (Rear on B pillar)

### For Third Row Passenger

Side air vents are provided on both side of C pillar for rear passenger.

Air flow and its direction can be adjusted with the help of knob provided on respective vent.



### HVAC CONTROLS (if available)



- A. Temperature Control
- B. Fresh / Recirculation air mode
- C. Blower Speed Control
- D. AC ON/OFF Switch
- E. Air Distribution Control

### Temperature Control



The temperature control knob allows you to adjust the temperature. The temperature can be increased by rotating the knob towards the red segment (clockwise) and decreased by rotating it towards the blue segment (anti-clockwise).

## CLIMATE CONTROL

---

### Fresh / Recirculation Air Mode

Press the switch to activate / deactivate air recirculation mode.



Press to 'ON' or 'OFF'

### Recirculation Mode

(Indicator light 'ON')

Air in the passenger compartment recirculates. No fresh air enters the compartment.

Always use when:

- Driving on a dusty road or through tunnel.
- On signals or slow traffic to avoid traffic pollution.
- Maximum cooling is required.

### Fresh Air Mode

(Indicator light 'OFF')

Fresh air is drawn into the vehicle.

Always use when:

- Discomfort is felt or windows are fogging up.
- Using or air flow modes during demist / defrost.
- Using normal heating mode.

### Blower Speed Control



This is to turn 'ON' the blower and select desired blower speed.

### AC ON/OFF



Press the switch to activate / deactivate the AC. The indicator lamp in the button will light up when climate control is activated.

#### NOTE

*The AC can be switched 'ON' only if the blower is 'ON' and engine is running.*

When AC is switched 'ON', engine idling RPM increases marginally to adjust the AC compressor load.

When desired temperature at evaporator is achieved Ac compressor will self displace optimum refrigerant flow.

#### NOTE

- Condensation may drip from the underside of the vehicle when it is in cooling mode. Traces of water on the ground are normal and are not a sign of leakage or malfunction.*
- Ventilate the vehicle for a brief period during warm weather. This will speed up the cooling process and the desired vehicle interior temperature will be reached quickly.*
- Never cover the air vents or air intake grilles in the vehicle interior.*
- If the AC is not used for a long period, such as during winter, it may not give the best performance when you start using it again. Operate the AC at least once a month to maintain optimum performance.*
- While starting the vehicle itself after long duration (more than 15 days), following procedure needs to be followed to meet AC performance.*

### Air Distribution Control



This is to select the air distribution pattern as described in the table.

## CLIMATE CONTROL

---

	Directs air through the center and side air vents
	Directs air through the center, side and foot well vents
	Directs air through the foot well air vents
	Directs air through the defroster & foot well vents (Default fresh air mode)
	Directs air through the defroster vents (Default fresh air mode)
	Directs fresh air enters in the compartment

## Functions and Settings


Recommended basic settings of the control elements of air conditioning system for the respective operating modes. These may vary depending on individual requirements and weather conditions.

	Control Knob Position			Button Position	
Functions	Air Flow Direction	Blower Speed	Air Temperature	Fresh / Recirculation air mode	AC ON/OFF
<b>Normal heating</b>		2nd or 3rd	Desired temp	Fresh air mode	Switched OFF
<b>Quick heating</b>		To MAX speed and then 2nd or 3rd	To the extreme right up to the stop	Briefly switch ON to Fresh air mode then Recirculation mode	Switched OFF
<b>Normal Cooling</b>		1st to 3rd	Desired temperature	Recirculation mode	Switched ON
<b>Quick Cooling</b>		To Max speed and then 2nd or 3rd	To the extreme left up to the stop	Recirculation mode	Switched ON
<b>Demisting</b>		2nd or 3rd	Desired temperature	Fresh air mode (Default)	Switched ON (Optional)
<b>Defrosting</b>		To MAX speed	Desired temperature	Fresh air mode (Default)	Switched ON (Optional)

## CLIMATE CONTROL

### FULLY AUTOMATIC TEMPERATURE CONTROL (FATC) (if available)

FATC system controls the inside temperature of the vehicle automatically and provides maximum passenger convenience regardless of outside weather conditions.



1. Rear window demister switch
2. Maximum defrost switch
3. Air distribution (mode) switch
4. Blower speed control down switch
5. Blower speed control up switch

6. Temperature control knob
7. Auto 'ON' selection switch
8. Fresh air / recirculation switch
9. AC compressor 'ON / OFF' switch
10. OFF mode switch

#### Display Unit



FATC display is shown on infotainment display screen.

FATC functions can be controlled using both the FATC control panel and the touch screen display.

Whenever the user presses any switch or turns the rotary knob, then the display unit will show the relevant Climate Information.

Also, when the display is not in climate mode then climate information will be displayed on the all-time display provide on the bottom bar.

### FATC Control

#### Rear Window Demister Switch

This switch operates rear window demister. The system will be deactivated after 15 min of continuous operation.



#### Maximum Defrost Switch

1. This switch directs the main airflow towards windscreens for faster defrosting. (It also overrides any mode selection you may have made).
2. When you turn off the button, the system returns to its default setting.

#### *(i) NOTE*

*For your safety make sure you have a clear view through all the windows before driving.*

#### Air Distribution (Mode) Switch

In AUTO mode, the FATC system will regulate the mode automatically. However, user override is possible with the use of MODE



button to select the desired airflow mode.

Each time you press the MODE button, the display shows the mode selected.

	Directs air through the center and side air vents
	Directs air through the center, side and foot well vents
	Directs air through the foot well air vents
	Directs air through the defroster & foot well vents (Default fresh air mode)
	Directs air through the defroster vents (Default fresh air mode)

### Blower Speed Control Down Switch (Low)

Press the Blower Speed control down button to decrease the blower speed.



### Blower Speed Control Up Switch (High)

Press the Blower Speed control up button to increase the blower



speed.

#### NOTE

*In 'AUTO' mode, the FATC system will regulate the blower speed automatically.*

### Temperature Control Knob



Turning the temperature control knob clockwise increases the temperature of the air. The desired temperature will be increased by steps of 0.5°C. User can select temperature range from 18°C to 30°C. Whereas the anti-clockwise direction decreases the temperature.

When you set the temperature to its lower limit (Lo) or its upper limit (Hi), the system runs at full cooling or heating only. It doesn't regulate the interior temperature.

## CLIMATE CONTROL

### Auto ON Selection Switch



To put the automatic climate control in fully automatic mode:

1. Press the 'AUTO' button.
2. Set the desired temperature by turning temperature control knob. The display will show all the functions during 'AUTO' mode.
3. The system automatically selects the proper mix of conditioned and / or heated air that will, as quickly as possible, raise or lower the interior temperature to your preference.
4. When you set the temperature to its lower limit (Lo) or its upper limit (Hi), the system runs at full cooling or heating only. It does not regulate the interior temperature.

### Semi-automatic Operation

You can manually select various functions of the climate control system when it is in fully automatic mode. All other features remain automatically controlled. Making any manual selection causes the word 'AUTO' in the display to go OFF and overridden setting is displayed. System will remain in semiautomatic mode till 'AUTO' is repressed.

### Fresh Air / Recirculation Switch

1. When the recirculation switch or LED is switched 'ON', air from the vehicle's interior is sent throughout the system.
2. When the recirculation switch is switched 'OFF', air is brought in from outside of the vehicle (fresh mode). Whenever discomfort is felt, switch to fresh air mode.



#### NOTE

*The outside air intakes for the climate control systems are at the base of windscreen. Keep this area clear from leaves and other debris.*

The system should be used with recirculation air mode for faster heat up and cool down, however keeping the system in recirculation mode, particularly with AC OFF, can cause the windows fog up.

**ⓘ NOTE**

*When Reverse gear is selected, air intake may switch to recirculation mode if previously in fresh mode to prevent exhaust fumes from entering in the vehicle.*

**AC ON/OFF Button**

Press the AC compressor ON/OFF button to turn the air conditioning ON or OFF. The AC icon will be activated on the display when the AC will be ON.

**OFF Switch**

Press the OFF button to switch OFF the system. OFF will be displayed on the infotainment screen.

 **⚠ WARNING**

Do not set climate control features while driving.

## CLIMATE CONTROL

### Functions and Settings

Functions	Control Knob Position		Button Position							
	Temperature	Auto	Rear demister	Maximum Defrost	Air Distribution	Blower Down	Blower Up	Fresh/air Recirculation	A/C	OFF Button
Normal heating	Desired Temperature	No Change	No Change	No Change	No Change	Desired Speed	Desired Speed	No Change	No Change	OFF
Quick heating	To the extreme right till temp 'HI'	OFF	No Change	OFF	↓ ↗	NA	Max speed	Fresh	ON	OFF
Normal Cooling	Desired Temperature	No Change	No Change	No Change	No Change	Desired Speed	Desired Speed	No Change	No Change	OFF
Quick Cooling	To the extreme left till temp 'LO'	OFF	No Change	OFF	↗	NA	Max Speed	Recirculation	ON	OFF
Demisting	To the right up to the desired temperature	No Change	ON	No Change	No Change	No Change	No Change	No Change	No Change	No Change

## CLIMATE CONTROL

	Control Knob Position		Button Position							
<b>Defrosting</b>	To the right up to the desired temperature	OFF	No change	ON		NA	Max Speed	Fresh	ON	OFF
<b>Panel OFF</b>	OFF	OFF	No change	OFF	OFF	OFF	OFF	No Change	OFF	ON

## CLIMATE CONTROL

### Quick Cooling

If your vehicle is parked under the sun, you can cool it down fast by following the steps given below:


1. Start the engine.
2. Turn on A/C by pressing the button. Make sure the temperature control is set to maximum cool. In case of FATC set temperature to 'Low' mode.
3. Set the blower to maximum speed.
4. Open windows half, set air direction towards face and fresh air mode.
5. When the interior has cooled down to a more comfortable level, close windows and set the controls as required in normal cooling, with re-circulation mode ON.

### FATC Sensors

HVAC system is fitted with three sensors.

#### Solar Sensor

A solar sensor is on top of the dashboard at the middle of defroster grill.



### Outside Ambient Temperature (OAT) Sensor

It is located under the front bumper grill.

#### *(i) NOTE*

- *Do not cover or spill any liquid on sensors.*
- *Do not cover sensor, this may cause the sensor to malfunction. This may lead to FATC not functioning to desired level.*

### In-car Sensor on Control Panel




### Rear Blower



Rear blower is available on third row trim (side wall). It can be switched 'ON' provided that front AC is switched 'ON'.

It can be switched 'ON/OFF' by rotating knob.



Rear Blower switch

### CABIN AIR PURIFICATION

The Climate Control System fitted with advance filter for cabin air purification.

- Pollen Filter (If available) : The filter takes care of dust particles and other pollutants.
- PM2.5 Combi filter (If available) : This high efficiency filter cleans the PM2.5 micron particles and harmful gases coming from atmosphere pollution and volatile organic compounds

#### *(i)* NOTE

- Replace the Filter as per Maintenance schedule. More frequent filter replacement are required/ recommended in case of vehicle is driven in heavy dusty conditions. If the vehicle is driven in heavy dusty conditions more frequent filter replacement are required. Replace the filter if you find poor ventilation, Cooling or Demisting and poor Air Quality Index (AQI).

## CLIMATE CONTROL

### Air Quality Index : (If available)

- Climate control system fitted with FATC calculates Air Quality Index (AQI) of cabin using PM2.5 AQI Index.
- FATC System in AUTO Mode automatically sets the blower speed and switches to recirculation air mode to improve AQI inside the cabin.
- The calculated AQI is displayed on display unit along with severity index.




#### *(i)* NOTE

- AQI calculation will be effective after 30 seconds after ignition ON and no value will be displayed during this period.

- If the AQI does not improve in some time get the sensor and Cabin filter inspected.

### PM2.5 Dust Sensor : (If available)

It is fitted in side the dashboard near to the brake pedal.



#### *(i)* NOTE

- Vacuum the dust sensor as per the maintenance schedule and no note for cabin filter cleaning or replacement.

### PRE DRIVING CHECKS

#### Make Sure That

- Windshield, windows, mirrors, lights, and reflectors are clean and unobstructed.
- Tools kit, jack & handle, warning triangle, owner's manual, first aid kit and vehicle documents are available and stored at their locations.

#### ⚠ WARNING

Never put any mat on top of the floor carpet near pedal region.

- All doors, engine bonnet and tail gate are securely closed and latched.
- All passengers are properly restrained. All occupants travelling should always wear seat belts or suitable CRS as applicable.
- Objects/luggage are secure properly against slipping or tipping.
- Rear seat is securely latched.
- Sufficient fuel for the trip.

#### Daily Check

- Tyres for abnormal wear, cracks or damage and embedded foreign material such as nails, stones, etc.
- Traces of fluid and oil below vehicle.

#### ⓘ NOTE

*Water dripping from the air conditioning system after use is normal.*

- All lamps, wipers, wiper blades and horn for proper operation.
- All switches, gauges and tell tales are working properly.

#### Adjust

- Seats, head restraints (if available) and steering wheel position.
- All the mirrors properly adjusted.

#### Weekly Check

- Engine oil level
- Coolant level
- Brake fluid level
- Windshield washer fluid level
- Battery electrolyte level
- Fuel level

#### ⓘ NOTE

- Tyre pressure to be measured at cold condition.*
- Check tyre pressure and condition after every 15 days including spare wheel.*

## STARTING AND DRIVING

### DRIVING TIPS

Fuel consumption, engine, transmission, brake and tyre wear are mainly affected by below factors:

- Operating conditions of your vehicle
- Your personal driving style

### Operating Conditions

- Avoid frequent start and stop as these increase fuel consumptions.
- Always make sure that the tyre pressures are correct.
- Do not carry any unnecessary weight.
- Regularly, service your vehicle and adhere to the recommended service maintenance schedule.

### Personal Driving Style

- Do not press the accelerator pedal while starting the engine.
- Do not warm up the engine when the vehicle is stationary.
- Always adapt your driving style to suit the prevailing road, weather conditions, and maintain a safe distance from the vehicle in front. Drive care-

fully.

- Avoid frequent, sudden acceleration and braking.
- Select appropriate gear according to varying speeds and load conditions.

#### ⓘ NOTE

*Do not rest your foot on the clutch pedal while driving.*

- Switch 'OFF' the engine in stationary traffic or at signals.
- Keep an eye on the vehicle's fuel consumption.
- Driving safety systems are merely aids designed to assist driving. You are responsible for the distance to the vehicle in front, for vehicle speed and anticipating braking in good time.

#### ⚠ WARNING

You could lose control of your vehicle if you try to adjust the driver's seat, head restraint, mirror, steering wheel and fasten the seat belt while driving. There is

a risk of an accident.

### Recommended Fuel Economy Speeds (MT only)

Gear	Speed (km/h)
1	15
2	30
3	50
4	70
5	90
6	105

### Good Driving Practices

- Slow down before shifting to a lower gear. This will help avoiding revving of the engine causing damage (for MT).
- Avoid frequent brake application which can cause overheating of brakes.
- Slow down the vehicle speed while travelling in cross winds. This gives much better control over the vehicle.
- Avoid high speed when cornering or turning.
- Press the clutch fully while shifting

---

- gears (for MT).
- Make sure that vehicle is completely stationary before you attempt to shift in reverse gear.
- Drive slowly on wet roads.
- You can get extra braking from the engine by shifting to a lower gear. This can help you to maintain a safe speed and prevent your brakes from overheating specially while going down a hill.

**Tips for Obtaining Better Fuel Efficiency**

- Always maintain the specified tyre pressure during fuel top-ups and also before a long trip. Vehicle running with low tyre pressure will consume more fuel than the one running with specified tyre pressure.
- Keep the vehicle clean. Get rid of the not in use luggage/stuff lying in the boot etc.
- Regularly inspect your vehicle for any leakages, worn out wires, rat bites etc.
- Always follow periodic & regular serv-
- ice schedule of the vehicle.
- Drive smart and smooth in an anticipatory manner. Select driving mode to suit your style.
- Do not accelerate excessively when you are in lower gears (1<sup>st</sup> or 2<sup>nd</sup>). Be gentle on the accelerator when you are in traffic. In lower gear, opening more throttle will shoot the engine RPM keeping the vehicle still at lower speeds which indirectly implies less distance with more fuel.
- Be in the maximum possible higher gear at a given speed. This reduces the engine operating speeds which means the engine is running at lower rpm (Revolutions per Minute) for the same vehicle speed. Lesser the number of engine revolution lesser the fuel burned.
- Avoid harsh braking.
- Maintain healthy driving habits & while decelerating, do coasting in gear and not in neutral or with clutch pedal pressed.
- Consider using the car AC when you really require. Consider using lower blower speeds rather than higher for cooling as at higher blower speeds it consumes more electric power which is ultimately drawn from engine by burning fuel.
- Avoid unnecessary extra electrical loading on the car.
- Stop the engine wisely at traffic signals. Switch 'OFF' the engine at the traffic signal only if the stoppage time is high (typically more than 30 sec).
- While driving on highways, drive with windows closed. The more you open the windows the higher will be the resistance to the vehicle at higher speeds which will reduce the fuel efficiency.
- Do not over speed; follow the speed limits. More the speed, higher the external resistance on the vehicle which will finally result into unnecessary consumption of fuel.

## STARTING AND DRIVING

---

### Running-in Period

The more you look after the engine when it is new, the more satisfied you will be with its performance in the future.

Avoid rapid acceleration and prolonged high speed running of the engine for the first 2,000 km.

Do not exceed the following road speeds during running in period.

Gear	Speed(km/h)
1	15
2	30
3	45
4	60
5	80
6	100

Avoid heavy loads, e.g. driving at full throttle, during this period. Change gears judiciously.

While cruising, brief full-throttle acceleration within the limits of local traffic laws contributes to a good break-in. Wide-opened throttle acceleration can be detri-

mental and should be avoided.


#### NOTE

*Avoid excessive revving up of engine rpm. Do not keep engine at idling for long duration.*

### SEAT ADJUSTMENTS

#### Driver Seat Adjustments (option 1)

Following seat adjustments can be carried out manually.



1. Backrest Angle
2. Seat Height Adjustment (if available)
3. Seat forward / rearward adjustment

#### ⚠ WARNING

Do not adjust the driver's seat while driving. Adjusting the seat while driving could cause the driver to lose control of

the vehicle.

#### 1. Seat Backrest Angle Adjustment

To change the seat back rest angle, lean forward slightly and pull up the lever (1). Adjust seat backrest until it reaches desired comfortable position. Make sure that lever returns to its original position and seat is securely latched.

#### ⓘ NOTE

*Adjust the seat backrest until your arms are slightly angled when holding the steering wheel.*

#### ⓘ NOTE

*Adjust the driver seat position in such a way that the driver will be able to operate the control pedals comfortably.*

#### ⚠ WARNING

Never travel in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision.

#### 2. Seat Height Adjustment (if available)

To raise the seat, pull and continue pumping the lever (2) in the upward direction

until the seat is at the desired height.

To lower the seat, pump the lever downward until the seat is at desired height.

#### 3. Seat Forward / Rearward Adjustment

Lift lever (3) and slide the seat forwards or rearwards. Release lever and make sure that seat is securely latched.

## STARTING AND DRIVING

### Power Seat Adjustments (Option 2)

#### Front seat adjustments:

Following seat adjustments can be carried out automatically.



1. Backrest angle adjustment
2. Seat height adjustment (if equipped)
3. Seat forward / rearward adjustment
4. Seat ventilation (if equipped)

#### **WARNING**

Do not adjust the driver's seat while driving. Adjusting the seat while driving

could cause the driver to lose control of the vehicle.

#### 1. Seat Backrest Angle Adjustment

To change the seat back rest angle, lean forward slightly and operate the button slightly(1) as per arrow mark either forward or rearward as required. Adjust seat backrest until it reaches desired comfortable position and then release the button.

#### 2. Seat Height Adjustment (if Equipped)

To raise the seat, pull the button slightly (2) in the upward direction as per arrow mark, until the seat is at the desired height. To lower the seat, push the button downward until the seat is at desired height.

#### **NOTE**

*Adjust the driver seat position in such a way that the driver will be able to operate the control pedals conformably.*

*Do not apply over force on power operated buttons as it may damage them. Button operates with slight finger force as they are electronically controlled.*

*Avoid unnecessary operation of power seat adjustment buttons as it consumes power from vehicle battery. Do not operate more than one operation button simultaneously.*

#### 3. Seat Forward / Rearward

To move seat forward push the button(3) slightly forward as per the arrow mark, to move seat rearward pull the button in rearward direction make sure that seat is securely latched.

#### 4. Seat Ventilation (for Driver And Co-driver)

To start ventilation, press button (4) once. It's has 3 ventilation adjustment in decreasing order and LED glows for each press. To Stop the ventilation long press button (4) for few seconds.

Default setting is highest speed on first press.



The ventilated seat by default is set to OFF whenever the ENGINE START/STOP button is turned ON.

### NOTE

*Do not apply excessive force on ventilation button as it may get damaged. Button operates with slight finger force as they are electronically controlled.*

### To protect ventilated seats-

- Use the air ventilation seat ONLY when the vehicle HVAC system is ON.
- Never use alcohol based liquids to clean the Seats as it may damage the leatherette material.
- Avoid spillage of liquids on the ventilated seats surface this may lead to blockage of air path/ holes ventilated seat system and may not function properly.
- Do not add seat covers, as it will not allow ventilated seats to function properly.
- Do not keep plastic covers of seat as it

is , as it will not allow ventilated seats to function properly.


### Lumbar Support (if available)



Continuous (Multiple adjusting position) lumbar support is provided on driver and front passenger seat to give you comfort while driving. It is adjusted by the lever provided on the side of the seat backrest.

### Captain Seat Adjustment 2nd Row (Option 3)

Following seat adjustments can be carried out manually.



1. Backrest angle
2. Seat forward / rearward adjustment lever
3. Seat ventilation (if equipped)

#### 1. Seat Backrest Angle Adjustment

To change the seat back rest angle, lean forward slightly and pull up the lever (1). Adjust seat backrest until it reaches de-

## STARTING AND DRIVING

sired comfortable position. Make sure that lever returns to its original position and seat is securely latched.

### 2. Seat Forward / Rearward

Lift lever (2) and slide the seat forwards or rearwards. Release lever and make sure that seat is securely latched.

### 3. Seat Ventilation

To start ventilation, press button (3) once. It's has 3 ventilation adjustment in decreasing order and LED glows for each press. To Stop the ventilation long press button (3) for Few seconds.

Default setting is highest speed on first press.



#### To protect ventilated seats-

- Use the air ventilation seat ONLY when the vehicle HVAC system is on.
- Never use a liquids like alcohol, high viscosity oils or other to spill on ventilated seats.

- Avoid spillage of liquids on the ventilated seats surface this may lead to blockage of ventilated seat system and may not function properly.
- Do not add seat covers, as it will not allow ventilated seats to function properly.
- Do not keep plastic covers of seat as it is , as it will not allow ventilated seats to function properly.

#### *NOTE*

*Do not apply excessive force on ventilation button as it may get damaged. Button operates with slight finger force as they are electronically controlled.*

**The ventilated seat by default is set to OFF whenever the ENGINE START/STOP button is turned on.**

#### Arm Rest Adjustment

A foldable arm rest is available in the captain seat. When not required, fold the armrest back into the seat.

### Captain Seat Child Seat Installation


Captain seat contains Isofix with Top-Tether.

It is recommended to install child seat in armrest Non-use position.



### Captain Seat Third Row Entry


Entry to third row seat to be done through gang way space (between two captain seats).



### Adjustment for Co-driver Seat

To improve the Second Row occupant legroom (Space), Occupant Can adjust the Co-driver seat using the lever (1).


Operate Lever (1) in forward direction & Push the seat forward as shown by arrow (2) until seat is at desired comfortable position.



### Adjustable Head Restraint

#### Front Seat

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the risk of injury to the head and neck in the event of an accident or similar situation.



#### WARNING

Do not drive the vehicle without the seat head restraints. Head restraints are intended to help reduce injuries during an accident.

## STARTING AND DRIVING

### Rear Seats Adjustment (60 - 40%)

Following seat adjustments can be carried out manually.



1. Backrest Angle
2. Seat forward / rearward adjustment lever
3. Seat Armrest Adjustment

### Seat Backrest Angle Adjustment

To change the seat back rest angle, lean forward slightly and pull backrest release knob (1). Adjust seat backrest until it reaches desired comfortable position. Make sure that lever returns to its original position and seat is securely latched.

### Seat Forward / Rearward Adjustment

- Use the seat sliding feature of 2nd row seat to improve the comfort and convenience.
- Lift lever (2) and slide the seat forward or rearward. Release lever and make sure that seat is securely latched.

### Seat Armrest Adjustment

A foldable arm rest (3) is available in the 60% seat. When not required, fold the armrest back into the seat.

#### *(i)* NOTE

- Remove all items and cups before folding the cup holders.
- Use cups, containers, bottles of right size and which have lids.

- The content could otherwise spill.

### Child Seat Installation

60-40% seat contains Isofix with Top-Tether.

It is recommended to install child seat in armrest Non-use position.






### Second Row Seat Folding (60 - 40% Split Seat)

You can increase the luggage capacity by folding the respective rear seats as required.

To fold the seat:




- Press the backrest release knob to fold the backrest seat forward.



## STARTING AND DRIVING

- Fold the backrest seat forward. Move the driver and front passenger seat forward if necessary.
- Press the backrest release knob to fold the backrest seat forward.



- Fold the backrest seat forward. Move the driver and front passenger seat forward if necessary.



- Follow the same procedure for other rear seat.


### *(i)* NOTE

- *Ensure that 'foldable arm rest' is close before seat folding.*
- *Fold both seats if required.*

### Rear Seat Folding (Complete Seat 100%)

To fold the seat:

- Simultaneously, press the backrest release knobs provided on both side.



- Fold the backrest seat forward. Move the driver and front passenger seat forward if necessary.



#### ⚠ WARNING

- You should always engage the rear seat back rest if you do not need the through loading feature.
- If the rear bench seat and seat backrest are not engaged they could fold forwards, e.g. when braking suddenly or in the event of an accident.


## STARTING AND DRIVING

- The vehicle occupant would thereby be pushed into the seat belt by the rear bench seat or by the seat backrest. The seat belt can no longer offer the intended level of protection and could even cause injuries.
- Objects or loads in the trunk cannot be restrained by the seat backrest. There is an increased risk of injury.
- Before every trip, make sure that the seat backrests and the rear bench seat/rear seat are engaged and securely latched.

### Third Row Entry

#### To access to Third row seat

- The second row seat are designed as foldable type to enable the passenger to get entry into the Third row.
- To get access to third row seats, first fold & tumble the 40% second row seat using the seat folding release knob.
- If required assist the seat for tumble operation.
- To return the seat back to original position once the passenger enters the third row, unfold the tumbled seat, operate the shoulder lever and lift the backrest to the upright position till it locks into its original position.




#### ⚠ WARNING

- *While folding the Second row seat, after getting inside the Third row seat, never keep your feet on the seat locking brackets.*
- *Never drive the vehicle with 40% seat in tumble condition.*





### Third Row Seat Folding


- Headrest to be in full down condition to fold the seat back.
- Adjust the second row seat if required.
- Pull the plastic lever & after click sound of unlatching, hand push in the seat back to lean it forward. Both the seats can be independently folded to create extra luggage space accordingly.



## STARTING AND DRIVING



- Pull only the straps (2) to lift the seat back to original position and not the plastic lever.



### *(i)* NOTE

*Lever to be only pulled for unlatching.  
it cannot be used simultaneously for  
pull and pushing the seat as well.*

### WARNING

- You should always engage the rear seat back rest unless you need extra luggage space.
- If the rear seat & seat backrest are not latched properly, they could fold forward during hard braking or in the event of collision.

### REAR VIEW MIRRORS

#### Inside Rear View Mirror (IRVM) (if available)

To adjust the mirror move the mirror up, move down or sideways to obtain the best rear view.

When driving at night, set the selector tab to select anti-glare mode (if available) to reduce glare from the headlights of vehicles behind you.



#### NOTE

*Use antiglare position only when necessary, as it reduces rear view clarity.*

#### Automatic Dimming IRVM (if available)



1. Photocell Sensors
2. ON/OFF button

Automatic dimming rear view mirror automatically controls the glare from the headlights of the car behind you in night time or low light driving conditions. Press ON/OFF

button to turn ON the automatic dimming function.

The LED indicator on the IRVM shows the active status of auto dimming function. The auto dimming IRVM is defaults to the ON position whenever the ignition switch is turned ON and it is switched OFF whenever reverse gear is engaged.

#### NOTE

*For proper operation, keep the photocell sensors clean and do not cover the area between the IRVM and the windshield.*

### Outer Rear View Mirrors (ORVM)

You can adjust the outer rear view mirrors manually by joy stick or remotely by knob. Adjust the outside rear view mirrors to desired position.

#### NOTE

*Objects visible in mirror are actually closer than they appear. Always make sure of the actual distance from the road users traveling behind by glancing*

## STARTING AND DRIVING


over your shoulder.

### Motorized Outer Rear View Mirrors (if available)

The switch to adjust the motorized mirrors is located on the driver's door. You can adjust the mirrors when the ignition switch is in the "ACC" or "ON" position.

#### Mirror Folding

To fold / unfold the ORVMs, keep the Selector switch in center position (i.e. neither 'L' nor 'R' position) and then toggle down.




#### To Adjust the Mirrors

1. Move the mirror selection switch to L (for left side) and R (for right side) to select the mirror you wish to adjust.
2. Use the 4 positions of the knob to adjust the rear view mirrors to required position.




### Rear View Mirrors with Joy Stick Knob (if available)



You can adjust the outer rear view mirrors manually by joy stick knob located in the driver and front passenger door panel.

If required mirrors are folded manually.

### SUN VISORS



1. Mirror Flap
2. Vanity Mirror
3. Light for Vanity Mirror

### Mirror Flap (if available)

The sun visors can be pulled down to block the glare coming through the windshield.

To block the glare from side windows:

Pull down the sun visor and release it from retainer. Swing the sun visor to the side.

### Vanity Mirror (if available)

Vanity mirror is provided on the back of the front passenger side sun visor.

### Light for Vanity Mirror (if available)

It is provided beside the vanity mirror. Light glows 'ON' as soon as flap of vanity mirror is open.

### STEERING WHEEL ADJUSTMENT (if available)



You can adjust the steering wheel position to suit your convenience.

The release lever is located under the steering column.

### To Adjust the Steering Wheel

1. Adjust the seat to a comfortable position.
2. Pull down release lever completely to unlock the steering column.
3. Adjust the steering wheel to the desired position by moving steering

## STARTING AND DRIVING

wheel in axial and radial direction (telescopic & tilt).



4. Push release lever up completely to lock the steering column.
5. Make sure that steering wheel is securely lock by checking up and down direction.

### ① NOTE

*When adjusting the steering wheel, make sure that:*

- You can operate control pedals without any obstacles.
- You can see all the displays in the instrument cluster clearly.

### ⚠ WARNING

- Before starting off, make sure that the steering wheel position is locked.
- Never unlock or adjust the steering wheel while the vehicle is in motion.

## STEERING LOCK AND IGNITION SWITCH (if available)



The ignition switch has the following four positions:

**LOCK** - This is the normal parking position. Key from lock can be removed in this position only.

“LOCK” position prevents normal use of the steering wheel after the key is removed.

To release the steering lock, insert the key and turn it clockwise to one of the other positions.

**ACC** - Accessories such as the infotainment system can be operated, but the engine remains 'OFF'. Steering gets unlocked.

**ON** - This is the normal operating position. All electrical systems are 'ON'.

**START** - Turn the key further clockwise to the START position, (spring loaded) to start the engine. As soon as the engine starts, release the ignition key, which returns to ON position. While cranking, all accessories will be momentarily 'OFF'.

### **Illuminated Key Ring (if available)**

When the vehicle is unlocked, the illuminated key ring glows up. This helps to locate ignition switch in the dark.

#### **NOTE**

*The engine can only be started when the gearshift lever is in "N" position with the clutch pedal firmly pressed.*

#### **NOTE**

*For Auto Transmission vehicle,*

*ACC: Key rotation from ACC to lock position only happen when gear lever is in Parking position.*

## **STARTING AND STOPPING (without PEPS)**

### **Manual Transmission (MT)**

#### **Starting the Engine**

Make sure that parking brake is engaged and vehicle is in neutral gear.

Press the clutch pedal fully and crank the engine. Do not press the accelerator pedal while starting the engine.

#### **NOTE**

*The Starter protection system fitted in this vehicle does not allow you to crank the engine until you fully press the*



*clutch pedal.*

Release the key as soon as the engine starts. Repeat if engine does not start.

#### **NOTE**

*The Starter protection system switches off the starter when it is continuously cranked for more than 10 secs. In such a case, get the key back to 'OFF' posi*

## STARTING AND DRIVING

*tion & wait for 30 secs.*

### ⚠ WARNING

The engine emits poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore, never leave the engine running in enclosed spaces without sufficient ventilation.

### ⓘ NOTE

*After starting, run the engine in idle speed for at least 30 seconds. Do not press accelerated pedal while starting the engine to avoid damage to turbocharger.*

### Starting Off

To start off, press the clutch pedal fully and shift into first gear.

After releasing the parking brake, gradually release the clutch and slowly press the accelerator.

### ⓘ NOTE

*When shifting or starting off, do not race the engine. Racing the engine can shorten engine life and affect smooth shifting.*

### Stopping the Engine

Turn the key to 'ACC' position to switch off the engine. Before switching off the engine, run the engine in idle condition for at least 30 seconds and then switch off. This will allow the engine oil to lubricate the turbocharger, till its speed is fully reduced and also allow the unit to cool down.

### ⚠ WARNING

- A quick burst on the accelerator before turning off the engine serves no practical purpose, it wastes fuel and can damage turbocharger.
- Do not switch off the engine when it is running at high speed. This will lead to premature turbocharger bearing wear.

### Gear Shifting and Driving



The gearshift pattern is as shown on the gear lever knob. Gear shifting should always be done with clutch pedal pressed.

### ⓘ NOTE

- Gear recommendation is displayed when the clutch pedal is in fully released position.
- If "F" is displayed in DIS of instrument cluster, it means 'Fault' condition. Contact a TATA MOTORS Authorized Service Centre.

### ⓘ NOTE

- Press the clutch fully when gear shifting. The reverse gear should be engaged only when the vehicle is stationary. Wait for 5 seconds after declutching to ensure smooth engagement of the reverse gear.
- Do not press clutch pedal while driving the vehicle or when stationary on a slope.
- When vehicle is in ACC/IGN/RUN mode and user does any door state transition including tailgate and if PEPS does not detect smart key inside the vehicle when last door in

cluding tailgate is closed, then audio warning chime comes ON.

### Reverse Gear



For engaging reverse gear, lift the latch and keeping latch lifted, shift to reverse position.

### ⚠ WARNING

- Never run the vehicle out of gear and coast down a hill. This is extremely hazardous. Always run the vehicle in gear.
- Slow down before shifting to a lower gear. This will help avoid overrevving the engine, which can cause damage.
- Ensure the vehicle is completely stopped before putting into reverse gear. It may cause damage to the transmission.

## STARTING AND DRIVING

### Automatic Transmission (if available)



The Automatic transmission has 6 forward and one reverse gear. The individual gears are selected automatically, depending on position of gear shift lever.

#### Starting Off

To start off, switch ON ignition switch and crank the engine, depress the brake pedal fully and release the parking brake. Press the shift lock button on the knob of gear selector lever and move the lever from Parking (P) mode to Drive (D) mode.

#### Park (P)

Use Park (P) position when starting the engine or parking the vehicle. Apply the parking brake whenever the vehicle is to be parked.



The selector lever must be engaged in Park (P) position only when the vehicle is stationary. DO not engage Parking Position (P) in running condition.

If engaged while the vehicle is in motion it may severely damage the transmission.

Before leaving the driver's seat, always make sure the shift lever is in the P (Park) position; then apply parking brake fully and shut the engine off. If this is not followed, Unexpected and sudden vehicle movement can occur.

#### Reverse (R)

This position puts the transmission in reverse gear when engaged in stationary condition with brake pedal fully pressed.



The selector shall never be moved into re-

verse while driving forward.

#### Neutral (N)

The transmission is in Neutral position.



It enables the engine to start and operate without driving the vehicle.

#### Drive Mode (D)


This position is for normal driving conditions for maximum efficiency and fuel economy. It should be used as often as possible.



To move the selector to D mode; press the Shift lock button in the handle of the selector lever and at the same time press the brake pedal fully.

#### Manual/sport Mode (M/S)

This display shows vehicle is in Manual/Sport mode.



This position allows the driver to switch to activate Manual mode to select gears like a manual gearbox.

Pressing the shift lever towards left side while in Drive mode will put the transmission in Manual mode.

The gear selector moves freely between the Manual (M) and Drive (D) positions. As soon as shifter is moved forward or backward, the Manual (M) mode is activated.

It is possible to shift from D mode to Manual mode and vice versa at any time during driving.

To return back to Manual mode if it has been selected; move the selector lever to Drive mode (by tapping the lever towards right) and engage it again to M mode.

If Manual mode is selected, 1st gear must be used for moving off from stationary condition.

In sports mode, only the 6 forward gears can be selected. To reverse or park the vehicle, move the shift lever to the R (Reverse) or P (Park) mode as required.

### **‘+’ For Upshifting in Manual mode**

Push the gearshift lever to the “+” direction and release it. Every time the lever is operated, upshifting takes one step at

a time in the order of 1<sup>st</sup> > 2<sup>nd</sup> > 3<sup>rd</sup> > 4<sup>th</sup> > 5<sup>th</sup> > 6<sup>th</sup> gear.

### **‘-’ For Downshifting in Manual mode**

Pull the gearshift lever to the “-” direction and release it. Every time the lever is operated, downshifting takes place in the order 6<sup>th</sup> > 5<sup>th</sup> > 4<sup>th</sup> > 3<sup>rd</sup> > 2<sup>nd</sup> > 1<sup>st</sup> gear.

In Manual/sports mode, downshifts are made automatically when the vehicle slows down. 1<sup>st</sup> gear is automatically selected when the vehicle stops.

In Manual/sports mode, when the engine rpm approaches the intended limits, upshift will be made automatically by varying the shift points.

### **(i) NOTE**

Driver Control  
Shift denied

- *Transmission Control Unit may disallow incorrect manual shift command by user and a message ‘Driver Control Shift denied’ is displayed on Instrument Cluster.*

- *In order to protect the engine, the transmission will automatically upshift to prevent engine over-revving OR downshift to prevent engine stalling at certain specified engine rpm limits.*
- *The first few shifts on a new vehicle, maybe somewhat abrupt after TCU replacement or software updation. This is normal condition. Shifting sequence will get adjusted after few shift cycle by TCU (Transmission Control Unit).*

### **Shift Lever - Manually Unlock Process**



Fig 1

## STARTING AND DRIVING

---




Fig 2

When vehicle is in ON condition and shift lever is locked/cannot moved from P (park) mode to other mode with the brake pedal depressed, below steps to be followed:

1. Apply the parking brake first.
2. Carefully squeeze & remove the bellow (1) by pulling it in upward direction as shown in area by arrows (shown in fig.1)
3. Press & hold the release button (2) provided on shifter housing till you move the shift lever from P (park) mode to other mode by simultaneously pressing the knob button (3) (Shown in fig.2).

4. Carefully insert the bellow lugs (4) & snap fit in console cutout (5) highlighted as dotted area (shown in fig.2).
5. Ensure the system is inspected by authorized dealer or service partner.

## Automatic Gear Shifter Lever Movement and Conditions

Lever Position Movement	Driver Intervention For Shift		
	Brake Pedal	Driver Shift	
	P -> R		
	R -> N	Not required	Not required
	N -> D	Not required	
	D -> M/S	Not required	Not required
	M/S -> D	Not required	Not required

## STARTING AND DRIVING

Lever Position Movement		Driver Intervention For Shift	
		Brake Pedal	Driver Shift
	D->>N	Not required	Not required
	N->>R	Not required	
	R->>P	Not required	



Brake Pedal Pressed



Shifter Lever Knob Pressed

### NOTE

- *Before engaging in any mode (P-R-N-D), Apply brake first then knob button to be pressed for safety reason.*
- *Before selecting the 'M' mode (manual mode), Ensure shift lever is placed in D mode first. Then engage M mode smoothly & vice versa. This sequence to be followed to ensure safety of system.*

### WARNING

- To avoid damage of transmission, do not accelerate the engine in R (Reverse) or any forward gear positions with the brakes ON.
- When stopped on an incline roads, Use the service brake or the parking brake, do not hold the vehicle stationary with engine power.
- Do not shift from N (Neutral) or P (Park) into D (Drive), or R (Reverse) when the engine is above idle rpm.
- Always shift the gears inline in sequence of (P-R-N-D). Do not try to shifts abruptly.

## STARTING AND DRIVING

### Shift Lock System

For your safety, the automatic transmission has a shift lock system which prevents shifting the transmission from P (Park) into R (Reverse) unless the brake pedal is depressed.

To shift the transmission from P (Park) into R (Reverse):

1. Press and hold the brake pedal.
2. Start the engine or turn the ignition switch to the ON position.
3. Move the shift lever to R mode.

#### NOTE

*If the brake pedal is repeatedly depressed and released with the shift lever in the P (Park) position, noise may be heard. This is a normal condition.*

### Key Interlock System for AT

1. For Mechanical Lockset

Shift the GSL to P position and then switch OFF Ignition and take out the key.

2. For PEPS

Shift GSL to P position and then only Ignition will be switched else vehicle will move to accessory on till GSL is moved to P position.

#### NOTE

*If the Brake pedal is repeatedly depressed and released slowly with the shift Lever in R (Reverse) position, noise may be heard. This is a normal condition.*

#### WARNING

Always depress the brake pedal fully, before and while shifting out of the P (Park) mode into another position. This is to avoid unintended motion of the vehicle which could injure the passengers inside or around the vehicle.

#### NOTE

*Good Driving Practices (AT)*

- *Never move the shift lever from P (Park) or N (Neutral) to any other position with the accelerator pedal*

depressed.

- *Never move the shift lever into P (Park) when the vehicle is in motion.*
- *Be ensure the vehicle is completely stopped before shifting into R (Reverse) or D (Drive).*
- *Always use the parking brake. Do not depend on placing the transmission in P (Park) to keep the vehicle from moving.*
- *Optimum vehicle performance and fuel economy is obtained by smoothly depressing and re-leasing the accelerator pedal.*

## STARTING AND STOPPING (PEPS) (if available)

### Engine Passive Start/stop



Start/Stop switch is provided on the dashboard towards the right side of steering wheel.

### Start / Stop Switch

A Start Stop Switch (SSSW) or Push to Start Button is a main component of Passive (Engine) Start and Stop system. It is used to control ACC, IGN out-puts as well as to start and stop the engine.

#### (i) NOTE

- If Smart key is inside the vehicle and on pressing start stop switch, if start stop switch green LED blink for 10 sec. duration then rotate steering wheel and simultaneously press start stop switch again.
- If smart key is inside the vehicle and on pressing start stop switch, if start stop switch green LED blinks more than 10 sec. duration then contact authorized TATA MOTORS dealer.
- If ESCL (Electronic Steering Column Lock) is not unlocked properly, then vehicle doesn't go into ACC mode.

below front cup holder).



### Emergency Start

If vehicle engine is switched from ON to OFF and Start Stop button is pressed with clutch press within 5 sec, Engine gets cranked.

#### (i) NOTE

If ESCL (Electronic Steering Column Lock) is not unlocked properly, then Engine will not get cranked.

## STARTING AND DRIVING

---

### ENGINE PASSIVE START - CONDITIONS

#### Single Press Start

1. Bring the smart key with you and sit in the driver seat.
2. Press the clutch pedal and then press the start-stop switch.
3. Green colour LED on start-stop switch will turn ON.
4. Once engine starts successfully, green colour LED on start-stop switch will remain ON.

#### Two Step Start

##### a) Step 1

1. Bring the smart key with you and sit in the driver seat.
2. Press the start-stop switch without pressing clutch pedal.
3. Amber colour LED on start-stop switch turns ON.
4. Engine will remain OFF and all electrical equipment and infotainment system can be used. Steering is unlocked.

##### b) Step 2

1. Press the clutch pedal and then press start-stop switch to start the engine.
2. Green colour LED on start-stop switch will turn ON.
3. Once engine start successfully, green colour LED on start-stop switch will remain ON.

#### Three Step Start

##### a) Step 1

1. Bring the smart key with you and sit in the driver seat.
2. Press the start-stop switch without pressing clutch pedal.
3. Amber colour LED on start-stop switch will turn ON.
4. Limited display on instrument cluster will be ON and steering will be unlocked. Engine remain OFF.

##### b) Step 2

1. Press the start-stop switch without pressing clutch pedal again.
2. Green colour LED on start-stop switch will turn ON.

3. Engine will remain OFF and all electrical equipment and infotainment system can be used.

##### c) Step 3

1. Press the clutch pedal and then press start-stop switch to start the engine.
2. Green colour LED on start-stop switch will turn ON.
3. Once engine started successfully, green colour LED on start-stop switch will remain ON.

### ENGINE PASSIVE STOP - CONDITIONS

#### Passive Stop / Off - Single Press Stop

- IGN is ON and engine is running.
- Customer presses start-stop switch with clutch pedal.
- ACC and IGN relay turns OFF.
- LED on start-stop switch turns OFF.

#### Emergency Stop / Off - Single Long Press Stop

- IGN is ON and engine is running.
- Vehicle is in running condition i.e. wheel rpm >10 RPM or wheel sensor faulty.
- Customer does long press of start-stop switch i.e. pressed for more than 3 seconds.
- IGN relay turns OFF, ACC relay remains ON.
- Amber colour LED on start-stop switch turns ON.

#### WARNING

When vehicle is in OFF mode ( ACC, IGN and Crank OFF) and user tries to lock the vehicle from outside by pressing any door handle switch and if PEPS detect smart key left inside the vehicle, then audio warning / chime comes ON.

### MANUAL TRANSMISSION (MT)

#### Starting the Engine

Make sure that parking brake is engaged and vehicle is in neutral gear.

Press the clutch pedal fully and crank the engine. Do not press the accelerator pedal when starting the engine.

#### NOTE

*The Starter protection system fitted in this vehicle does not allow you to crank the engine until you fully press the clutch pedal.*



Release the key as soon as the engine starts. Repeat if engine does not start.

#### NOTE

*The Starter protection system switches off the starter when it is continuously cranked for more than 10 secs. In such a case, get the key back to 'OFF' position & wait for 30 secs.*

## STARTING AND DRIVING

---

### ⚠ WARNING

The engine emits poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore, never leave the engine running in enclosed spaces without sufficient ventilation.

### ⓘ NOTE

- After starting, run the engine in idle speed for at least 30 seconds. Do not press accelerated pedal while starting the engine to avoid damage to turbocharger.*
- When vehicle is in ACC/IGN/RUN mode and user does any door state transition including tailgate and if PEPS does not detect smart key inside the vehicle when last door including tailgate is closed, then audio warning chime comes ON.*

### Stopping the Engine

Press the start stop switch to switch off the engine. Before switching off the engine, run the engine in idle condition for at least 30 seconds and then switch off. This will allow the engine oil to lubricate the turbocharger, till its speed is fully reduced and also allow the unit to cool down.

### ⚠ WARNING

- A quick burst on the accelerator before turning off the engine serves no practical purpose, it wastes fuel and can damage turbocharger.*
- Do not switch off the engine when it is running at high speed. This will lead to premature turbocharger bearing wear.*

### Starting Off

To start off, press the clutch pedal fully and shift into first gear.

After releasing the parking brake, gradually release the clutch and slowly press the accelerator.

### ⓘ NOTE

*When shifting or starting off, do not race the engine. Racing the engine can shorten engine life and affect smooth shifting.*

### Gear Shifting And Driving



The gearshift pattern is as shown on the gear lever knob. Gear shifting should always be done with clutch pedal pressed.

### Reverse Gear



For engaging reverse gear, lift the latch and by keeping latch lifted, shift to reverse position.

#### *(i)* NOTE

- *Gear recommendation is displayed when the clutch pedal is in fully released position.*
- *If "F" is displayed in DIS of instrument cluster, it means 'Fault' condition. Contact the TATA MOTORS Authorized Service Centre.*

- *Press the clutch fully while shifting the gear. The reverse gear should be engaged only when the vehicle is stationary. Wait for 5 seconds after declutching to ensure smooth engagement of the reverse gear.*
- *Do not press clutch pedal while driving the vehicle or when stationary on a slope.*

#### WARNING

- *Do not switch off the ignition while driving.*
- *If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.*

## STARTING AND DRIVING

---

### ⓘ NOTE

*You may notice a noise from transmission under certain circumstances. This noise is normal and is not an indication of a problem with your clutch or transmission. This noise may be noticed when vehicle is idling in NEUTRAL condition with the clutch engaged (clutch pedal released) or when the transmission is warm. It may also be heard while driving.*

### ⓘ NOTE

- Your vehicle is equipped with Dual Mass Flywheel (DMF), which plays important role in providing refined powertrain / driveline experience.
- Driving at very low engine speed is likely to stall the engine, especially when driven without any accelerator pedal inputs.

### Recommended Driving Precautions:

- Shift to lower gear as per gearshift indicator (GSI) on cluster.
- To start-off (marching/ drive away), always engage in first gear.
- While down shifting (from 3<sup>rd</sup> to 2<sup>nd</sup> gear) at low engine RPM's (below 1000 rpm) press accelerator pedal to provide required rpm.

## DRIVING

### Climbing Sharp Gradients on Loose Surfaces

Start off smoothly in a suitable gear. Accelerate smoothly so that there is no loss of traction by over-revving of the engine.

Choose a slope as smooth as possible and select the appropriate gear so that gear changing in the middle of the climb is not required.

Changing gears in the middle of the climb can cause loss of momentum and engine stalling. Shifting to lower gear has to be done cautiously to avoid loss of traction.

Under no conditions should the vehicle be moved diagonally across a hill. The danger is in loss of traction and sideways slip-page, possibly resulting in toppling over. If unavoidable, choose as mild an angle as possible and keep the vehicle moving.

If the wheels start to slip within few feet of the end of the climb, motion can be maintained by swinging the steered wheels left and right, thereby providing increased grip.

If the vehicle stalls or losses headway

while climbing a steep hill, make a quick shift to reverse and allow the vehicle to move back with the control of engine compression.

### Descending Sharp Gradients

Depending on the severity of the gradient, shift into appropriate gear. Use engine braking judiciously without over-revving the engine.

Brake application under such situations should be done very.

#### ⚠ WARNING

When descending on sharp gradients, NEVER turn the ignition key to the 'OFF' position. Emission control system damage may result.

### STOPPING THE VEHICLE

Turn the key to 'ACC' position to switch off the engine. Before switching off the engine, run the engine in idle condition for at least 30 seconds and then switch off. This will allow the engine oil to lubricate the turbocharger, till its speed is fully reduced and also allow the unit to cool down.

#### ⚠ WARNING

A quick burst on the accelerator before turning off the engine serves absolutely no practical purpose, it wastes fuel and can damage turbocharger.

#### ⚠ WARNING

Do not switch the engine off when it is running at high speed. This will lead to premature turbocharger bearing wear.

### BRAKING

Your vehicle has power assisted brakes.

The distance needed to bring the vehicle to a halt increases with the speed of the vehicle. Start applying brake anticipating the distance and slow down gradually.

#### ⚠ WARNING

- Never use the brake pedal as a footrest.
- If you rest your foot on the brake pedal while driving, the braking system can overheat. This increases the stopping distance and can even cause the braking system to fail. There is a risk of an accident.
- Never press the brake pedal and the accelerator pedal at the same time.

If you have driven for a long time in heavy rain without braking, there may be a delayed reaction from the brakes when braking for the first time. This may also occur after the vehicle has been washed.

Brake performance may become poor and

## STARTING AND DRIVING

unpredictable if brakes are wet.

After driving through water or washing the underside of the vehicle, test the brakes while driving at a slow speed to see if they have maintained their normal effectiveness. If the brakes are less effective than normal, dry them by repeatedly applying the brakes while driving slowly until the brakes have regained their normal effectiveness.

### Braking on Downhill Gradients

On long and steep gradients, you must reduce the load on the brakes by shifting early to a lower gear. This allows you to take advantage of the engine braking effect and helps avoid overheating and excessive wear of the brakes.

#### ⚠ WARNING

- Do not shift to lower gear on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip.

- There is an increased danger of skidding and accidents.

## PARKING BRAKE


### Mechanical Parking Brake

Mechanical parking brake acting on the rear wheels is provided on the vehicle.



Parking Brake

### Parking Brake Applied




To apply the parking brake, hold the lever as shown in above figure with knuckle facing towards vehicle front and pull the lever.

#### ⚠ WARNING

Do not press the button, while applying parking brake.

### Parking Brake Released



To release parking brake, hold the lever and pull the lever up slightly, press the knob with the help of middle and ring finger as shown in figure and release the parking brake.

#### ⓘ NOTE

*Apply the parking brake properly before leaving the vehicle and release it before moving the vehicle.*

Mechanical parking brake acting only on the rear wheels is provided on the vehicle.

To apply the parking brake, pull the lever up fully. The parking brakes tell-tale illuminates on the instrument cluster. To release it, pull the lever up slightly, press the release knob and push the lever down. Parking brakes tell-tale on the instrument cluster will turn 'OFF' when the lever is fully released.

### Vehicle Parking

- Park the vehicle in a safe place.
- Apply the parking brake.
- Engage the gear shift lever in Park (P) mode.
- Ensure that all window glasses are closed and all lamps are turned 'OFF'.
- At night, put on the parking lights if required.
- Remove the key from the vehicle and lock the vehicle.
- Block the wheels and engaged in gear if parked on a slope.

## STARTING AND DRIVING

### *(i)* NOTE

When parking on a downhill gradient, place the gear lever in 'Reverse' position. While parking on uphill gradient, place the gear lever in the '1<sup>st</sup>' position.

### **⚠ WARNING**

Never leave children unsupervised in the parked vehicle. They could also operate the vehicle's equipment. There is a risk of an accident and injury.

### *(i)* NOTE

*Do not use parking brake for braking unless unavoidable circumstances like when service brake is not working properly. The braking distance is considerably longer and the wheels could lock. There is an increased danger of skidding and accidents.*

### **⚠ WARNING**


During parking, Ensure that Vehicle should not be keyed off in D mode.

### Automatic Parking Brake (if available)



APB switch is located behind the gear shift lever replacing the conventional parking brake (Hand brake lever connected to brake mechanism by cable). APB is applied by pulling up the APB switch and can be released by pushing down the APB switch which needs the vehicle to be at ig-

nition/Engine ON condition. Always ensure parking brake is released and parking brake warning lamp is OFF before start of the drive. Park brake warning lamp in cluster at engine running condition indicates failure in brake system and vehicle needs to be checked at TATA Service center. If this is not possible use the vehicle with extreme precaution until you reach service center.



### How to Apply

1. Depress the Brake pedal.
2. Pull APB switch upward.

#### *(i)* NOTE

- *Kindly ensure APB indication turns on in the Cluster.*
- *Also APB is applied automatically if Engine is turned off and Gear lever is engaged to park position for Automatic transmission.*
- *During parking the vehicle on Steep incline or trailer is attached kindly ensure APB can hold the vehicle before leaving.*



#### *(i)* NOTE

*Kindly ensure parking brake indication in instrument cluster is turned off after APB is released.*

#### **WARNING**

- Do not use parking brake in vehicle running condition except for emergency situations like service brake failure. This can damage vehicle brake system.
- If the APB fails to apply, prevent vehicle movement by blocking the rear wheels.

### How to Release

APB will be released only if you press the APB switch along with

## STARTING AND DRIVING

### APB Gets Released Automatically For Automatic Transmission

1. In engine running condition shift the gear lever from Park (P) or Neutral (N) to Drive (D) or reverse (R).
2. Driver Door is closed.
3. Seat belt is fasten.
4. Depress the accelerator pedal when gear lever is in Drive (D) or reverse (R) position.

### For Manual Transmission

1. In engine running condition shift the gear lever to 1st or reverse gear.
2. Driver Door is closed.
3. Seat belt is fasten.
4. Depress the accelerator pedal when gear lever is in 1st or reverse gear.

#### ⚠ WARNING

EPB and AVH will get auto released when a Drive off situation is detected (Clutch released partially and accelerator pedal pressed). This is applicable

even when vehicle is in neutral gear and due care needs to be taken especially when the vehicle is parked in nose down condition.

#### ⓘ NOTE

- *Make sure park brake indication in cluster is turned off after automatic release of APB.*
- *For safety you can engage APB only once even though ignition is turned off in case vehicle starts to roll away but you cannot release APB in ignition off condition.*
- *Also it is recommended to depress the brake pedal and release the APB manually when driving downhill or backing up the vehicle.*

nearest authorized TATA service center.

- Don't drive your vehicle with APB engaged at any time it will cause excessive brake pad wear and it will damage the brake rotors.

### Warning Indicator

With APB applied if you are trying to drive off the vehicle and APB is not releasing APB warning light with text message will appear in cluster.



In this situation depress the brake pedal and try to release APB by manually pressing the APB switch. Very Light Click sound may be heard during engaging or releasing APB but this sound is normal and indicates APB is working as intended.

#### ⚠ WARNING

- If parking brake warning is still ON in the cluster even though APB is getting applied and re-leased, the system needs to be checked by

#### ⚠ WARNING

- During Leaving your keys with Valet please inform him/her about APB.
- APB can malfunction if you drive with APB engaged.

- For Smooth Automatic release of APB please depress accelerator pedal slowly.
- It is recommended to always park the vehicle with parking brake engaged to avoid any vehicle moment which can damage vehicle or injure pedestrians.
- You should not allow anyone who is not familiar with vehicle to touch parking brake buttons, unintentional park brake release can lead to injuries.

### APB Malfunction Indicator

Both the APB malfunction lamp and parking brake lamp glow in cluster for 3 secs during ignition ON then disappears. If any abnormality is there in the system the malfunction indicator stays continuously ON. In the case of any fault in the ESP system, this lamp may or may not appear.

Parking brake lamp does not illuminate if the APB is not engaged except the 3 secs during the ignition ON.

#### **WARNING**

- If any abnormality is observed, APB malfunction lamp will glow. Kindly do the ignition latch and check if the same behavior is there .If the Malfunction lamp is still there, have a check with the authorized Tata service center.
- If the parking brake lamp is not glowing on application of APB, have a check with the authorized Tata service center.

### Emergency Braking

In the case of any failure in the service brake or during any other emergency situations APB switch can be applied in vehicle running condition. APB switch needs to be pulled continuously for dynamic braking with APB. If any abnormal noise or burning smell is noticed, kindly have a check with the authorized Tata service center.

## STARTING AND DRIVING

### AUTOMATIC VEHICLE HOLD (if equipped)



The system eliminates the requirement of depressing the brake pedal continuously when the vehicle stops in between running.

#### How to Apply

1. Depress the Brake pedal.
2. Ensure seatbelt is fasten and driver's door is closed.
3. Press AVH switch.
4. Auto Hold indication turns on in the

Cluster which indicates AVH is turned ON and in Standby mode.

5. When the vehicle reaches the standstill condition though brake pedal is released AVH holds the vehicle and AVH indication changes the color from white to green.



AVH will be released when accelerator pedal is depressed in first gear or Reverse gear (in case of Manual Transmission) and R (Reverse), D (Drive) or Manual shift mode (in case of Automatic Transmission).

#### *(i) NOTE*

- When the vehicle is turned off keeping the Auto Vehicle Hold in the ON condition, Auto Vehicle Hold will gets released and APB will get automatically applied.
- For safety, for smooth take off depress the accelerator pedal slowly when the AVH is active.

AVH indication and warning lamps which will appear on the cluster is provided below.



AVH indication ON



AVH active indication (Green color)



AVH failure indication (Red color)

### How to Disengage AVH

In Ignition ON Condition depress the Auto hold switch the Auto Hold indication in white color will disappear from the cluster indicating AVH is turned off.

AVH once turned ON will not be turned off automatically until it is deselected by switch input from user.

#### NOTE

*Auto hold function will not become active if*

- Driver Seat belt is not buckled.*
- Driver Door is not closed properly.*
- APB is in applied condition.*

For end user safety Auto hold will shift automatically to APB in below conditions:

1. Vehicle is in standstill for more than 3 minutes.
2. Gear leaver shift from any of Drive (D), Reverse(R) to Park (P) Position for AT Transmission vehicles.
3. If you turn off the Engine /Ignition in standstill condition.

4. Vehicle is standing on steep slope.

In above conditions AVH indication will change from Green to white and APB indication will turn on in the cluster.

#### WARNING

If any abnormality is present in the system, AVH malfunction lamp in amber colour will glow which is amber in colour. Kindly do the ignition latch of 30 seconds and check if the same behaviour is there. If the Malfunction lamp is still there, get your parking brake system checked with the authorized Tata dealer.

### Precautions During Vehicle Towing with APB

Before towing please ensure APB is not engaged as it can damage Brake pads and Brake components during vehicle towing.


1. APB should be manually released if battery of the vehicle is healthy during towing and Ignition should be kept in ON state till vehicle reaches to service centre.
2. If vehicle battery is not in healthy state during vehicle towing external power is required for manual re-lease of APB and ignition should be ON till vehicle reaches to service center or
3. If it is not possible to keep the ignition ON till vehicle reaches to service center then keep APB button pressed in release position, Brake paddle pressed and turn off the ignition this will avoid auto engagement of APB during switching off the ignition.

### *(i) NOTE*

- In case of vehicle is power down APB cannot be released, External supply or Jump start is necessary to release the APB.*
- It is not recommended to touch/remove any component of Rear calipers to disengage the APB as it will damage the caliper Components permanently.*

### REVERSE PARK ASSIST (if available)

The user can view the Park assist screen by selecting this feature in Infotainment display to see any obstacle behind the vehicle while parking.



The system also displays the Park assist screen when the reverse gear is engaged.

It provides audio and visual information through the vehicles infotainment system / Buzzer. Always look at surrounding before initiating reverse parking for kids, pets and elderly people moving around the vehicle.

Variant where infotainment display is not present and audio warning is given through a buzzer, on activating the Reverse Park Assist system, a tone will be played within first two seconds to indicate

the proper functioning of the system. After these two seconds, normal functioning of the system will continue. If no tone is heard for first two seconds, it shall mean that RPAS system is faulty. The owner should, in that case, go to the nearest dealer for rectification.

### Reverse Park Assist with Sensor



#### Operation

The reverse park assist system can also be activated manually through infotainment screen. Display will be seen on infotainment screen.

#### *(i)* NOTE

*Turning the ignition 'OFF' 'while the Park assist feature in running would disable the feature.*

## STARTING AND DRIVING

---

### Audio Warning

Audio warning may come from Infotainment system speaker or through Buzzer, depending on vehicle model and configuration.

Approx. Distance Range From Bumper (in cm)	Visual Information	Audible Information
25 – 40	All six zones are highlighted (Red, Green and Yellow zones)	Continuous Beep
41 – 80	Bottom four zones are highlighted (Yellow and Green zones)	Fast Beep
81 – 120	Bottom two zones are highlighted (Green zones)	Slow Beep

### Reverse Park Assist Limitations

Reverse Park Assist system is not a collision avoiding system. It is solely the driver's responsibility to park the vehicle safely.

Reverse Park Assist feature works on ultra sound echo technology, due to which performance is not guaranteed in following scenarios:

- If the object has a sharp edge surface, where surface may divert echoes from sensor reception.
- If object is mesh fence made up of thin wires, where echoes can't be given by the surface.
- Fast moving objects passes in the sensor field of detection, where echoes are not processed by the system.
- If object is made/covered by foam or sponge or snow where ultrasonic sound signals are absorbed.

- Objects close to the rear bumper can go undetected by the Reverse Park Assist field of detection. Driver should use extreme caution while parking the vehicle.
- If height of the bumper is changed due to alteration to the suspension or other causes.
- If the sensor areas are extremely hot from direct sunlight or cold due to freezing weather.
- If Sensors are covered by a hand, sticker, accessory, etc.
- If ultrasonic noise is present around Vehicle due to other vehicle sensors, horn, engine, air braking system (large vehicles), Exhaust Fans, Wireless transmitters or mobile phones.
- If the vehicle speed exceeds 10 km/h, the system will not warn you even though objects are detected, error message 'Vehicle Speed is high, drive slowly!' will appear.
- Driving on uneven road surfaces e.g. Gravel, unpaved roads, Artificial Speed Breakers, or gradient.

- Poles of square/rectangle cross section might not be detected at vehicle's edge.

### **WARNING**

Due to any reason, if the sensor gets misaligned or loses its intended fitment position, contact your dealer for refit-  
ment.

### **(i) NOTE**

*Turning the ignition 'OFF' 'while the Park assist feature in running would disable the feature.*

### **WARNING**

0 to 25 cm obstacle detection performance is not guaranteed due to ultrasonic sensor technology limitation.

## STARTING AND DRIVING

---

### Reverse Park Assist System Preventive Maintenance/cleaning

1. Regularly clean the Sensors and keep them free from dust, ice, mud, water, chewing gum etc. for proper working of the system. Use a smooth cloth for cleaning.
2. Do not use water at high pressure for cleaning the sensor.
3. Do not cover the sensors. This will interrupt park assist performance.
4. Do not remove mud, snow on the sensors using stick or hard material. Use normal water and soft cloth.

#### **WARNING**

- In low light conditions, the screen may darken or image may appear faint.
- If the tire sizes are changed, the position of the fixed guidelines displayed on the screen may change.
- In case of damage of the rear portion of the vehicle, Reverse Park Assist sensors position may change

which causes wrong visual information on display. In case of damage, make sure that, Reverse Park Assist sensors are fitted properly at the intended location.

- In case of uneven road conditions or up-hill or downhill conditions, do not depend on Reverse Park Assist aid.
- Do not apply any kind of force on the reverse park assist sensors.
- Always use rear view mirrors along with Reverse Park Assist for confirming safety of the rear and the surrounding conditions.

### Park Assist Malfunction Indications

In case of Reverse park assist system malfunctions, fault screen may appear on the infotainment system.


Reason for this fault may be

1. Body Control Module Failure
2. Sensor Malfunction
3. Partner components such as Infotainment music system, Instrument Cluster failure

## REAR PARK ASSIST WITH CAMERA (if available)



Rear View Camera is a visual reverse guiding system. When reversing or parking, make sure that there are no persons, animals or objects in the area in which you are reversing.



Three color moving grid lines guide the user to understand the rear object distance exactly. The grid lines are updated by the motion of the vehicle as well as by the steering input.

Guidelines will help you to rightly find the sufficient parking place, helps you to keep the vehicle straight, rear object proximity indication etc.

### *(i)* NOTE

*Turning the ignition 'OFF' while the Park assist feature in running would disable the feature.*



### Activation

#### Reverse Gear

This system will start, if reverse gear is engaged, or park assist button (if available) is pressed or manual activation is done through Infotainment screen.

#### Deactivation


System will deactivate, if reverse gear is disengaged, or park assist button (if available) is pressed.

If started through infotainment, the system can be stopped using a cross button on infotainment screen.


## STARTING AND DRIVING

---

### Understanding Guidelines Indication



Static guidelines



Dynamic guidelines

#### Green Line

Indicates, if rear object is in this colored zone, you have to be cautious. Still you can go backward safely.

#### Yellow Line

Indicates, if rear objects are in this colored zone, you have to take utmost care. However, objects fall in this zone, may not hit vehicle.

#### Red Line

Indicates, if rear objects are in this colored zone, you have to stop the vehicle and not allowed to go back-ward. If you still go backward, your vehicle will hit the object.

#### Do's And Don't

- As the camera is, IP protected, do not detach, disassemble or modify in any manner from the actual position. This will show required visual information in display.
- Do not use camera when tailgate is open. If tailgate is open, visual information may not be the actual rear view of the vehicle & system will warn with message 'Tail Gate Open, Please close.'
- When the camera is operated under fluorescent lights, sodium light or mercury light etc., illuminated areas on the lens may appear to flicker in the display.
- Do not attach any advertisement or styling or any kind of stickers on top of camera. If this happens, camera cannot provide you the visual image and may damage camera.
- Do not add any accessory, which will obstruct camera field of view.

## Cleaning Camera

1. Due to environmental reasons, dust, mud or fog may accumulate on the camera lens. So regularly clean the camera lens.
2. Use water to clean the camera lens. Do not use extreme cold or hot water. Rapid changes in temperature may brittle the camera lens. Do not apply High Pressure water for cleaning.
3. Wipe the camera lens with soft cloth.
4. Do not use hard cloth or material to wipe the camera lens. This will cause scratches on the camera, and leads to deteriorated visual image on the display.
5. Do not apply organic solvent, car wax, window cleaner or glass coat to clean the camera. If this is applied, wipe it off as soon as possible.
6. Do not apply heavy force on lens, while cleaning.
7. Do not remove mud, snow on the camera lens using stick or hard material. Use normal water and soft cloth.

### ⚠️ WARNING

- The camera uses fish eye lens. So the size of the objects or in the display may differ from the actual size and distances in low light conditions, the screen may darken or image may appear faint.
- If the tire sizes are changed, the position of the fixed guidelines displayed on the screen may change.
- During rainy conditions, image may get obscured. In such conditions, do not depend on camera view. The camera used in the vehicle, may not reproduce the same color of the real object.
- The camera used in the vehicle, may not reproduce the same color of the real object.
- In case of damage of the rear portion of the vehicle, camera position may change. Which causes wrong visual information on display. In case of damage, make sure that, camera is fitted properly at the in tended location.
- In case of uneven road conditions or up-hill or downhill conditions, do not depend on rear view camera park aid.
- Do not apply any kind of force on the camera.
- Always use rear View mirrors along with Rear View Camera for confirming the safety of the rear and the surrounding conditions.
- High humidity and variation in ambient temperature may result into condensation inside the camera lens, which may further result into degradation of camera video feed on the screen. It is recommended that not to rely on camera video feed for parking assistance in such scenario. This phenome-non is temporary and will be automatically recovered with reduction in humidity and less variation in ambient temperature.
- The area displayed by the rear view camera is limited. The camera does



## STARTING AND DRIVING

not display objects that are close to or below the bumper, underneath the vehicle, or objects out of the camera's field of view. The area displayed on the screen may vary according to vehicle orientation or road conditions.

### Rear View Camera System Precautions

#### Area Displayed on Screen

The rear view camera system displays an image of the view from the bumper of the rear area of the vehicle. To adjust the image on the rear view monitor system screen.





- The area displayed on the screen may vary according to vehicle orientation

conditions.

- Objects, which are close to either corner of the bumper or under the bumper, cannot be seen on the screen.
- The camera uses a special lens. The distance of the image that appears on the screen differs from the actual distance. The monitor may not display items that are located higher than the camera field of view.

#### When the Ground Behind the Vehicle Slopes Up Sharply







The distance guidelines will appear to be closer to the vehicle than the actual distance.

Because of this, objects will appear to be farther away than they actually are.

In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.

### When the Ground Behind the Vehicle Slopes Down Sharply




The distance guidelines will appear to be further from the vehicle than the actual distance.

Because of this, objects will appear to be closer than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.

## STARTING AND DRIVING

### When Any Part of the Vehicle Sags





When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the fixed guide lines on the screen and the actual distance/course on the road.

### When Approaching Three-dimensional Objects


The distance guidelines are displayed according to flat surfaced objects (such as the road). It is not possible to determine the position of three-dimensional objects (such as vehicles) using the distance guidelines. When approaching a three-dimensional object.

#### a. Distance Guidelines




Visually check the surroundings and the area behind the vehicle. On the screen, it appears that a truck is parked at point B. However, in reality if you back up to point A, you will hit the truck. On the screen, it appears that A is closest and C is furthest away. However, in reality, the distance to A and C is the same, and B is farther than A and C.

### b. Vehicle Width Guidelines



Visually check the surroundings and the area behind the vehicle. In the case shown below, the truck appears to be outside of the vehicle width guidelines and the vehicle does not look as if it hits the truck. However, the rear body of the truck may actually cross over the vehicle width guidelines. In reality if you back up as guided by the vehicle width guidelines, the vehicle may hit the truck.



### DRIVE MODE (if available)



Drive mode selection switches are provided on center console for activation. Press the switch to select the mode.

'ECO', 'CITY' and 'SPORT' drive modes are provided. These modes can be used to adjust engine characteristics and vehicle performance in line with desired requirement.

## STARTING AND DRIVING

Drive Mode	Performance
CITY	Increased engine Torque and Power output for BALANCED performance. It is default mode.
ECO	Optimum engine Torque and Power output for FUEL EFFICIENT performance.
SPORT	Produce more torque from engine.

### *(i)* NOTE

When vehicle is in ECO or SPORT mode, by pressing current mode switch again, mode will switch to CITY mode.

## TERRAIN RESPONSE MODE (if available)



Rotate the knob clockwise to select the terrain mode.

### 1. Normal Road Mode

In this Mode System will adapt to the prevailing surface conditions automatically and enables control settings based on the condition sensed.

This mode is designed to react more sensitively to support a regular driver to utilize available physical limit.

Vehicle performance optimized to support

all surface condition. Almost no lateral forces allowed, Braking System, Traction System is more focused on Vehicle stability to provide better driving confidence even to amateur users.

### 2. Wet Mode

When road conditions are no more Normal, wet mode delivers confidence without compromising driving pleasure. Wet mode automatically engages advance traction, reduces throttle response, which in turn provides greater confidence without compromising safety of occupants in slippery conditions.

The wet mode is designed for driving in the rain. It is characterized by having better traction and handling so you can effectively and safely drive during these conditions.

### *(i)* NOTE

If you have driven for a long time in wet road without braking, there may be a delayed reaction from the brakes when braking for the first time. You have to depress the brake pedal more firmly.

Maintain a greater distance from the vehicle in front.

### 3. Rough Road Mode

Rough Road Mode optimizes the vehicle behavior for driving over rough road or other unyielding obstacles.

Braking performance is also tuned to support Rough road surfaces as compared to other drive modes.

System allows improved rough road performance to be more easily accessible to all customers specially novice or inexperienced user.

#### NOTE

*Cautiously drive the vehicle on a rough road or off the road. Otherwise, the tires and wheels may be damaged. After driving those areas, inspect the tires and wheels.*

### 4. Electronic Stability Program (ESP)(if available)

ESP monitors driving stability and traction.

If ESP detects that the vehicle is deviating from the direction desired by the driver, one or more wheels are braked to stabilize the vehicle. The engine output is also modified to keep the vehicle on the desired course within physical limits. ESP assists the driver when pulling away on wet or slippery roads. ESP can also stabilize the vehicle during braking and acceleration. Activate the ESP feature by pressing on the center console.



### 5. Hill Descent Control (HDC) (if available)

While driving down on a hill slope, activate the HDC feature by pressing on the center console.



HDC provides a smooth and controlled hill descent by enabling the vehicle to control the speed of each wheel. The system will automatically apply the brakes to slow down to the desired vehicle speed. Cruise control +/-buttons or Brake and accelerator pedal can adjust the speed to a comfortable level.

HDC interventions will be automatically disabled once the descent is complete and vehicle is on levelled road. Non-zero speed less than 35 kmph would be required to turn ON HDC. A speed greater than 40 kmph will end all active HDC control and switch HDC to standby mode. Once the vehicle speed is lower than the specified threshold of 40 kmph HDC becomes activated again whenever required (No press of HDC button is required).HDC is permanently switched off if the vehicle

## STARTING AND DRIVING

---

speed exceeds 60 kmph and Active state on HDC switch will go off automatically. HDC works in both Neutral and in Gear forward and reverse position.

While driving down a hill, the engine braking should be used by shifting into a lower gear. Do not drive in neutral gear or switch off the engine.

### **WARNING**

HDC cannot take account of road, weather, traffic and tyre conditions. You are always responsible for keeping control of the vehicle and for assessing whether the downhill gradient can be managed.

### EMERGENCY EQUIPMENT

You should be familiar with the location of the emergency equipment provided in the vehicle and how to use it.

Check this equipment periodically and ensure that they are in proper working condition and stowed at their locations.

#### First Aid Kit


The first aid kit is kept inside the glove box compartment.

The kit contains items that can be used in case of minor injuries only.


#### *(i)* NOTE

*Check contents of the first aid kit periodically and replenish consumed or expired items.*

### Tool Kit, Jack and Spare Wheel



### Spare Wheel




Tool kit, Jack are provided in rear boot.

1. Spare wheel removal spanner
2. Advance Warning Triangle
3. Puncture repair kit
4. Jack Handle

## EMERGENCY AND BREAKDOWN ASSISTANCE

### Advance Warning Triangle



An advance warning triangle is kept on the tool tray in the luggage compartment.

Use advance warning triangle to warn the approaching traffic in case of vehicle breakdown or during emergency, where your vehicle could become a potential traffic hazard.

Press hazard warning switch, all turn signal lamps will start blinking.



Keep the warning triangle at an approximate distance of 50-150 m behind your vehicle in the same lane of traffic. The reflecting side of the triangle should face the oncoming traffic and it should be free from any obstacles.

***NOTE***

*After using the warning triangle tie it firmly and keep it inside the bag to avoid rattling noise.*

### Hazard Warning Switch



Press the hazard warning switch to activate the hazard warning. All the turn signal lamps will flash simultaneously. To turn OFF, press the switch again.



Use the hazard warning to warn the traffic during emergency parking or when your vehicle could become a traffic hazard.

***NOTE***

*The hazard warning lamps can operate even if the ignition is switched off.*

### SPARE WHEEL REMOVAL PROCESS

- To remove the spare wheel, open the tail gate.
- Open the cover and take out the advance warning triangle.



- Open the flap with the help of screw driver provided in tool kit for accessing to spare wheel removal retaining bolt.
- Insert the spare wheel removal spanner and rotate anticlockwise to unscrew the retaining bolt.

## EMERGENCY AND BREAKDOWN ASSISTANCE

- As the retaining bolt gets loosened, the spare wheel lowers down as shown.




- Remove the holding bracket from the spare wheel and get the spare wheel separated.



### Spare Wheel Fitment Process

- Engage the holding brackets in spare wheel.



- Insert the spare wheel removal spanner and rotate clockwise to lift the spare wheel.
- Tighten the bolt until you heard the 'Tak' noise. Do not overtight.

#### *(i)* NOTE

While stowing the spare wheel, ensure that winch bracket is properly engaged in wheel slot.

### IN CASE OF FLAT TYRE

- Reduce vehicle speed gradually. Avoid sudden steering movement or braking.
- Pay attention to the traffic conditions as you do so.
- Switch on the hazard warning lamps.
- Stop the vehicle on solid, non-slippery and level ground, as far away as possible from traffic.
- Use the Jack on level, hard ground. Avoid changing the wheel on uphill and downhill slopes. Chock the wheels, if the deflated wheel needs to be changed on slope / ghat area.
- If possible, bring the front wheels into the straight-ahead position.
- Secure the vehicle against rolling away.
- Set the parking brake firmly and shift into "R" (Reverse) gear on level ground and while vehicle is in downhill position.
- When the vehicle is in uphill position, shift the gear in first gear.

- Switch off the engine.
- Keep advance warning triangle at a suitable distance behind the vehicle as an indication of breakdown.
- Close all the doors.
- Chock the wheels.

#### ⚠ WARNING


If you drive with a flat tyre, there is a risk of the following hazards:

- A flat tyre affects the ability to steer or brake the vehicle.
- You could lose control of the vehicle.
- Continued driving with a flat tyre will permanently damage the tyre and cause excessive heat buildup and possibly a fire. There is a risk of an accident.

### Changing Flat Tyre

Remove the center hub cap/wheel cover in case of steel wheel rim (if available).

Loosen the nuts (as indicated) on the wheel in diagonal sequence. Do not unscrew the nuts completely before jacking the vehicle.



Wheel nut removal

#### ⓘ NOTE

- *The jack is designed only to raise and hold the vehicle for a short time while a wheel is being changed. It is*

## EMERGENCY AND BREAKDOWN ASSISTANCE

- not suited for performing maintenance work under the vehicle.
- Use the jack on level, hard ground. Avoid changing the wheel on uphill and downhill slopes. Chock the wheels, if the deflated wheel needs to be changed on slope / ghat area.
- Before raising the vehicle, secure it from rolling away by applying the parking brake.
- Shift the gear into 'R' (reverse) on level ground and while vehicle is in downhill position, and shift the gear in first gear when vehicle is in uphill position.
- Chock the wheels.
- Do not use wooden blocks or similar objects as a jack underlay.
- Do not place your hands and feet or lie under the raised vehicle when it is supported by a jack.
- Do not run the engine when the vehicle is supported by the jack and never allow passengers to remain in

the vehicle.


- Do not open or close a door or the tailgate when the vehicle is raised.

Assemble the Jack handle and wheel spanner (as shown in jacking fig).



Position the jack vertically and raise it by turning the jack handle clockwise until the jack sits completely on jacking point and the base of the jack lies evenly on the ground.

### Jacking Point Location on Vehicle


The jacking points are indicated below the door of the vehicle (Refer jacking point location).




Jacking point location



Continue to raise the jack slowly and smoothly until the tyre clears the ground. Do not raise the vehicle more than necessary.



Remove wheel mounting nuts with the help of wheel spanner and take out flat tyre.



Roll the spare wheel into position and align the holes in the wheel studs.

Install wheel nuts with their cone shaped end facing the wheel. Tighten each nut by

## EMERGENCY AND BREAKDOWN ASSISTANCE

hand until the wheel is securely seated on the hub.

Lower the jack completely then tighten the wheel nuts one by one using wheel spanner.

Press fit the wheel cover back /center hub cap back (if available).

Restore all the tools and jack at their respective location.

Place the flat tyre at spare wheel location.

### NOTE

*Check and correct the tyre pressure and wheel nuts tightness of the changed wheel at nearest authorised service station.*

*Get the flat tyre repaired at the earliest.*

### WARNING

Do not jack the vehicle under rear axle.

## PUNCTURE REPAIR KIT (if available)

### Introduction

#### WARNING

Compliance with these instructions is vital to ensure vehicle safety. Non-compliance with these instructions means risking tire damage, which can affect vehicle handling and lead to loss of vehicle control. This may result in serious injury or death. Inform all other users of the vehicle if standard items for dealing with a puncture (e.g. spare tire) have been replaced by the Puncture repair Kit.

The Puncture repair Kit seals most tire punctures to restore temporarily mobility. Recommended use only for passenger car ground tires only and vehicle tire inflation pressure up to 300 kPa (3 bar, 43 psi). The system consists of a compressor and a sealant, and serves to effectively and conveniently seal punctures in car tires caused, for example, by nails or similar foreign objects with a diameter of up to  $\frac{1}{4}$

“ (6 mm).

Depending on the type and extent of tire damage, some tires can only be partially sealed or not sealed at all. Loss of tire pressure can affect vehicle handling, leading to loss of vehicle control. Observe the following rules when using the Puncture repair Kit:

- Drive with caution and avoid making sudden steering or driving maneuvers, especially if the vehicle is heavily loaded or you are towing a trailer.
- The system will provide you with an emergency temporary repair, enabling you to continue your journey to the next vehicle or tire dealer, or to drive a maximum distance of 200 km (120 miles).
- Do not exceed a maximum speed of 80 km/h (50 mph).
- Keep the Puncture repair Kit out of the reach of children.
- Once the Puncture repair Kit has been used for a temporary tire repair, the functionality of the TPMS module (if

## EMERGENCY AND BREAKDOWN ASSISTANCE

applicable) shall be checked by an expert and replaced if necessary.

These instructions provide a step-by-step explanation of how to use the Puncture repair Kit to temporarily repair a tire puncture.


Please read the section on "How to proceed in the event of a tire puncture".

### WARNING

Do not use the Puncture repair Kit if the tire has already been damaged as a result of being driven underinflated. Do not try to seal damage other than that located within the visible tread of the tire. Do not try to seal damage to the tire's sidewall.

### Location In Vehicle

In luggage compartment




### Puncture Repair Kit Removal Process

- To access the puncture repair kit open the tailgate.
- Open the cover and take out the Puncture Repair kit.

## EMERGENCY AND BREAKDOWN ASSISTANCE

### Step



## EMERGENCY AND BREAKDOWN ASSISTANCE

### Instructions On How To Use The Puncture Repair Kit Safely

- Use product with original vehicle ground tires only.
- Only use the Puncture repair Kit with tubeless tires.
- If used for other than its intended purpose, the Puncture repair Kit may cause severe accident or injury due to the fact that compressed air can act as an explosive or propellant.
- Park your vehicle at the roadside so that you do not obstruct the flow of traffic and you are able to use the Puncture repair Kit without being in danger.
- Engage the hand brake, even if you have parked on a level road, to ensure that the vehicle will not move.
- Do not attempt to remove foreign objects like nails or screws penetrating the tire. Leave them as they are.
- Leave the engine running while the Puncture repair Kit is in use, but not if the vehicle is in an enclosed or poorly ventilated area.

- Never leave the Puncture repair Kit unattended while in use.
- Do not keep the compressor operating for more than 10 minutes otherwise there is a risk of it over-heating.
- Replace the sealant bottle with a new one before the expiration date is reached (see bottle label). In case that the sealant is expired the functionality cannot be fully guaranteed. Only use original Puncture re-pair Kit bottles which are pressure resistant.

### How To Proceed In The Event Of Tyre Puncture

You can temporarily repair a tire puncture in two steps.

First pump the tire sealant and air into the tire (see Step 1). Immediately thereafter, drive a short distance (3-10 km / 2-6 miles) in order to distribute the sealant in the tire. After that, check the tire pressure and pump more air into the tire if necessary (see Step 2). Then you can proceed to drive with caution for a maximum distance of 200 km (120 miles) and at a maximum speed of 80 km/h (50 mph).

Inform all other users of the vehicle that the tire has been temporarily sealed with the Puncture repair Kit and make them aware of the special driving conditions to be observed.

#### ⚠ WARNING

Need to drain fluid from tire before repair.

### Step 1 :pumping The Tyre Sealant And Air Into The Tyre

1. Peel off the decal denoting the maximum permissible speed (80 km/h | 50 mph) from the casing and attach it to the edge of the windscreen as shown on the picture.
2. Take the hose and power plug with cable out of the Puncture repair Kit casing. Unscrew the orange cap of the bottle connector.
3. Unscrew the red cap of the sealant bottle. (Shake sealant bottle well before use.

## EMERGENCY AND BREAKDOWN ASSISTANCE

### ⚠ WARNING

Leave the bottle seal intact. Screwing the bottle onto the bottle holder will pierce the seal of the bottle. Avoid skin contact with the sealant which contains natural rubber latex. Do not open pressure "air release" valve. Please use protective glove for safety purpose.

4. Screw the bottle clockwise firmly against the slight resistance of the notches onto the sealing gasket of the bottle connector until it is screwed tight.
5. Remove the valve cap from the damaged tire. Pull the protective cap off the end of the hose and screw the hose firmly onto the valve of the damaged tire. Make sure that the compressor switch is switched to "0" and the pressure "air release" valve is closed.
6. Insert power plug into the 12 volt power socket connection.
7. Start the engine (only if the vehicle is outdoors or in a well ventilated area).

### ⚠ WARNING

Asphyxiation may occur if the engine is allowed to run in a non-ventilated or poorly ventilated area (e.g. inside a building)

8. Press compressor switch to "I".

### ⓘ NOTE

*Check the sidewall of the tire prior to inflation. If there are any cracks, bumps or similar damage, do not attempt to inflate the tire. Do not stand directly beside the tire while the compressor is pumping. Watch the sidewall of the tire. If any cracks, bumps or similar damage appear, turn off the compressor and let the air out by means of the pressure "air release" valve. In this case, do not continue to use the tire.*

### ⓘ NOTE

*When pumping in the sealant through the tire valve, the pressure may rise up to 500 kPa (5 bar, 73 psi) but will drop again after about 30 seconds.*

9. Inflate the tire within about 10 minutes to an inflation pressure of minimum 180 kPa, (1.8 bar, and 26 psi) and a maximum of 300 kPa (3 bar, 43 psi).
10. Switch off the compressor briefly in order to read the actual tire pressure from the pressure gauge.

### ⚠ WARNING

If heavy vibrations, unsteady steering behavior or noises should occur while driving, reduce your speed and drive with caution to a place where it is safe for you to stop the vehicle. Recheck the tire and its pressure. If the tire pressure is less than 130 kPa (1.3 bar, 19 psi) or if there are any visible cracks, bumps or similar damage on the side wall, do not continue to use the tire!

**11, 12.** Once a tire inflation pressure of at least 180 kPa (1.8 bar, 26 psi) has been reached.

- Switch the compressor to "0".
- Pull the power plug from the 12 volt power socket connection.
- Slowly unscrew the hose from the tire valve (sealant residues may escape from the hose) and put the protective cap back onto the hose.
- Leave the bottle in the holder. This avoids unexpected leakage of sealant residue.
- Make sure the Puncture repair Kit, the cap of the bottle and the orange cap are stored safely, but are still easily accessible, in the vehicle.

The kit will be needed again when you check the tire pressure.

**13, 14.** Immediately start and drive for about 3-10 km (2-6 miles) so that the sealant can seal the damaged area. Do not drive for more than 10 min and not any faster than 80 km/h (50 mph) (observe the decal indicating the permissible speed).

### ⚠ WARNING

If heavy vibrations, unsteady steering behavior or noises should occur while driving, reduce your speed and drive with caution to a place where it is safe for you to stop the vehicle. Recheck the tire and its pressure. If the tire pressure is less than 130 kPa (1.3 bar, 19 psi) or if there are any visible cracks, bumps or similar damage on the side wall, do not continue to use the tire!

### ⚠ WARNING

If the tire check shows that the pressure of the sealant-filled tire is less than 130 kPa (1.3 bar, 19 psi) or if there are any visible cracks, bumps or similar tire damage on the side wall, you must not continue to use that tire.

- Make sure that the compressor switch is switched off to "0".
- Insert the power plug into the 12 volt power socket connection.
- Start the engine (only if the vehicle is outdoors or in a well ventilated area).

### ⚠ WARNING

Asphyxiation may occur if the engine is allowed to run in a non-ventilated or poorly ventilated area (e.g. inside a building )

### Step 2 Checking The Tyre Pressure

**15.** Stop the vehicle after driving about 3-10 km (2-6 miles). Check and, where necessary, adjust the pressure of the damaged tire. Remove the protective cap from the end of the hose. Screw the hose firmly onto the valve of the damaged tire.

**16.** Read the tire pressure from the pressure gauge.


If the pressure of the sealant-filled tire is 130 kPa (1.3 bar, 19 psi) or more, it must now be adjusted to the pressure specified for your vehicle (Refer sticker on vehicle).

**17,18.** Switch the compressor on to "I" and pump the tire up to the specified tire pressure within max. 10 minutes.

## EMERGENCY AND BREAKDOWN ASSISTANCE

### *(i)* NOTE

Compressor unit we can use for filling the air & checking the pressure of the normal tyre.



- Switch the compressor off and check the tire pressure again. If tire pressure is too high, deflate the tire to the specified pressure using the pressure "air release" valve.
- Rest of the remaining sealant in the hose might leak out when opening pressure "air release" valve or taking off the protective cap of the hose. Please use protective glove for safety purpose.
- Once you have inflated the tire to its correct tire pressure, switch off the compressor, pull the plug out of the socket, unscrew the hose, fasten the tire valve cap and put back on the protective cap of the hose.

tective cap of the hose.

- Leave the bottle in the holder and store the Puncture repair Kit away safely in the vehicle trunk.

### *⚠* WARNING

After using the sealant you may drive no faster than 80 km/h (50 mph), and the damaged tire must be replaced as quickly as possible (with in a maximum driving distance of 200 km (120 miles)). You must not continue to drive if heavy vibrations, unsteady steering behavior or noises should occur while driving.

**19, 20.** Drive to the nearest workshop to get the damaged tyre repaired and if the tyre repair is not possible, tyre should be removed from the car. Before the tire is removed from the rim, inform your tire dealer that the tire contains sealant. Sealant deposits in a used hose may impair proper function of the Puncture repair Kit. Both the sealant bottle and the hose need to be replaced together after using the Puncture repair Kit.

### *(i)* NOTE

Remember that emergency roadside tire repair kits only provide temporary mobility. Regulation concerning tire repair after usage of Puncture Repair Kit may differ from country to country. You should consult a tire specialist for advice.

### *⚠* WARNING

Before driving, ensure tire is adjusted to recommended inflation pressure as indicated on vehicle placard. Monitor tire pressure until sealed tire is replaced. Proceed as described above from point 15 onwards.

New sealant and replacement parts can be purchased from your authorized repair shop or dealer. Sealant bottles can be disposed with house-hold waste.

### JUMP LEAD STARTING


Use only a battery of same rating & capacity to jump start your vehicle. Position the booster battery close to your vehicle so that the jump leads will reach both batteries.

When using a battery of another vehicle, do not let the vehicles touch.

Apply the parking brake firmly and keep the gearshift lever in neutral.


Turn off all vehicle accessories, except those necessary for safety like hazard warning lamps.

If your vehicle is equipped with Battery sensor, then do not connect your jump start cable lead directly on the Sensor surface. Connect only on the negative cable surface as shown on the image. After jump start event, IAC function will be restored only when the Vehicle is parked in idle for 3-4 Hours.



Make jump lead connections as follows:

- Connect one end of the first jump lead to the positive (+) terminal of the discharged battery.
- Connect the other end to the positive (+) terminal of the booster battery.
- Connect one end of the second jump lead to the negative (-) terminal of the booster battery.
- Make the final connection (other end of the negative terminal) to an unpainted, heavy metal part (i.e. engine mounting stud/nut) of the vehicle of discharged battery.



- Start the engine of the vehicle with the discharged battery.
- Before disconnecting the jumper cables, let the engine run for several minutes.
- If the booster battery you are using is fitted to another vehicle, start the engine of the vehicle with the booster battery. Run the engine at moderate speed.
- Remove the jump leads in the exact reverse order in which you connected them.

## EMERGENCY AND BREAKDOWN ASSISTANCE

### NOTE

*Do not disconnect the discharged battery from the vehicle.*

### WARNING

Never connect the jump lead directly to the negative (–) terminal of the discharged battery. This may lead to an explosion.

### WARNING

- Do not allow battery electrolyte to come in contact with eyes, skin, fabrics or painted surfaces. The fluid contains acid which can cause injury and severe damage. Wear protective apparel. Do not inhale any battery gases. Keep children away from batteries. In case if battery acid comes in contact with the skin, wash it off immediately with water and seek medical attention.
- During charging and jump-starting, explosive gases can escape from

the battery. There is a risk of an explosion. Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over the battery.

- Make sure that the positive terminal of a connected battery does not come into contact with vehicle parts. Never place metal objects or tools on a battery.
- It is important that you observe the described order of the battery terminals when connecting and disconnecting a battery. If you are in doubt, seek assistance from qualified specialist workshop.
- Never connect or disconnect the battery terminals while the engine is running.

### TOWING

When towing a break down vehicle, certain precautions and procedures must be taken to prevent damage to the vehicle and/or components. Failure to use standard towing precautionary measures when lifting or towing a break down vehicle could result in an unsafe operating condition.

To ensure proper towing and to prevent accidental damage to your vehicle, take help of a TATA MOTORS authorized dealer or a commercial tow-truck service.

### NOTE


*Make sure that the parking brake is released; vehicle in neutral gear position and steering wheel is unlocked. The power steering functions only when engine is running. Hence, during towing the steering efforts will be more.*

### ⚠ WARNING

- Never get under your vehicle after it has been lifted by a tow truck.
- For towing a vehicle, the best way is to use a wrecker. Alternatively use a rigid tow bar.
- Switch 'ON' the hazard warning indicators of both the vehicles to warn other road users.
- Limit the speed to 20-30 kmph.
- In case of brake failure, use the parking brake to control the vehicle.
- Fasten the tow rope or tow bar at the towing eyes. Otherwise, the vehicle could be damaged.
- When towing, pull away slowly and smoothly. If the tractive power is too high, the vehicles could be damaged.

### Access to Tow Hook

- Unscrew the screws (1) & (2) with the help of screw driver which is provided in Tool kit.



For removal of cover, pull the rear side down.



- Slide the cover in rear direction to disengage front lugs.
- Then carefully disengage the side lugs.

## EMERGENCY AND BREAKDOWN ASSISTANCE



For fitment of cover,

- Engage the front lugs first.
- Slowly press from both side to engage side lugs.
- Engage rear lugs and then tighten the screws.

### Recommended Towing

In case of break down, we recommend that your vehicle be towed with the driving wheels off the ground or place the vehicle on a flatbed truck as shown.


#### **WARNING**

- Never tow your vehicle with the front wheels on the ground or four wheels on the ground (forward or backward), as this may cause serious damage to the transmission.
- When towing with the rear wheels on the ground or on towing dollies, place the ignition switch in the 'ACC' or 'ON' position, and secure the steering wheel in the straight-ahead position with a rope or similar device.

To avoid serious damage to automatic transaxle, limit the vehicle speed to 15 km/h (10 mph) and drive less than 1.5 km (1 mile) when towing.

Before towing, check the automatic transaxle fluid leak under your vehicle. If

the automatic transaxle fluid is leaking, a flatbed equipment or towing dolly must be used.



### FUSES

Your vehicle has fuse boxes at two locations.

The vehicles electrical circuits have fuses to protect the wiring from short circuits or sustained overload.




1. Engine Compartment Fuse Box
2. Cabin Compartment Fuse Box

### Checking and Replacing Fuses


If any electrical unit in your vehicle is not functioning, check the fuses first.

Please follow the steps below that will guide you to check and replace them.

- Apply parking brake.
- Switch off all electrical accessories.
- Turn the ignition key to the 'LOCK' position.
- In the fuse box, identify the defective fuse from its melted wire.



- Remove the blown fuse by "fuse puller". The fuse puller and spare fuses are provided in the engine compartment fuse box.



Engine compartment fuse box

- Blown fuses must be replaced with fuses of same rating, which you can recognize by color and value.

#### NOTE

Always ensure that the spare fuses are replenished.



- Ensure that all other fuses are pressed firmly in position.
- If a newly inserted fuse also blows, have the cause traced and rectified at nearest TATA MOTORS Authorized Service Centre immediately.

## EMERGENCY AND BREAKDOWN ASSISTANCE

### **WARNING**

- If you manipulate or bridge a faulty fuse or if you replace it with a fuse of higher amperage, the electric cables could be overloaded. This could result in a fire. There is a risk of an accident and injury.
- Always replace faulty fuses with the specified new fuses having the correct amperage.

### Battery Mounted Fuse




Fuse No.	Function	Fuse Rating
PF1	STARTER MOTOR	250 A

### **WARNING**

If Fuse box cover is removed for any reason, it should be refitted properly at its original position.

### Engine Compartment Fuse Box



To access the fuse box, follow the procedure as given below:

- Open the Engine compartment.
- Remove the 2 screws of air intake cover (snorkel) with the help of screw driver provided in tool kit.
- Remove the snap fitted cover of fuse box.



Fuse box located in Engine compartment near battery.


### *(i)* NOTE

*The fuse box layout is for reference purpose only. Please refer the sticker provided inside the fuse box cover.*



## EMERGENCY AND BREAKDOWN ASSISTANCE

### Fuses - Engine Compartment (Diesel)



## EMERGENCY AND BREAKDOWN ASSISTANCE

Fuse No.	Function	Fuse Rating
1	INTERIOR F/B BAT - I	60A
2	EMS BATT	10A
3	COMPRESSOR	10A
4	ATS	15A
5	HORN HIGH/LOW TONE	15A
6	ABS ECU	25A
7	SPARE	-
8	EMS RELAY	40A
9	BRAKE LAMP	5A
10	FUEL PUMP	20A
11	DCU	15A
12	TCU	20A
13	TELEMATICS CONTROL UNIT	5A
14	INTERIOR F/B BAT - II	60A
15	GLOW PLUG	60A
16	IGNITION LOAD	30A
17	ABS ECU	40A

Fuse No.	Function	Fuse Rating
18	COOLING FAN LOW	40A
19	STARTER MOTOR SOL	30A
20	BLOWER MOTOR	40A
21	COOLING FAN FAST	60A
22	UNDERBONNET F/R BOX	30A
23	REVERSE LAMP AT	5A
24	HEAD LAMP HIGH BEAM RH	10A
25	HEAD LAMP HIGH BEAM LH	10A
26	HEAD LAMP LOW BEAM RH	10A
27	HEAD LAMP LOW BEAM LH	10A
28	EMS ECU - II	15A
29	EMS ECU - I	20A
30	EMS ECU - III	10A
39	SPARE	-

Fuse No.	Function	Fuse Rating
40	EMS IGN	5A
41	ABS IGN	5A
42	REVERSE LAMP (MT)/TCU (AT)	5A
43	FRONT WIPER MOTOR	30A
44	SPARE	-
45	IBS	5A
46	SPARE	-
47	EMS-CRANK INPUT	5A

## EMERGENCY AND BREAKDOWN ASSISTANCE

---

Relay No.	Relay Function	Relay Rating
R1	IGNITION MINI NO RELAY	40A
R2	COOLING FAN LOW MINI NO RELAY	40A
R3	COOLING FAN HIGH MAXI NO RELAY	70A
R4	EMS ECU MINI NO RELAY	40A
R5	STARTER SOLE-NOID MINI NO RELAY	40A
R6	STARTER INHIBIT MINI NO RELAY	40A
R7	-	
R8	-	
R9	WIPER SPEED SLOW/FAST MICRO (NO-NC) RELAY	20A
R10	-	


Relay No.	Relay Function	Relay Rating
R11	WIPER ON/OFF MICRO (NO-NC) RELAY	20A
R12	ATS MICRO NO REALY	20A
R13	HEAD LAMP HIGH BEAM MICRO NO REALY	20A
R14	DCU MICRO NO RELAY	20A
R15	HEAD LAMP LOW BEAM MICRO NO RELAY	20A
R16	HORN MIRCO NO RELAY	20A
R17	FUEL PUMP MICRO NO RELAY	20A
R18	AC CLUTCH MICRO NO REALY	20A

### Cabin Compartment Fuse Box


#### Cover Removal Procedure

Fuse box is located behind glove box. To access the fuse box, remove cover as per procedure given below:


1. Remove snap fitted end-cover first.




2. To remove the cover, gently pull the cover from bottom side such that the lugs get disengaged.



3. Open glove box and remove complete assembly by removing highlighted 4 screws.




4. Disconnect glove box lamp connection.




## EMERGENCY AND BREAKDOWN ASSISTANCE


5. Disconnect glove box switch connection.



6. Pull out the fuse from fuse box modules from available cutout as shown below.



7. Check the fuse of required function with help of fuse box sticker present at shown location.




8. If fuse is blown, replace with same rating fuse from spare fuses in engine compartment fuse box.
9. Fit back the glove box by following reverse procedure.

***(i)* NOTE**

*It is recommended to replace fuse at TATA Authorized service center.*

# EMERGENCY AND BREAKDOWN ASSISTANCE

## Fuses - Cabin Compartment



## EMERGENCY AND BREAKDOWN ASSISTANCE

Fuse Function	Fuse Rating
IGN SUPPLY	10A
POWER SOCKET	15A
RESTRAINT CONTROL MUDULE	10A
MIRROR ADJUST MOTOR	5A
IMMO IGN/ PEPS IGN FEEDBACK	5A
USB CHARGER	10A
RELAY COIL/ PEPS ACC	10A / 5A
ACC BATT HIGH POWER	20A
BCM - I	15A
IMMO BATT/ TPMS BATT	5A
BCM - II	15A
INFOTAINMENT	20A
BCM - III	15A
OBD/ ACC BATT LOW POWER	15A
HVAC BAT	10A
AMPLIFIER	20A
PEPS	10A

Fuse Function	Fuse Rating
I. CLUSTER	5A
KEY-IN/ POWER SEAT	5A / 20A
ACC RELAY COIL/ SUN-ROOF	5A / 20A
TERRAIN RESPONSE SWITCH	10A
TRANSIT	10A
REAR WIPER	10A
REAR BLOWER MOTOR	15A
PARK ASSIST	5A
W/W MTR DR DOOR	25A
USB CHARGER 3 <sup>rd</sup> ROW	5A
CDL	15A
STARTER FEEDBACK	5A
HRW	25A
BLOWER CONTROLLER	5A
TAILGATE RELEASE	10A
SUNSHADE	20A
AIR PURIFIER	5A
WIRELESS CHARGER	5A

Fuse Function	Fuse Rating
VENTILATED SEAT 7 SEATER/6 SEATER	5A / 10A

## EMERGENCY AND BREAKDOWN ASSISTANCE

Relay Function	Relay Rating
CDL - LOCK MICRO NO-NC RELAY	20A
CDL - UNLOCK MICRO NO-NC RELAY	20A
TAILGATE RELEASE MICRO NO RELAY	20A
IGNITION MICRO NO RELAY	20A

Relay Function	Relay Rating
REAR WIPER MICRO NO RELAY	20A
POWER SEAT MICRO NO RELAY	20A
REVERSE LAMP MICRO NO RELAY	20A
HEATED REAR WINDOW MINI NO RELAY	40A

Relay Function	Relay Rating
BLOWER MOTOR MINI NO RELAY	40A
ACCESSORY MINI NO RELAY	40A

### BULB SPECIFICATION

Sr. No.	Description	Rating	Type	Qty.
1	High beam + Low beam (Option I)	12V, 55W	H7	4
2	High beam + Low beam (Option II)	High Beam : 12V, 55W Low Beam : 12V, 25W	High Beam : H7 Low Beam : D5S	4
3	Turn Signal Front (Option I)	12V, 21W	PY21W	2
4	Turn Signal Front (Option II)	LED	LED Module	2
5	Turn Signal Rear	12V, 21W	PY21W	2
6	Fog Lamp Front (Option I)	12V, 19W	H16	2
7	Fog Lamp Rear (Option II)	12V, 21W	P21W	2
8	Stop Lamp	LED	LED Module	2
9	Position Lamp Front (Option I)	12V, 5W	W5W	6
10	Position Lamp Front (Option II)	LED	LED Module	2

## EMERGENCY AND BREAKDOWN ASSISTANCE

Sr. No.	Description	Rating	Type	Qty.
11	Position Lamp Rear	LED	LED Module	4
12	Reverse Lamp	12V, 16W	W16W	2
13	Rear Registration Plate Lamp	LED	LED Module	2
14	Side Repeater Lamp on ORVM	LED	LED Module	2
15	High Mounted Stop Lamp (Option I)	12V, 5W	W5W	5
16	High Mounted Stop Lamp (Option II)	LED	LED Module	1
17	Boot Lamp	12V, 5W	W5W	1
18	Glove Box Lamp	12V, 5W	W5W	1
19	DRL (if available)	LED	LED Module	2
20	Roof Lamp 1st Row	LED	LED Module	1
21	Roof Lamp 2nd Row	LED	LED Module	1
22	Door Ajar / Puddle Lamp	12V, 5W	W5W	4
23	Ambient light (mood)	LED	LED Module	7

## EMERGENCY AND BREAKDOWN ASSISTANCE

### 24 X 7 ROAD ASSISTANCE

**Dear Customer,**

It is our responsibility and our endeavor to ensure that you have our complete service backup, wherever and whenever you need the same. When you have a road network that spans wide area, the probability of a breakdown happening within hailing distance of a TATA MOTORS Authorized Workshop is very low.

It is precisely for this reason, we have tied up with TVS AA, who will provide breakdown assistance including towing to the nearest TATA MOTORS Authorized Workshop through their Authorized Service Providers (ASP).

The 24X7 On Road Assistance Program shall be automatically available to your vehicle for the duration of Warranty period. The program shall also be available, if you avail the same post warranty.

**Response Time \*\* for the On Road Assistance Program**

<b>Within City Limits</b>	<b>60 minutes</b>
<b>On State or National Highways</b>	<b>90 minutes</b>
<b>Ghat Roads and other places</b>	<b>120 minutes</b>

\*\* (The response time will depend on the location, terrain, traffic density and the time of the day.)

**Standard Procedure when Calling for on Road Assistance in case of a Breakdown:**

- Dial the toll free help line number – **1800 209 8282**
- Identify your vehicle with the Vehicle chassis number that is available in the Owner's Manual.
- Explain your exact location with landmarks and tell us about the problem you face with the vehicle.
- Park your vehicle on the edge of the road, open the bonnet and put on the hazard warning signal.

- Place the advance warning triangle supplied with the vehicle approx. 3 m from the vehicle in the direction of on-coming traffic.



## EMERGENCY AND BREAKDOWN ASSISTANCE

---

### Coverage Under 24 X 7 on Road Assistance Program

1. The **24x7 On Road Assistance Program** Service covers the following services on your vehicle during warranty period.

- Wheel change through spare wheel.
- Arrangement of fuel. (Fuel cost will be chargeable at actual cost).
- Re-opening the vehicle in cases of key lock out.
- Rectification of electrical problems related to battery, fuses etc.
- On spot repairs for complaints repairable at site.
- Vehicle to vehicle towing or winching & towing for non-accident cases up to the nearest TATA MOTORS authorized workshop. Towing charges at actual cost beyond the same to be paid to the ASP in cash. (Any ferry or toll charges levied in relation to the vehicle being towed to be paid by the customers in actuals in cash).

For accident cases, towing charges to be

borne by the customer.

2. The **24x7 On Road Assistance Program** coverage on availing the 24X7 policy, post warranty is up to maximum of 6 instance of assistance in one year for both the plans- Basic and Premium. In the premium plan, this includes 2 instances of towing up to the nearest TATA MOTORS authorized workshop.

### Exclusions

#### 24 X 7 On Road Assistance Program does not apply to

- Cost of parts consumables and labour for such repairs not covered under warranty\*. These charges are to be settled with ASP in cash.
- Toll or ferry charges paid by ASP in reaching to the breakdown site to be settled with ASP in actuals in cash.
- Cases involving accident, fire, theft, vandalism, riots, lightening, earthquake, windstorm, hail, tsunami, unusual weather conditions, other acts of God, flood, etc.
- Vehicles that are unattended, un-reg-

istered, impounded or abandoned.

- Breakdown/defects caused by misuse, abuse, negligence, alterations or modifications made to the vehicle.
- Lack of maintenance as per the maintenance schedule as detailed in the owner's manual.
- Cases involving racing, rallies, vehicle testing or practice for such events.

## **EMERGENCY AND BREAKDOWN ASSISTANCE**

### **Disclaimer**

- The Service is not available in Lakshadweep.

\*\*The reach time is indicative & the actual reach time will be conveyed by the call center at the time of breakdown call.

- The reach time can vary depending on the traffic density & time of the day.
- The reach time indicated does not account for delays due to but not limited to acts of God, laws, rules & regulations for time being in force, orders of statutory or Govt. authorities, industrial disputes, inclement weather, heavy down pour, floods, storms, natural calamities, road blocks due to accidents, general strife and law & order conditions viz. fire, arson, riots, strikes, terrorist attacks, war etc.

<sup>^</sup>On spot repairs at breakdown site shall depend on nature of complaints & will be as per the discretion of the ASP.

\*The decision for free of charge repairs will be as per the warranty policy & procedures of TATA MOTORS PASSENGER VEHICLE LIMITED and as

per the interpretation of the same by ASP. You will be duly informed by the ASP & call center for the change applicable if any.

- All charges wherever applicable need to be settled directly with the ASP.

### **Exclusion of Liabilities**

- It is understood that TATA MOTORS shall be under no liability whatsoever in respect of any loss or damage arising directly or indirectly out of any delay in or non-delivery of, defect/deficiency in service/parts provided by ASP.
- In case vehicle cannot be repaired on-site, customers are advised to use the towing facility for taking their vehicle to the nearest TATA MOTORS authorized workshop only. In no condition will the vehicle be towed to any unauthorized workshop. TATA MOTORS will not be responsible for any repairs carried out in such unauthorized workshop.
- Customer are advised to take acknowledgment from the ASP for the list of accessories/extra fittings and other belongings in the vehicle as well as the current condition related to dents/scratches breakages of parts/fitments of the vehicle at the time of ASP taking possession of the vehicle & to verify these items when delivery is

## **EMERGENCY AND BREAKDOWN ASSISTANCE**

---

taken back by them, Claim for loss of or damage to items, if any should be taken up with ASP directly. TATA MOTORS shall not be responsible for any such claims, damages/loss or any deficiency of service of the ASP.

- Vehicles will be handled, repaired & towed as per the customer's risk & TATA MOTORS shall not be liable for any damages / claims as a result of the same.
- Services entitled to the customers can be refused or cancelled on account of abusive behavior, fraudulent representation, malicious intent and refusal to pay the charges for any charges related services and spare parts during service or on previous occasion on part of the customer.
- On site repairs may be temporary in nature. The completion of repairs does not certify the road worthiness of the vehicle. The customer is advised to ensure temporary repairs carried out on-site is followed by permanent repairs at a TATA MOTORS Authorized Work-

shop at the earliest. Terms and conditions and service coverage, exclusions etc. are subject to change without notice

### MAINTENANCE AND SERVICE

Periodic maintenance is essential for ensuring long trouble free performance.

Have your vehicle serviced regularly from TATA MOTORS Authorized Service Centre.

There is a large network of TATA MOTORS Authorized Service Centre to help you with their professional servicing expertise. Scheduled maintenance information is provided which makes tracking routine service easy.

The following checks can be carried out between the recommended scheduled maintenance services. Take help of our authorized service center for assistance.

- Engine oil level
- Engine coolant level
- Brake/Clutch fluid level
- Washer fluid level checking & topping up
- Power steering fluid level
- Battery electrolyte level
- Tyre inflation pressure including spare wheel

#### *(i)* NOTE

*Refer “Opening and Closing” section for engine bonnet opening.*

#### WARNING

- Be careful not to touch a hot engine, exhaust manifold and pipes, muffler, radiator and water hoses.
- Do not work on a vehicle with the engine running in an enclosed space, unless you are sure of enough ventilation.
- Keep all open flames and other burning material (such as cigarettes) away from the battery and all fuel related parts.

If you need to do any work inside the engine compartment,

- Switch off the ignition.
- Never reach into the area where there is a risk of danger from moving components, such as the fan rotation area.
- Keep clothing away from moving parts.

## MAINTENANCE AND SERVICES

### ENGINE COMPARTMENT



1. Brake fluid reservoir
2. Windshield washer container
3. Coolant auxiliary tank
4. Power Steering Oil Reservoir
5. Dip stick engine oil
6. Engine oil filling cap
7. Fuse and relay box (Below Air intake)
8. Battery

### Oil / Fluid Level

#### Engine Oil Level Checking


Warm up the engine to normal operating temperature.

Turn it 'OFF' and wait for 5 minutes for the oil to return to the oil pan. Be sure the vehicle is on a level surface.

Take out the dipstick, wipe it clean, and reinsert it fully. Pull it out again and examine the oil level. It should be between 'MIN' and 'MAX' level. If not, top up with recommended engine oil.

#### *(i)* NOTE

*The oil consumption depends upon the driving style and the conditions under which the vehicle is used.*



Engine oil dipstick

#### *(i)* NOTE

- Do not remove the filler cap when the engine is running.*
- Do not add oil above the MAX. mark. Oil level above the MAX. mark may cause engine damage.*

***For location of Engine oil filling cap and dip stick, please refer Engine Compartment.***

#### Engine Oil Quality Monitoring Indicator

Your vehicle is equipped with a feature in the engine management system which will monitor the engine oil quality throughout the lifetime of the oil in the engine. This will ensure that an oil change is requested only when really necessary. Once the oil quality reaches a threshold, the engine management system will ask for oil change by lighting the above lamp. This lamp will be blinking for oil change request.



Depending on your driving conditions, the oil quality may get deteriorated sooner. For example, if you are driving predominantly in highway conditions without straining the engine excessively, the oil lamp indicating oil change may appear later than expected. Similarly, if you drive continuously and for a long time in city at low speeds with frequent cold starts and short journeys, the engine management system may prompt you to change the oil sooner than had the car been used mainly in highways.

## MAINTENANCE AND SERVICES

### *(i)* NOTE

- *Under no circumstances oil change intervals should exceed 15,000 km or 12 Months, whichever occurs earlier.*

This behavior is absolutely normal, the oil change is intended to keep your engine at peak efficiency, and replacing used oil with fresh oil is normal maintenance and not a malfunction.

As soon as this lamp is blinking, the oil should be changed as per oil change / servicing procedure. Please contact nearest TATA authorized service center immediately.

Once the oil is changed as per the normal oil change / servicing procedure, the oil quality should be reset using TATA MOTORS diagnostic tool. The vehicle should never be run again after an oil change without resetting oil quality using TATA MOTORS diagnostic tool.



If the vehicle is continuously driven ignor-

ing this lamp, MIL, in addition to the above lamp, will be turned ON. Depending on the distance driven without oil change and oil quality reset, the engine will go into a soft or strong performance reduction mode.

### *(i)* NOTE

*The appearance of this blinking warning light or symbol is not related to the amount of oil in the engine, so if the light or symbol comes ON and blinking, never add / top up engine oil but contact the nearest TATA authorized service center to have oil change and reset.*

### Brake/clutch Fluid Level



Pull the notch and release the top cover.



Remove the cap and check the level. Top up if required.

### *(i)* NOTE

- *Do not allow brake fluid to make contact with the skin or eyes.*
- *Do not allow brake fluid to splash or spill on the painted surface as it will damage the paint. In case of spillage, wipe it off immediately.*

**For location of Brake/Clutch Fluid Container and filling cap, please refer Engine Compartment.**

## Engine Coolant Level



Check whether the coolant level is between the 'MIN' and 'MAX' marks provided on the coolant reservoir.

When the coolant level is low, top up with recommended coolant up to 'MAX' level.

### *(i)* NOTE

*In case of emergency, a large amount of water without engine coolant may be added in order to reach a vehicle service location.*

Whenever coolant has been added, the

coolant level in the coolant reservoir should be checked few times after driving the vehicle to confirm correct level.

**For location of Engine coolant container and filler cap, please refer Engine Compartment.**

### *(i)* NOTE

*Topping of the coolant should be done in the auxiliary tank only.*

Make sure that only TATA MOTORS recommended coolant is used. Mixing of different coolants may harm your engine's cooling system and its components. Do not add extra inhibitors or additives to the coolant. These can be harmful and compromise the corrosion protection of the engine coolant.

### *⚠* WARNING

- The engine cooling system is pressurized, particularly when the engine is warm. When opening the cap, you could get burnt by hot coolant spraying out. There is a risk

## MAINTENANCE AND SERVICES

of injury.

- Let the engine cool down before opening the cap. Wear eye and hand protection when opening the cap. Open the cap slowly half a turn to allow pressure to escape.

### Power Steering Fluid Level



The level of the power steering fluid should be between the MIN. and MAX. mark on the side of the power steering fluid container. If the level falls below the MIN. mark, add recommended fluid.

In case of leakage or hard steering, please contact the nearest Authorized Service outlet.

#### ⚠ WARNING

- Do not start the engine without oil in the power steering system.
- Do not allow dirt into power steering fluid reservoir during refilling or top up.

#### ⓘ NOTE

- Holding steering wheel at lock position (i.e >5sec) can damage /fail the power steering pump operation.*
- Do not run the vehicle with dry power steering pump. Ensure the power steering fluid is available in the reservoir.*

#### ⓘ NOTE

*For Oil/fluid specification and Quantity, please refer 'Maintenance' section.*

***For location of Power steering fluid***

**container, please refer Engine Compartment section.**

### Windshield Washer Fluid Level

Check that there is washer fluid in the tank. Refill it if necessary. Use a good quality windshield washer fluid, diluted with water as necessary.



#### ⓘ NOTE

- Do not use detergent or any other additive in the windshield washer reservoir. This can severely impair visibility when sprayed on the wind*

*shield, and can also damage your vehicle's paint.*

- *Do not operate washer motor with no fluid in washer tank, washer motor will be damaged.*

**For location of Windshield Washer Container and filling cap, please refer respective Engine Compartment.**

### Battery




- To access battery terminals, remove the cover by removing the 5 knobs.
- Examine the battery for electrolyte

level against the marking on the battery outer case.

- Examine the battery terminals for corrosion (a white or yellowish powder). To remove it, wash the terminals with a solution of baking soda. It will bubble up and turn brown.
- When this stops, wash it off with plain water. Dry off the battery with a cloth or paper towel.
- Apply petroleum jelly to the terminals to prevent further corrosion.
- Use a proper wrench to loosen and remove cables from the terminals.
- Always disconnect the negative (-ve) cable first and reconnect it last.
- If your vehicle is equipped with Battery Sensor, then disconnect only the Sensor Output Cable. Do not remove the Sensor, Sensor connector completely as this will result into Sensor function loss temporarily. Sensor functionality will be restored when the Vehicle is parked for 3-4 hours without any operation.

- Clean the battery terminals with a terminal cleaning tool or wire brush.
- Reconnect and tighten the cables, coat the terminals with petroleum jelly.
- Make sure that the battery is securely mounted.
- If you need to connect the battery to a charger, disconnect both cables to prevent damage to the vehicle's electrical system.
- If your vehicle is equipped with Battery Sensor, connect the jump start leads on output terminal of Battery Sensor. Do not connect the jump start leads on Sensor surface or Battery terminal. This will result of function loss of Battery sensor.
- Refer the below Battery Sensor image for do's and don'ts.

## MAINTENANCE AND SERVICES



Battery

**For location of battery, please refer image of the respective Engine Compartment.**

### ① NOTE

Use only authorized Battery recommended by TATA Motors. Use of any other unauthorized Battery will result into Intelligent Alternator Control (IAC) function deterioration.

### ① NOTE

**Authorized Battery:**  
78 Ah- Enhanced flooded battery to be replaced with enhanced flooded battery (78 Ah) of the respective supplier only.

### ① NOTE

- During normal operation, the battery generates gas which is explosive in nature. A spark or open flame can cause the battery to explode causing very serious injuries.
- Keep all sparks, open flames and smoking materials away from the battery.
- The battery contains sulphuric acid (electrolyte) which is poisonous and highly corrosive in nature. Getting electrolyte in your eyes or on the skin can cause severe burns. Wear protective clothing and a face shield or have a skilled technician to do the battery maintenance.

## TYRES



1	Under inflation	Excessive side tread wear
2	Correct tyre pressure	Uniform wear
3	Over inflation	Excessive center tread wear

## Inflation

Check for inflation and condition of your vehicle tyres periodically.

Check the pressure in the tyres when they are cold.

Keeping the tyres properly inflated gives you the best combination of riding comfort, handling, tyre life and better fuel efficiency.

Over inflation of tyres makes the vehicle ride bumpy and harsh. Tyres are more prone to uneven wear and damage from road hazards.

Under inflated tyres reduce your comfort in vehicle handling and are prone to failures due to high temperature. They also cause uneven wear and more fuel consumption.

### *(i)* NOTE

*Every time you check inflation pressure, you should also examine tyres for uneven wear, damage and trapping of foreign objects in the treads and wear.*

## Recommended Tyre Pressure in Cold Condition (laden / Unladen)

Tyre Size	Front	Rear
235/70 R16	33 psi / 2.27 bar	33 psi / 2.27 bar
235/60 R18	33 psi / 2.27 bar	33 psi / 2.27 bar
235/65 R17	33 psi / 2.27 bar	33 psi / 2.27 bar

### *(i)* NOTE

*In case of Air filling in hot tyre condition, increase tyre pressure by 3 psi over specified cold pressures.*

## Tyre Pressure Sticker Location



On B pillar near driver seat


## MAINTENANCE AND SERVICES

### Tyre Rotation


To increase tyre life rotate the tyre at specified intervals or earlier depending on the operation of vehicle.

The illustrations shows how to rotate tyres when normal or temporary spare wheel is fitted.

### For steel wheel rims with spare steel wheel rim



### For alloy wheel rims with spare wheel or steel wheel rim (if available)



### Wheel Alignment

Incorrect wheel alignment causes excessive and uneven tyre wear. Check wheel alignment at specified intervals.

### Wheel Balancing

Wheels of your vehicle are balanced for better ride comfort and longer tyre life. Balancing needs to be done whenever tyre is removed from rim.

### WARNING

If the vehicle vibrates abnormally on a smooth road, have the wheel balanced done immediately.

### NOTE

- While driving in snow, it is advisable to use the snow chain on roads. Follow assembly and safety instruction provided by the snow chain manufacturers.
- Please refer service schedule for wheel alignment.

### Special Care for Tubeless Tyres

- While removing tyre from wheel rim and mounting it back on wheel rim, take precautions not to damage tyre bead. Use tyre removal and assembly machines. Damage or cut on tyre bead may cause gradual loss of air and deflation of tyre.
- Do not scratch inside of tubeless tyre with metallic or sharp object. Tubeless tyres are coated with impermeable layer of rubber from inside which holds the air inside the tyre. Removal of this layer due to scratching may cause gradual loss of air and deflation.
- If wheel rim gets damaged in service, get the wheel rim repaired/ replaced immediately. Running the vehicle with damaged rim may cause deflation of tyre and subsequent dislodging of tyre from rim.
- Maintain recommended inflation pressure. Over-inflation, in particular, may cause puncture or bursting of tyre.

### (i) NOTE

- *Life and wear pattern of tyres depends on various parameters like tyre pressure, wheel alignment, wheel balancing, tyre rotation, etc. It also largely depends on vehicle speed, load carried, usage, driving habits, road conditions, tyre quality, etc. In case fault is suspected to be due to poor quality of tyres, the same may be taken up with concerned tyre manufacturer.*
- *For steel rim, Red dot of tyre to be matched with blue dot of rim while re-fitment.*
- *For alloy rim, Yellow dot of tyre to be matched with valve of rim while re-fitment*

### REMOTE KEY BATTERY REPLACE-MENT (for Flip key)

Remote control key contains a battery, which is housed under the cover.

If red LED on remote flashes for 5 times after operating any button on remote. It is recommended to replace battery at a TATA MOTORS Authorized Service Centre.

You should, however, proceed as follows if you wish to replace the discharged battery yourself:

1. Open the key blade.
2. Press off the battery cover with your thumb or using a flat screwdriver at the points of the arrows.
3. Remove the discharged battery from the key by pressing the battery downwards at the point of the arrow.

## MAINTENANCE AND SERVICES



4. Insert the new battery.



5. Ensure that the "+" symbol on the bat-

tery is facing upwards. The correct polarity is shown on the battery cover.

6. Position the battery cover on the key and press on it until it is heard to lock in place.

### SMART KEY BATTERY REPLACEMENT (for PEPS variant)

#### Procedure:

1. Open rear side of key (battery cover).



2. Replace with new battery in the smart key battery slot with proper polarity of battery.
3. Close the battery cover.
4. Ensure that the key cover is intact properly.

### *(i)* NOTE


*Use CR 2032 battery only.*

### *(i)* NOTE

*An inappropriately disposed battery can be harmful to the environment and human health. Dispose the battery according to your local law(s) and regulation.*

## ON BOARD DIAGNOSTIC (OBD II) SYSTEM

Diagnostic connector is located on RH side below the steering wheel.



On board Diagnostics or OBD, is an automotive term referring to a vehicle's self-diagnostic and reporting capability. The OBD system allows continuous diagnosis of the components of the vehicle correlated with emissions. This system warns the driver, by turning "ON" the Malfunction Indication lamp (MIL) on the instrument cluster, when a fault causes emission levels to increase.

The OBD system also has a diagnostic connector that can be interfaced with appropriate diagnostic tools, which makes it possible to read the fault codes stored in the Electronic Control Unit, together with a series of specific parameters for Engine operation and Diagnosis. This check can also be carried out by the traffic police.

## MAINTENANCE AND SERVICES

### DIESEL PARTICULATE FILTER (DPF)

Your vehicle is equipped with a Diesel Particulate Filter (DPF). DPF is a mechanical filter that physically traps particulate matter from diesel engine exhaust gas.



DPF traps the particulate matter in the following way:

- Filtration** - Particulates / soot are collected in the inlet channel of the filter.
- Regeneration** - When the filter channels are filled up with soot, they are cleaned automatically by the engine management system. This process is known as DPF Regeneration and this will happen during normal running of the vehicle.

DPF equipped in vehicle normally regenerates automatically which is controlled by engine management system.

In certain specific driving conditions, DPF regeneration may not happen automatically as the desired temperatures required to regenerate soot may not be achievable

due to specific driving conditions. This includes prolonged driving at low vehicle speeds for considerable amount of time (driving in heavy city traffic), prolonged running of the engine in idle conditions etc. In such cases, a warning lamp as indicated above will be illuminated in the instrument cluster indicating that soot regeneration is insufficient.

This warning lamp switches ON constantly to indicate that the DPF needs to be regenerated. This lamp does not indicate any malfunction.

The warning lamp remains OFF during normal vehicle behavior and lights up only when driving condition requires the driver to be notified. When this lamp is ON, keep the car running ideally at 3<sup>rd</sup> gear, 60km/hr with engine speed over 2000 rpm until regeneration is completed and warning lamp goes OFF. The process normally takes about 20 minutes.

#### NOTE

*Do not shut down engine till the warning lamp goes OFF.*

If DPF regeneration process requested above is not followed for a long distance and the vehicle is driven with warning lamp ON, it can cause MIL to be turned ON.



Once MIL is ON, please contact nearest TATA authorized service center.

Service should connect the TATA MOTORS diagnostic tool and conduct DPF service regeneration as indicated in the diagnostic tool.

Insufficient DPF regeneration resulting in the above lamps can also happen if the vehicle is driven with adulterated diesel.

### DPF Warning Lamp

The lamp blinks constantly to indicate that the DPF needs to eliminate the trapped pollutants (particulate matter) through the regeneration process, it therefore does not indicate a malfunction. The lamp remains off during the entire DPF regeneration and it lamps up only when driving conditions require the driver to be notified. To switch off the lamp, keep the car running until regeneration is complete (ideally at 3<sup>rd</sup> gear, 60 kmph with engine speed over 2000 rpm). The process normally takes about 20 minutes.

**Note:** Failure to obey the correct procedure for long distance when the DPF lamp comes ON can cause the warning lamp (MIL) to come ON. In that case, please contact nearest TATA authorized service center to restore correct DPF operation.

#### **WARNING**

Avoid parking of vehicle over inflammable materials, such as dry leaves; grass



etc. as exhaust system is hot enough to initiate fire.

#### **WARNING**

- Ensure exhaust system is not blocked and is free from obstruction.
- Blockages in the exhaust can create backpressure, low top speed, poor pick up, black smoke, carbon build up and low mileage and can affect power output of the engine and the emission levels.

#### **WARNING**

The maximum sulphur content of the diesel fuel must not exceed 0.001% (10 parts per million). Failure to comply with the standards may damage engine components and the exhaust after-treatment system.

### EXHAUST AFTER TREATMENT SYSTEM

Exhaust after treatment consists of below components:

1. Diesel Oxidation Catalyst (DOC)
2. Diesel Particulate Filter (DPF)
3. Selective Catalyst Reduction (SCR)
4. Various Sensors and Actuators.

The exhaust gas coming from the engine first passes through the DOC and then through DPF.

DPF is a filter, which filters carbon soot in the exhaust gas. DOC and DPF contains precious metals which converts hydrocarbons, carbon monoxide etc. in the exhaust gas to harmless constituents.

Additionally DPF also removes most of the carbon soot particles in the exhaust gas. The collected carbon soot in the DPF is regenerated to clean the filter.

In order to reduce the NOx levels even further, SCR system is used. In SCR system, DEF is injected in the exhaust stream. With the help of injected ammonia in the DEF, NOx is converted into harmless con-

## MAINTENANCE AND SERVICES

---

stituents.

### NOTE

*In order to control exhaust emissions, this vehicle is equipped with SCR system through which DEF (Diesel Exhaust Fluid) continuously flows. It is normal to have a noise from the SCR system during vehicle operation or for about 20 to 30 seconds after engine is switched off.*

### REGENERATION PROCESS

DPF is a mechanical filter that physically traps particulate matter from diesel engine exhaust gas.

DPF traps the particulate matter in the following way:

- Filtration – Particulates / soot are collected in the inlet channel of the filter.
- Regeneration – When the filter channels are filled up with soot, they are cleaned automatically by the engine management system. This process is known as DPF Regeneration and this will happen during normal running of the vehicle.

In certain specific driving conditions, DPF regeneration may not happen automatically as the desired temperatures required to regenerate soot may not be achievable due to specific driving conditions. This may happen in prolonged driving at low vehicle speeds for considerable amount of time (driving in heavy city traffic), prolonged running of the engine in idle conditions, use of adulterated diesel etc.

In such cases, a DPF warning lamp will be illuminated indicating that soot regeneration is insufficient.

### DIESEL EXHAUST FLUID (DEF)

The vehicle is equipped with DEF injection system and Selective Catalytic Reduction (SCR) to meet emission standards.



#### DEF Storage

DEF is a very stable product with a long shelf life. Stored at temperatures LOWER than 32°C, it has a shelf life of at least one year.

#### *(i)* NOTE

*DEF freezes at temperatures lower than -11°C.*

#### *(i)* NOTE

*When working with DEF, it is important to know that:*

- Any containers or parts that comes into contact with DEF must be DEF compatible (plastic or stainless steel). Copper, brass, aluminum, iron or non-stainless steel should be*

*avoid-ed as they are subject to corrosion by DEF.*

- During filling, if DEF overflows / is spilled, kindly ensure it is cleaned / wiped up completely by wet cloth & then by dry cloth also.*

#### Adding DEF

##### Preliminary Conditions

Consumption of the additive DEF depends on the condition of vehicle use and is indicated on the instrument cluster.

DEF freezes at temperatures lower than -11°C. If the car stands for a long time at this temperature refilling could be difficult. For this reason, it is advised to park the vehicle in a garage and/or heated environment and wait for the DEF to return to liquid state before topping up.

Proceed as follows:

- Park the car on flat ground and stop the engine by placing the ignition in the OFF position.*
- DEF filler is located in the tailgate compartment below the tool kit tray. Open*


the tailgate and remove the tool kit tray and remove the cap from the DEF filler.

#### **⚠ WARNING**

Never fill DEF or diesel fuel into the wrong filling ports. This may result serious damage to Engine, Fuel system and Emission system components. In case of wrongly filled do not start the engine, contact TATA Motors Authorised Service Centre.

## MAINTENANCE AND SERVICES

### DEF Filler Tank



1. Urea cap without tether
2. Spill out collecting cup

### DEF Refilling Procedure

Conditions for refilling:

Vehicle should be parked on a flat road surface.

Switch OFF the Engine and ignition should be in OFF position.

#### NOTE

After DEF refilling through Nozzle OR container, in case of DEF is spill out during refilling. Spill out DEF need to be swipe out with help of cotton or same mean.

### DEF Quantity Refilling

It is recommended that DEF tank is filled to full capacity.

In order to recognise the re-filling, minimum 8L of DEF should be filled

#### NOTE

Do not switch on the key during refill operation if refill is not done in one attempt.

Park the vehicle in plain surface in no load condition and Switch-OFF the ignition, wait for 6 minutes.

After refilling DEF in ignition OFF condition, wait for 6 minutes.

After 6 minutes, switch ignition ON. Wait for DEF level to get updated on instrument

cluster. Start the vehicle. Ensure that DEF will be filled at room temperature.

### Precautions while Refilling DEF

#### Refilling with Nozzles

You can fill up at any DEF Distributor/Retailer.

Proceed as follows:

- Insert the DEF nozzle in the filler, start refilling and stop refilling at the first shut-off (the shut-off indicates that the DEF tank is full). Do not proceed with the refilling, to prevent spillage of DEF.
- Extract the nozzle.

#### NOTE

It is recommended to use a portable magnet adapter on DEF Nozzle while filling, otherwise dispenser filling is not possible.



*Portable Magnet Adapter*

### Refilling with Containers

#### Procedure for filling DEF in DEF tank

- Ensure ignition is in OFF position (remove key from barrel, if provided)
- Ensure vehicle is parked in plain surface in no load condition (vehicle should be empty without passengers or luggage)
- Fill Wait for 6 minutes after ignition off.
- Fill TATA MOTORS PASSENGER VEHICLE LIMITED authorized DEF (minimum 8 liters)
- Wait for 6 minutes after filling DEF.
- Turn ON the ignition and wait till DEF level gets updated in instrument cluster.
- Start the vehicle.

### Low DEF Level Warning Messages

These messages will be indicated when DEF level is low. This can happen when vehicle runs without filling DEF in spite of message to fill DEF.

- First warning message will be indicated at approximately in between 1500 – 2400 km before emptying of DEF tank at the current DEF consumption rate. “DEF LEVEL LOW, REFILL SOON” message will be indicated at this warning level.



- If the vehicle runs without filling DEF,

next warning level will be indicated at approximately 600 km before emptying of DEF tank at current DEF consumption rate. “ENGINE STOPS IN 600 KM” message will be indicated at this warning level. This message will continue till DEF tank becomes empty with corresponding distance gradually reducing to 0 km.



- On further driving the vehicle without filling DEF, message “ENGINE WILL NOT RESTART IN NEXT KEY ON” will appear.

## MAINTENANCE AND SERVICES



- Message "ENGINE STOP TANK EMPTY" will be displayed once DEF tank is empty.

Once the engine is stopped with this message, it will not be possible to restart the engine without filling DEF.

### NOTE

*Please refer to DEF filling procedure for filling DEF.*

### DEF Level Messages in case of SCR System Fault

These messages will be indicated when there is any problem in the SCR system and SCR system fault is displayed.

- Depending on the distance, the vehicle

can run before emptying of DEF tank at the current DEF consumption rate. "SCR SYSTEM FAULT, ENGINE STOPS IN XXX KM" message will be indicated.



If the vehicle is run without rectifying the SCR system (through TATA MOTORS service center), warning message will continue with corresponding distance gradually reducing to 0 km.

After this, engine will not start in the next ignition cycle. The vehicle has to be brought to TATA MOTORS service center for rectification.

## DEF Level Messages in case of Poor Quality DEF

- In case of use of poor quality of DEF, message “DEF QUALITY LOW, ENGINE STOPS IN XXX KM” will appear. In such cases, currently filled DEF has to be drained completely and proper good quality DEF needs to be filled until DEF tank is full.

- *Messages may vary slightly depending on the vehicle variant.*



### *NOTE*

- *Please refer to DEF filling procedure for filling DEF.*

## MAINTENANCE AND SERVICES

---

### SERVICE INSTRUCTIONS

The **TATA SAFARI** has been manufactured to give you economical and trouble free performance. To achieve this, please follow the instructions as stated.

Your vehicle is entitled to three free services (labour only). The free service coupons are attached to the sales invoice. Please present these coupons to the servicing dealer while availing free services.

**1st free service** - At 1,000 - 2,000 kms. OR 2 months, whichever is earlier.

**2nd free service** - At 7,000 - 8,000 kms. OR 6 months, whichever is earlier.

**3rd free service** - At 14,500 - 15,500 kms. OR 12 months, whichever is earlier.

All services other than free services are chargeable.

Servicing of the vehicle can be done at any TATA MOTORS Authorised Dealer Workshop or TATA MOTORS Authorised Service Centre (TASC).

Warranty claims can be settled by any TATA MOTORS Authorised Dealer Workshop or TATA MOTORS Authorised Service Centre (TASC).

**SERVICE SCHEDULE**

# - Kms or Months whichever occurs earlier

Operation	Kms	Pdi	1.5k	7.5k	15k	22.5k	30k	37.5k	45k	52.5k	60k	67.5k	75k	82.5k	90k	97.5k	105k	112.5k	120k	127.5k	135k	142.5k	150k
	Months	0	2	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120
<b>GENERAL</b>																							
Wash the vehicle & Clean Condenser Fins.	Every Service	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Check & Top up Fluids (If required): Transaxle Oil, Diesel Exhaust Fluid (DEF)*, Coolant, Brake Fluid, Battery Electrolyte, Wind Screen washer fluid.	Every Service	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Check Fuel Lines for Leakages.	Every Service	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Check and Capture all DTC's Clear all faults and Erase the Codes.	Every Service	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
							•				•				•				•				•

## MAINTENANCE AND SERVICES

Operation	Kms	Pdi	1.5k	7.5k	15k	22.5k	30k	37.5k	45k	42.5k	60k	67.5k	75k	82.5k	90k	97.5k	105k	112.5k	120k	127.5k	135k	142.5k	150k
	Months	0	2	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120
Check & Replace if found damaged -Exhaust hanger.	30K/24M																						
Check all door latch & striker operations, Adjust If required and apply grease if required.	15K/12M				•		•	•		•		•	•	•	•	•	•	•	•	•	•	•	•
Check Engine mount, Rubber Boots, Rubber seat, Dust cover & Bushes for damage & replace if required (Sus-pension).	7.5K/6M		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Check for all bolts & nuts (Tighten).	7.5K/6M		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
<b>ENGINE (Diesel)</b>																							
Change engine oil and Oil filter.	15K/12M				•		•		•		•		•		•		•		•		•		•

## MAINTENANCE AND SERVICES

Operation	Kms		Pdi	1.5k	7.5k	15k	22.5k	30k	37.5k	45k	52.5k	60k	67.5k	75k	82.5k	90k	97.5k	105k	112.5k	120k	127.5k	135k	142.5k	150k		
	Months	0	2	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120			
Drain water from Fuel Filter Bowl.	7.5K/ 6M			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
Replace fuel filter cartridge.	15K/ 12M				•		•		•		•		•		•		•		•		•		•		•	
Check AC & alternator belt condition visually, replace if found damage.	15K/ 12M				•		•		•		•		•		•		•		•		•		•		•	
Change coolant.	# 60K/ 36M										•									•						
Replace air filter element (more frequently for vehicle operating in severe condition).	# 30K/ 36M						•				•				•				•						•	
Replace timing drive kit (Timing belt, Auto tensioner and Idler).	# 150K/ 60M																									•
Replace FEAD kit (Belt, idler 1&2, Auto tensioner)	90K/ 48M															•										

## MAINTENANCE AND SERVICES

Operation	Kms	Pdi	1.5k	7.5k	15k	22.5k	30k	37.5k	45k	52.5k	60k	67.5k	75k	82.5k	90k	97.5k	105k	112.5k	120k	127.5k	135k	142.5k	150k
	Months	0	2	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120
<b>TRANSAXLE</b>																							
Check oil level and top up if necessary - Manual Transmission.	15K / 12M				•		•	•		•		•	•	•	•	•	•	•	•	•	•	•	•
Automatic Transmission fluid																							
<b>STEERING</b>																							
Check oil level and top up if necessary.	15K/ 12M				•		•	•		•		•	•	•	•	•	•	•	•	•	•	•	•
Replace Power steering Oil.	# 105K/ 36M																•						
<b>BRAKES</b>																							
Check front brake pads & rear brake linings. Replace if necessary.	15K/ 12M				•		•	•		•		•	•	•	•	•	•	•	•	•	•	•	•
Replace brake fluid. Check brake system components for Leakages.	# 45K/ 24M								•						•					•			

## MAINTENANCE AND SERVICES

Operation	Kms		Pdi	1.5k	7.5k	15k	22.5k	30k	37.5k	45k	52.5k	60k	67.5k	75k	82.5k	90k	97.5k	105k	112.5k	120k	127.5k	135k	142.5k	150k
	Months	0	2	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120	
Inspect & if necessary adjust hand-brake setting.	15K/12M				•		•		•		•		•		•		•		•		•		•	
<b>WHEELS &amp; TYRES</b>																								
Check & Adjust Wheel alignment.	# 15K/12M				•		•		•		•		•		•		•		•		•		•	
Check for Tyre pressure, condition & rotate.	# 7.5K/12M				•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
<b>ELECTRICAL</b>																								
Check specific gravity of battery electrolyte.	7.5K/6M				•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Check headlamp focussing.	15K/12M				•		•		•		•		•		•		•		•		•		•	
<b>A.C. SYSTEM</b>																								
Clean filter and check Air-conditioning / HVAC system for satisfactory per	Every Service	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•

## MAINTENANCE AND SERVICES

Operation	Kms	Pdi	1.5k	7.5k	15k	22.5k	30k	37.5k	45k	52.5k	60k	67.5k	75k	82.5k	90k	97.5k	105k	112.5k	120k	127.5k	135k	142.5k	150k
	Months	0	2	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120
formance.																							
Replace Pollen Filter.	15K/12M				•		•		•		•		•		•		•		•		•		•
Replace Combi PM2.5 filter	15K/12M				•		•		•		•		•		•		•		•		•		•
Vacuum Dust Sensor	15K/12M				•		•		•		•		•		•		•		•		•		•
<b>SUNROOF (if available)</b>																							
Check and clean the guide rails and drain holes.	Every Service	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Clean the guide rails and mechanism and apply grease.	7.5K/6M			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•

\* DEF is a consumable item, refill or replacement is not based on service intervals. The consumption of DEF can vary depending on driving style, and road and weather conditions

\*\*— For severe off-road usage, above checks to be done at every 5,000 km or after every severe usage event.

**Additional Maintenance Schedule under Severe Driving Conditions**

Sr. No.	Operation	Frequency	Condition			
			A	B	C	D
1	Engine oil and oil filter	Change every 7500 km or 6 months or whenever oil quantity lamp glows.	•	•	•	•
2	Air filter element	Change at every 15,000 km or 18 months whichever is earlier.		•	•	

**A - Driving in conditions such as Patrolling, Pickup Van, Vehicle Towing, with Trailer Towing**

**B - Driving on Dusty / Sandy roads**

**C - More than 50% (in terms of km) driving in heavy city traffic**

**D - Frequently operating in mountainous area**

**(i) NOTE**

*In case of emergency, a large amount of water without engine coolant may be added in order to reach a vehicle service location.*

## MAINTENANCE AND SERVICES

---

### VEHICLE PARKING FOR LONG DURATION

#### (Non - Use maintenance)

If you want to park your vehicle at one place for long duration, following care is to be taken:

1. Park the vehicle in covered, dry and if possible well-ventilated premises. Engage a gear.
2. Remove the battery terminal cables (first remove the cable from the negative terminal). Ensure that battery is fully charged.
3. Block the wheel or engage in the gear mode.
4. Clean and protect the painted parts using protective wax.
5. Clean and protect the shiny metal parts using commercially available special compounds.
6. Sprinkle talcum powder on the rubber windscreens wiper and lift them off the glass.
7. Wiper blade lifting sequence during cleaning / replacing, first lift front pas-  
senger side wiper blade, then driver side blade.
8. Slightly open the windows.
9. Cover the vehicle with a cloth or perforated plastic sheet. Do not use sheets of imperforated plastic as they do not allow moisture on the vehicle body to evaporate.
10. Inflate the tyres to 0.5 bar above the normal specified pressure and check it at regular intervals.
11. Check the battery charge every six weeks.
12. Do not drain the engine cooling system.

**FUEL SPECIFICATION****Fuel (Diesel)**

Normal grade BS VI compliant diesel conforming to IS1460:2017 or equivalent is recommended to be used as fuel.

Do not use premium diesel available in the market like extra premium / Turbojet etc.

**Recommended Fuel Specifications**

Parameter	Unit	BS VI
Cetane Number (min)	CN	51
Sulphur content	mg/kg	10
Lubricity (HFRR)	micron	460

**① NOTE**

*It is mandatory to use Diesel fuel with recommended Sulphur contents as given above. Use of any other diesel fuel can increase the pollutants/damage the engine or exhaust after treatment system.*

## TECHNICAL INFORMATION

### LUBRICANT SPECIFICATION

Use following genuine fluids, coolants and lubricants recommended for optimum performance of your vehicle.

Item	Specification	Company	Brand	Qty
Engine oil (Diesel)	0W20 ACEA C2	<b>PETRONAS</b>	Tata Motors Genuine Oil Fully Synth0W20	5 L
Coolant (Pre-mixed) (Antifreeze agent +Soft water 40:60 ratio)	Class II/JIS K2234 TATA SS7700S1	<b>SUNSTAR CCI</b>	Tata Motors Genuine Coolant 2200	7 L
		<b>ANSYESCO</b>	Tata Motors Genuine Coolant Puro-cool++ Anchemo Anand	
Manual Transaxle Oil	PETRONAS ZC 601 FF	<b>PETRONAS</b>	TATA Motors Genuine Transaxle oil SAFARI	1.9 L
Automatic Transmission Oil	ATF SP-IV M1	<b>S-OIL TOTAL</b>	ATF SP-IV M1	7.82 L
Brake / Clutch fluid	SAE J 1703, DOT 4	<b>GOLDEN CRUISER</b>	TATA Genuine Brake Fluid	0.72 L
		<b>CASTROL</b>	Universal Brake fluid DOT 4	
		<b>PETRONAS</b>	TUTELA Brake Fluid DOT 4	
Power Steering oil	ATF-DEXRON III	<b>CASTROL</b>	ATF DEX III	1 L
Diesel Exhaust Fluid (DEF)	Solution confirms to ISO22241 standards	<b>NPL</b>	TATA ORIGINAL D.E.F	15 L
Compressor Oil	SP 10	<b>SANDEN VIKAS</b>	SP10 COMPRESSOR OIL-SANDEN VIKAS-L 0.25	135 cc

Refrigerant - R134a - 780±20 gms

## TECHNICAL SPECIFICATIONS

Parameter	Specifications
<b>Engine</b>	
Model/type	2.0L KryoTec BSVI
Capacity	1956 cc
Max. Engine output	125 kW at 3750 (+/-50) rpm
Max. Torque	350 Nm at 1750 to 2500 rpm
<b>Clutch</b>	
Type	Dry, Single Plate diaphragm type
Outside diameter of clutch	240 mm
<b>Transaxle (MT)</b>	
Model	C635 - FIAT
Type	Manual, 6-speed, Synchromesh
No. Of gears	6 Forward, 1 Reverse
<b>Transaxle (AT)</b>	
Model	6F33 - HTS
Type	Automatic, 6-speed, Planetary
No. Of gears	6 Forward, 1 Reverse
<b>Steering</b>	
Type	Power assisted-Hydraulic with Tilt & Telescopic mechanism and collapse feature

## TECHNICAL INFORMATION

Parameter	Specifications	
<b>Brakes</b>		
Brakes	Front (Disc); Rear (Disc)	
Parking Brakes	Cable Operated mechanical	
<b>Suspension</b>		
Type	Front: Independent lower wishbone MacPherson strut with coil spring Rear: Semi-independent Twist blade suspension with Panhard rod & coil spring	
Shock absorber	Front: MacPherson strut Damper twin tube with gas filled Rear: Damper twin tube with gas filled	
<b>Wheels &amp; tyres</b>		
Tyres	For Front & Rear, Option 1 : 235 / 70 R16 105H (Radial-Tubeless) Option 2 : 235 / 65 R17 104H (Radial-Tubeless) Option 3 : 235 / 60 R18 103V (Radial-Tubeless)  For Spare wheel, Option 1 : 235 / 70 R16 (Radial-Tubeless) Option 2 : T155 90 R18 113 M	
Wheel rims	Option 1: 6.5J X 16 steel wheel Option 2: 7.5J X 17 alloy wheel Option 3: 8J X 18 alloy wheel	
<b>Fuel tank</b>		
Capacity	50 liters	
<b>DEF Tank</b>		
Capacity	15 liters	


## TECHNICAL INFORMATION

Parameter	Specifications
<b>Cab / body</b>	
Type	Monocoque
<b>Electrical system</b>	
System voltage	12 Volts
Alternator capacity	160 Amp
Battery	12V, 78 Ah
<b>Main chassis dimension (in mm)</b>	
Wheel base	2741
Track front	1616
Track rear	1630
Overall length	4661
Overall height	1786
Max. Width	1894
Min. Ground clearance	143
<b>Performance</b>	
Max. Speed	170 kmph
Max. Recommended gradability	30%
Minimum Turning Circle Dia. in meters	11.6 m
Minimum Turning Clearance circle dia. in meters	12.2 m

## TECHNICAL INFORMATION

Parameter	Specifications	
Weight (in kg)		
Kerb weight (unladen)	1771 (XE) 1779 (XM) 1782 (XT) 1803 (XT+) 1789 (XZ 7 Seat) 1779 (XZ 6 Seat) 1810 (XZ+ 7 Seat) 1800 (XZ+ 6 Seat)	1811 (XMA) 1808 (XTA) 1820 (XTA+) 1811 (XZA 7 Seat) 1801 (XZA 6 Seat) 1825 (XZA+ 7 Seat) 1815 (XZA+ 6 Seat)
Gross vehicle weight	2346 (XE) 2354 (XM) 2357 (XT) 2378 (XT+) 2364 (XZ 7 Seat) 2279 (XZ 6 Seat) 2385 (XZ+ 7 Seat) 2300 (XZ+ 6 Seat)	2386 (XMA) 2383 (XTA) 2395 (XTA+) 2386 (XZA 7 Seat) 2301 (XZA 6 Seat) 2400 (XZA+ 7 Seat) 2315 (XZA+ 6 Seat)

### VEHICLE DIMENSIONS




**NOTE:** Dimensions are in mm Unladen condition

## TECHNICAL INFORMATION

---

### AGGREGATE IDENTIFICATION NUMBERS




Engine No. Plate – Diesel




Chassis No. punching near driver seat (RHS outer side)




VIN plate near Front passenger seat (LHS outer side)



Transaxle No. Punching (AT)



Transaxle No. Punching (MT)



Transmission Sticker number (AT)

## CAR CARE

Your vehicle is subjected to many external influences such as climate, road conditions, industrial pollution and proximity to the sea. These conditions demand regular care of the vehicle body. Dirt, insects, bird droppings, oil, grease, fuel and stone chippings should be removed as soon as possible.

### Washing

Following these tips while washing your vehicle.

1. Always wash your vehicle in shade and the surface is at room temperature.
2. Wash with mild vehicle wash soap like 'Car Shampoo' and use a soft bristle brush, sponge or soft cloth and rinse it frequently while washing to avoid scratches.
3. To avoid scratches, please wear soft gloves. Remove finger rings, nails, wrist watch while washing.
4. To remove stubborn stains and contaminants like tar, use turpentine or

cleaners like 'Stain remover' which are safe for paint surfaces.

5. Avoid substances like petrol, diesel, kerosene, benzene, thinner, acids or other solvents that cause damage to paint.
6. Dry your vehicle thoroughly to prevent any damp spots.
7. Rinse all surfaces thoroughly to prevent any traces of soap and other cleaners as this may lead to the formation of stains on the painted surface later.

### ① NOTE

- *Avoid parking the car under trees without proper cover, it will reduce the amount of bird droppings, tree sap and pollen contact on paint surface. Regularly remove the twigs, leaves and vegetation near the windshield areas, to avoid water stagnation.*
- *Always close the sunroof while washing the vehicle.*

### ⚠ WARNING

Do not direct high pressure washer fluid/ water jets (Pressure above 0.5 bar) at electrical devices and connector during washing. This is to prevent malfunction / failure of electrical system due to water ingress.

After drying the vehicle, inspect it for chips and scratches that could allow corrosion to start. Apply touch up paint where necessary.

### Cleaning of Carpets

Vacuum clean the carpet regularly to remove dirt. Dirt will make the carpet wear out faster. Periodically, shampoo the carpet to keep it looking new.

Use carpet cleaners (preferably foam type). Follow the instructions that come with the cleaner. Apply it with a sponge or soft brush. Keep the carpeting as dry as possible by not adding water to the foam.

### (i) NOTE

*Avoid wiping of painted surface in dry condition as it may leave scratches on the painted surface.*

### Cleaning of Windows, Front and Rear Glasses

Clean the windows inside and outside with commercially available glass cleaners.

This will remove the haze that builds up on the inside of windows. Use a soft cloth or paper towels to clean all glass and plastic surfaces.

### Waxing

Waxing and polishing is recommended to maintain the gloss and wet-look appearance of your paint finish.

1. Use good quality polish and wax for your vehicle.
2. Re-wax your vehicle when the water does not slip off the surface but collects over the surface in patches.

3. Stain should not be removed by rubbing. As far as possible, try to blot or lift the stain with cloth or plastic spatula and then clean the remaining stain with cloth or sponge.
4. If the stain has dried, then gently brush off the material and then press with

### Polishing

Polishes and cleaners can restore shine to the painted surface that has oxidized and become dull. They normally contain mild abrasives and solvents that remove the top layer of the finish coat. Polish your vehicle, if the finish does not regain its original shine after using wax.

### Interior Fabric Cleaning Tips

5. Do not use household detergents to clean the fabric.
6. Always use clean cotton cloth for cleaning.

### Paint Care

Following guidelines will help you to protect your vehicle from corrosion effectively.

### (i) NOTE

*Avoid Spillage or Direct contact of Air freshener liquid/chemicals with painted plastic parts. These chemicals may cause damage to paint like blisters, peel off, wrinkles etc.*

## Proper Cleaning

In order to protect your vehicle from corrosion it is recommended that you wash your vehicle thoroughly and frequently in case:

- There is a heavy accumulation of dirt and mud especially on the underbody.
- It is driven in areas having high atmospheric pollution due to smoke, soot, dust, iron dust and other chemical pollutants.
- It is driven in coastal areas.
- The underbody must be thoroughly pressure washed after every three months.
- In addition to regularly washing your car, the following precautions need to be taken.

## Periodic Inspection

- Regularly inspect your vehicle for any damage in the paint film such as deep scratches and immediately get them repaired from an authorized service outlet, as these defects tend to accelerate corrosion.

- Inspect mud liners for damages.
- Keep all drain holes clear from clogging.

## Proper Parking

- Always park your vehicle in shade to protect it from harsh sunlight or in a well-ventilated garage so that there is no dampness on any part of the vehicle.

## Wiper Care

- To prevent damage to the wipers or windshield, do not operate the wipers when the windshield is dry.
- To prevent damage to the wiper arms and other components, do not attempt to move the wipers manually.

## FAST TAG

FAST TAG is pasted on front windshield from the inside. It enables Electronic toll collection.



### *(i)* NOTE

*Do not attempt to rip or tamper the tag.  
It will disable the functionality of the tag.*

## CAR CARE

---

### VALUE CARE - AMC

Value Care (AMC) is a fixed cost maintenance plan that guarantees protection against unexpected repairs & provides substantial savings through protection against inflation & price volatility of consumables during the running of the vehicle.

Our customers can choose from **Value Care Gold**, **Value Care Silver**, **Promise to Protect (P2P)** and **Protect plus** plan as per the requirement & usage to ensure hassle free, reliable & economic maintenance of the vehicle.

Coverage – **Schedule Service and Wear & Tear.**

#### Advantage (Customer Benefits)

- Price protection against rising prices of lubes and parts.
- A higher resale value for your vehicle.
- Peace of mind with Cashless repairs & services.
- Vehicle servicing at a workshop of your choice pan India.
- Covers Repairs including Wear & Tear parts viz. Brakes, Suspension, Wiper, Clutch, Brake Pads, Brake Liners etc.
- Covers Scheduled maintenance services including Lubricants, Parts, Wheel Alignment and Balancing Labour.
- Available at unmatched value.... Huge Savings!!!
- Savings on Goods & Services Tax whenever vehicle attend under AMC.



**Available Offers (Types of AMC)**

- Silver AMC
- Gold AMC
- Promise to Protect (P2P)
- Protect Plus

**Silver AMC**

Value Care Silver Plan covers the following:

- Scheduled maintenance services at periodic interval of Km for Labor, Parts & Consumables.
- 1. Change of Oil Filter, Fuel Filter, Air Filter & Sedimenter.
- 2. Change of Engine Oil, Transmission Oil (if applicable), and Power steering Oil\*.
- 3. Change of Coolant, Brake Oil & Clutch Fluid\*.
- 4. General Checkup, Wheel Alignment / Balancing (Excluding Balancing Weight).
- 5. Washing of Vehicle, Wheel greasing as applicable.

**Gold AMC**

The value care Gold Plan extends your scheduled maintenance cover to include any normal wear and tear items identified during the scheduled service and other vehicle parts that need to replace during the period of cover arising from proper and uniform usage.

- Scheduled maintenance services at periodic interval of Km for Labor, Parts & Consumables.

In addition to coverage mentioned under Silver AMC, the Gold AMC also covers Repairs or Replacement of Wear & Tear Items for both Parts & Labour.

## **CAR CARE**

---

1. Brake Pads, Brake Liners, Wheel Cylinders.
2. Clutch Disc, Clutch Cover, Cables, Mountings.
3. Suspension Bush, Wiper Blades, Auxiliary Belt & other Wear & Tear Items.
4. Washing of Vehicle, Wheel greasing as applicable.

### **Promise to Protect (P2P)**

Value Care – Promise to protect (P2P) is a maintenance plan that guarantees protection against unexpected wear & tear repairs to provide substantial saving through protection against inflation & price volatility during the running of the vehicle.

New Vehicle (under warranty vehicles) are eligible to avail this offer –Identified 13 wear & tear parts listed below Including Labour is covered in this AMC with the price range of 11 to 14 paisa per Km.

**\*applicable to selected models\***

### **List of Covered Parts**

Clutch, Brake Pad, Brake Linings, Brake Disc, Wiper, Wheel Cylinder, Suspension Bushes, Engine Mountings, Ball Joints, Hoses, Auxiliary Belt, (Alternator & A/C Belt), Window Winder.

### **Protect Plus**

The value care Protect plus Plan extends your scheduled maintenance cover to include coverage of P2P. It covers scheduled maintenance services – labour, parts & consumables + Identified 13 wear & tear parts of P2P plan Including Labour.

New Vehicle (under warranty vehicles) are eligible to avail this offer.

**\*Applicable to selected models\***

**(i) NOTE**

- *AMC is available in the dealership from where you have purchased your vehicle.*
- *We strongly recommend purchase of AMC at time of purchase of your vehicle to get benefit for coverage of Scheduled Services and Wear & Tear parts.*
- *The Dealer Service Marketing Executive shall explain to you the Terms and conditions, Coverage and Owner's responsibility.*
- *One Time payment is to be made to avail AMC offer.*
- *P2P & Protect plus offer valid on selected models & may vary from Model to Model, Variant to Variant.*
- *Please read the offer eBooklet for further details about coverage and exclusions of various AMCs.*

**Owner's Responsibility**

- Proper use, maintenance and care of the vehicle in accordance with the instructions contained in the Owner's Manual and Service Booklet. The records of the same to be ensured in Owner's Manual.
- Retention of maintenance service bills.

I / We have been explained the Terms and conditions, Coverage and Owner's responsibility by the Dealer Service Marketing Executive.

I wish to avail /  Do not wish to avail extended warrant policy.

**Customer's Signature**

**Dealer's Signature**

## CAR CARE

---

### EXTENDED WARRANTY

TATA MOTORS recommends the purchase of its extended warranty program.

**Coverage** - Mechanical + Electrical

#### Benefits

- Insures you against unforeseen break down repair bills.
- Documentation is simple and hassle free.
- Near cashless & speedy claim

#### Term

2+1 Year or 1,15,000 Km whichever occurs first

OR

2+2 Year or 1,30,000 Km whichever occurs first

OR

2+3 Year for Unlimited Km

Extended Warranty is available in the dealership from where you have purchased your vehicle. We strongly recommend purchase of Extended Warranty at time of purchase of your vehicle. Extended Warranty can be availed until warranty period from date of purchase of vehicle. The Dealer Service Marketing Executive shall explain to you the Terms and conditions, Coverage and Owner's responsibility.

#### Note

- The 12 or 24 or 36 months extended warranty does not follow the 24 months Manufacturer's warranty.
- The extended warranty comes into force once the manufacturer's warranty expires e.g. after 24 Months.
- It is more restrictive as by the time it comes into force the vehicle is already 24 months old.



**What is Covered?**

- Mechanical / Electrical break down as defined in this warranty and confirmed by the dealer within the stipulated terms and conditions.
- TATA MOTORS dealer shall either repair or replace any part found to be defective with a new part or an equivalent at no cost to the owner for parts or labour.
- Such defective parts which have been replaced will become property of TATA MOTORS PASSENGER VEHICLE LIMITED.
- Comprehensive list of parts covered is mentioned in the page 9-12 of the Extended Warranty Booklet.

**What is not covered?**

Please refer the Extended Warranty Booklet for details of the exclusion list.

**Owner's Responsibility**

- Proper use, maintenance and care of the vehicle in accordance with the instructions contained in the Owner's Manual and Service Booklet. The records of the same to be ensured in Owner's Manual.
- Retention of maintenance service bills.

I / We have been explained the Terms and conditions, Coverage and Owner's responsibility by the Dealer Service Marketing Executive.

I wish to avail /  Do not wish to avail extended warrant policy.

**Customer's Signature**

**Dealer's Signature**

## CAR CARE

---

### VALUE ADDED SERVICES

**Why are Corrosion Protection Waxes necessary?**

**Corrosion is caused by:**

Water / salt water acid rain & atmospheric fallouts.

**Critical areas are:**

Cavities: joints, crevices, spot welds, underbody

- Corrosion is the most important factor when we talk about the vehicle life. If you treat your car you can prolong the life.
- It is very dangerous to drive around in a corroded vehicle.
- The corrosion creeps onto the vehicle from the inside and from the outside. The most dangerous kind of corrosion is often not discovered until it is too late.

**Benefits of Anti - Rust Treatment:**

- A professionally applied range of world class products offering real value to the new and used vehicle customer.
- The treatment has been developed to withstand the harshest environmental and climatic conditions (rust. Pollutants, stone and gravel impact, etc.)
- Insulate cabin space from external noises.
- Expensive tin work and Denting / Painting avoided.
- Higher resale value for the vehicle.
- Higher safety – uncorroded vehicle
- 10 free checkups available



---

TATA MOTORS has tied up with **M/s Wurth, M/s Autokrom, M/s 3M India Lt d & M/s Bardahl** for these world class treatment at affordable prices. These treatments are available in all authorized workshops. The Dealer Service Marketing Executive will explain to you the benefits and terms and conditions of this treatment.

I / We have been explained the Benefits, Terms and conditions and the prices of these treatments by the Dealer Service Marketing Executive.

I wish to avail /  Do not wish to avail extended warrant policy.

**Customer's Signature**

**Dealer's Signature**

## CAR CARE

---

### VEHICLE EXTERIOR ENRICHMENT

#### Why Vehicles are Painted?

- For Corrosion protection of the metal surfaces.
- Ease of application from other corrosion protection treatments.
- Cheaper than other corrosion protection methods eg. Galvanizing, anodizing.
- For decoration and identification.

#### Various Environmental Hazards Affecting Paints

Environmental hazards: destroy your vehicle's finish.

Even as your new vehicle rolls off the assembly line, the paint is not protected.

#### The Enemy

Ultraviolet Rays, Pollution, Tree Sap, Bird Droppings, Car Wash Chemicals, Road Salt, Acid Rain.

#### Benefits: Vehicle Exterior Enrichment

- Removal of medium scratches, orange peel, oxidation, dust nibs etc. & swirl marks from painted surface.
- Restoration of original gloss levels, UV protection after gloss is restored.
- Cleaning & dressing of tyres, Bumpers & all exterior plastic moldings/trims.

TATA MOTORS has tied up with **M/s Autokrom, M/s 3M & M/s Wurth** for this world class treatment at affordable prices. This treatment is available in all authorized workshops. The Dealer Service Marketing Executive will explain to you the benefits and terms and conditions of this treatment.



---

## VEHICLE INTERIOR ENRICHMENT

### Why protect your new car's fabric interior?

- Someone will spoil your vehicle's fabric carpet or seats.
- A significant detractor from your vehicle's resale value.
- A permanent stain on your vehicle's interior fabric.

### The Enemy

Drink Spills - Food Stains - Mud - Ultraviolet Rays Pets - Traffic

### Benefits: Vehicle Interior Enrichment

- Removal of medium stains and dirt from all interior parts of the car i.e., carpet, upholstery and roof lining.
- Cleaning of windshield and all windows (inside and outside).
- Dressing of all internal plastics (e.g.: door pad trims) and rubber parts.
- The treatment involves cleaning and dressing of all parts of the exposed interiors.
- Specialised protection for seat fabric from liquid spills.

TATA MOTORS has tied up with **M/s Wurth** and **M/s Autokrom** for this world class treatment at affordable prices. This treatment is available in all authorized workshops. The Dealer Service Marketing Executive will explain to you the benefits and terms and conditions of this treatment.

I / We have been explained the Terms and conditions, Coverage and Owner's responsibility by the Dealer Service Marketing Executive.

I wish to avail /  Do not wish to avail extended warrant policy.

**Customer's Signature**

**Dealer's Signature**



## **WARRANTY - TERMS AND CONDITIONS**

### **VEHICLE WARRANTY: TERMS AND CONDITIONS**

We WARRANT each **TATA SAFARI** vehicle and parts thereof manufactured by us to be free from defect in material and workmanship subject to the following terms and conditions:

1. This warranty shall be for a period of **2 years from the date of sale of the car or a mileage of 1, 00,000 Kms whichever occurs earlier**.
2. Our obligation under this warranty shall be limited to repairing or replacing, free of charge, such parts of the car which, in our opinion, are defective, on the car being brought to us or to our dealers within the period. The parts so repaired or replaced shall also be warranted for quality and workmanship but such warranty shall be co-terminus with this original warranty.
3. Any part which is found to be defective and is replaced by us under the warranty shall be our property.
4. As for such parts as Tyres, Batteries, Audio and / or Video equipment (if any), etc. not manufactured by us but supplied by other parties, this warranty shall not apply, but buyers of the car shall be entitled to, so far as permissible by law, all such rights as we may have against such parties under their warranties in respect of such parts.
5. This warranty shall not apply if the car or any part thereof is repaired or altered otherwise than in accordance with our standard repair procedure or by any person other than from our sales or service establishments, our authorized dealers, service centres or service points in any way so as, in our judgment which shall be final and binding, to affect its reliability, nor shall it apply if, in our opinion which shall be final and binding, the car is subjected to misuse, negligence, improper or inadequate maintenance or accident or loading in excess of such carrying capacity as certified by us, or such services as prescribed in our Owner's Manual are not carried out by the buyer through our sales or service establishments, our authorized dealers, service centres or service points.
6. **This warranty shall not apply to the replacement of normal wear parts, including without limitation, drive belts, hoses, wiper blades, fuses, clutch disc, brake shoes, brake pads, cables and all rubber parts (except oil seal and glass run).**
7. This warranty shall not cover any inherent normal deterioration of the car or any of its parts arising from the actual use of the car or any damage due to negligent or improper operation or storage of the car.
8. This warranty shall not apply to normal maintenance services like oils & fluid changes, head lamps focusing, fastener retightening, center hub cap/wheel cover, wheel balancing and alignment, tyre rotation, adjustment of valve clearance, fuel timing, ignition timing and consumables like bulbs, fuel, air & oil filters and gas leaks in case of air conditioned cars.
9. This warranty shall not apply to any damage or deterioration caused by environmental pollution or bird droppings. Slight ir-

## **WARRANTY - TERMS AND CONDITIONS**

---

regularities not recognized as affecting the function or quality of the vehicle or parts, such as slight noise or vibration, defects appearing only under particular or irregular operations are items considered characteristics of the vehicle.

10. This warranty shall be null and void if the car is subjected to abnormal use such as rallying, racing or participation in any other competitive sport. This warranty shall not apply to any repair or replacements as a result of accident or collision.
11. This warranty is expressly in lieu of all warranties, whether by law or otherwise, expressed or implied, and all other obligations or liabilities on our part and we neither assume, nor authorize any person to assume on our behalf, any other liability arising from the sale of the car or any agreement in relation thereto.
12. The buyer shall have no other rights except those set out above and have, in particular, no right to repudiate the sale, or any agreement or to claim any reduction in the purchase price of the car, or to demand any damages or compensation for losses, incidental or indirect, or inconvenience or consequential damages, loss of car, or loss of time, or otherwise, incurred or accrued.
13. Any claim arising from this warranty shall be recognized only if it is notified in writing to us or to our authorized dealer without any delay soon after such defects as covered & ascertained under this warranty.
- 14. This warranty is fully transferable to subsequent vehicle**

**owner. Only unexpired remaining period of warranty applies.**

15. We reserve our rights to make any change or modification in design of the car or its parts or to introduce any improvement therein or to incorporate in the car any additional part or accessory at any time without incurring any obligation to incorporate the same in the cars previously sold.

### ENVIRONMENTAL SAFETY

TATA MOTORS PASSENGER VEHICLE LIMITED is committed to produce vehicles using environmentally sustainable technology. A number of features have been incorporated in TATA MOTORS passenger vehicles which have been designed to ensure environmental compatibility throughout the life cycle of the vehicle. We would like to inform you that your vehicle meets emission norms and this is being regularly validated at the manufacturing stages.

As a user you too can protect the environment by operating your vehicle in a proactive manner. A lot depends on your driving style and the way you maintain your vehicle. We have given a few tips for your guidance.

#### Driving

- Avoid frequent and violent acceleration.
- Do not carry any unnecessary weight in the vehicle as it overloads the engine. Avoid using devices requiring high power consumption during slow city traffic condition.
- Monitor the vehicle's fuel consumption regularly and if showing rising trend get the car immediately attended at the Company's Authorised Service Outlets.
- Switch off the engine during long stops at traffic jams or signals. If you need to keep the engine running, avoid unnecessary revving it up or stopping and starting.
- It is not necessary to rev up the engine before turning it off as it unnecessarily burns the fuel.

- Shift to higher gears as soon as possible. Use each gear upto 2/3rd of maximum engine speed.
- A chart indicating gear shifting speeds is given in this book.

#### Maintenance

- Ensure that recommended maintenance is carried out on the vehicle regularly at the Authorised Service Outlets.
- As soon as you see any leakages of oil or fuel in the vehicle we recommend to get it attended immediately.
- Use only recommended grades and specified quantity of lubricants.
- Get your vehicle checked for emission periodically by an authorised dealer.
- Ensure that fuel filter, oil filter and breather are checked periodically and replaced, if required, as recommended by TATA MOTORS.
- Do not pour used oils or coolants into the sewage drains, garden soil or open streams. Dispose the used filters and batteries in compliance with the current legislation.
- Do not allow unauthorized person to tamper with engine settings or to carry modifications on the vehicle.
- Never allow the vehicle to run out of fuel.
- Parts like brake liners, clutch discs should be vacuum cleaned. Do not use compressed air for cleaning these parts which may spread dust in the atmosphere.

## **ENVIRONMENT SAFETY**

---

**While carrying out servicing or repairs of your vehicle, you should pay keen attention to some of the important engine aggregates and wiring harness which greatly affect emission. These components are:**

1. Fuel injection equipment- pump, rail, injectors, nozzles and high-pressure pipes.
2. Air Intake & Exhaust system, especially for leakages.
3. Cylinder head for valve leakage.
4. All filters such as air, oil and fuel filters (check periodically).
5. Turbocharger.
6. EGR Valve & Cooler
7. Intake throttle
8. Electrical connections.
9. If the 'Check Engine lamp', 'MIL' , 'SCR' or 'DPF' lamp continuously glows, please take the vehicle to a TATA MOTORS Authorized Dealer/Service Center.
10. Exhaust After Treatment System parts.
11. EMS wiring harness i.e. electrical connections to all sensors and actuators.

This Owner's manual contains further information on driving precautions and maintenance care leading to environment protection. Please familiarize yourself with these aspects before driving.



## **SOUL – SUV OWNER'S UNITED LEAGUE. JOIN TODAY!!**

Become a part of the Exclusive Tata SUV Owner's Community - SOUL and join the fellow Explorers to escape your day to day routine and ignite your Spirit of Adventure by participating in Exciting Expeditions and Discovering Unexplored Destinations.

What's more? You also get to avail exciting benefits and privileges specially curated to enrich your journey with your Tata SUV.

To register, visit our website -  
[www.soul.tatamotors.com](http://www.soul.tatamotors.com) or call – 1800-209-8282

To #DriveWithSOUL, follow us on:



/soul\_tatamotors\_official



/officialtatamotorscars



/TataMotors\_Cars



/TataMotorsGroup



Customer's copy



PDI Coupon

**SAFARI**

Pre Delivery Inspection

---

Dealer's copy



**PDI Coupon** **SAFARI**

Pre Delivery Inspection

**AVAIL ALL SERVICES TO GET BENEFIT OF WARRANTY**

---

**This Coupon entitles for free labour jobs.(Refer maintenance section)**

Owner's Name:

Owner's Name:

VIN No.:

VIN No.:

Engine / Motor No.:

Engine / Motor No.:

Reg. No.:

Reg. No.:

ODO Reading:

ODO Reading:

Date of Sale:

Date of Service:

Date of Service:

Service Dealer code:

**I hereby certify that the PDI has been carried out to my entire satisfaction.**

Service Dealer's Stamp & Signature

Customer's Signature

Service Dealer's Stamp & Signature

(Free Service coupons are valid at all TATA Authorized Service Centers in India)



Customer's copy



1<sup>st</sup> Free Service Coupon

**SAFARI**

Valid for 1000 - 2000 kms. OR 2 months,  
Whichever is earlier

Dealer's copy



**TATA 1<sup>st</sup> Free Service Coupon** **SAFARI**

Valid for 1000 - 2000 kms. OR 2 months, whichever is earlier.

**AVAIL ALL SERVICES TO GET BENEFIT OF WARRANTY**

**This Coupon entitles for free labour jobs.(Refer maintenance section)**

Owner's Name:

Owner's Name:

VIN No.:

VIN No.:

Engine / Motor No.:

Engine / Motor No.:

Reg. No.:

Reg. No.:

ODO Reading:

ODO Reading:

Date of Sale:

Date of Service:

Date of Service:

Service Dealer code:

**I hereby certify that the service has been carried out to my entire satisfaction.**

Service Dealer's Stamp & Signature

Customer's Signature

Service Dealer's Stamp & Signature

(Free Service coupons are valid at all TATA Authorized Service Centers in India)



Customer's copy



2<sup>nd</sup> Free Service Coupon

**SAFARI**

Valid for 7000 - 8000 kms. OR 6 months,  
whichever is earlier

Dealer's copy



**TATA 2<sup>nd</sup> Free Service Coupon** **SAFARI**

Valid for 7000 - 8000 kms. OR 6 months, whichever is earlier.

**AVAIL ALL SERVICES TO GET BENEFIT OF WARRANTY**

**This Coupon entitles for free labour jobs.(Refer maintenance section)**

Owner's Name:

Owner's Name:

VIN No.:

VIN No.:

Engine / Motor No.:

Engine / Motor No.:

Reg. No.:

Reg. No.:

ODO Reading:

ODO Reading:

Date of Sale:

Date of Service:

Date of Service:

Service Dealer code:

**I hereby certify that the service has been carried out to my entire satisfaction.**

Service Dealer's Stamp & Signature

Customer's Signature

Service Dealer's Stamp & Signature

(Free Service coupons are valid at all TATA Authorized Service Centers in India)



Customer's copy



3<sup>rd</sup> Free Service Coupon

**SAFARI**

Valid for 14,500 – 15,500 kms. OR 12 months, whichever is earlier

Dealer's copy



**TATA 3<sup>rd</sup> Free Service Coupon** **SAFARI**

Valid for 14,500 – 15,500 kms. OR 12 months, whichever is earlier.

**AVAIL ALL SERVICES TO GET BENEFIT OF WARRANTY**

**This Coupon entitles for free labour jobs.(Refer maintenance section)**

Owner's Name:

Owner's Name:

VIN No.:

VIN No.:

Engine / Motor No.:

Engine / Motor No.:

Reg. No.:

Reg. No.:

ODO Reading:

ODO Reading:

Date of Sale:

Date of Service:

Date of Service:

Service Dealer code:

**I hereby certify that the service has been carried out to my entire satisfaction.**

Service Dealer's Stamp & Signature

Customer's Signature

Service Dealer's Stamp & Signature

(Free Service coupons are valid at all TATA Authorized Service Centers in India)

