

#	Model	Variant	Phone Brand	PhoneName	OperatingSystem	Android Auto	CarPlay	Pairing	Auto Connect Or Disconnect	Signal Strength	Battery	Call Answer From Informant	Call Reject From Informant	Call Terminate	Handset To Hands free	Hands free To Handset	Call Log Sync	Contacts Download	Play Or Pause	Next Or Previous	Fast Forward Or Fast Rewind	Song Details	Message	Connect Next	Remote Control App	w3w	WirelessAA	WirelessCP
1	Neosn BS4	XZ	Samsung	Samungs Galaxy J2 ACE (2016)	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
2	Neosn BS4	XZ	Samsung	Samungs Galaxy A9 Pro (2016)	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
3	Neosn BS4	XZ	Coolpad	Coolpad Note 3	Android 5.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
4	Neosn BS4	XZ	Coolpad	Coolpad 3600	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
5	Neosn BS4	XZ	Mi	Redmi Note 4G	Android 4.4.4	NA	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
6	Neosn BS4	XZ	Vivo	vivo V3 max	Android 5.1.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
7	Neosn BS4	XZ	Vivo	vivo i803	Android 5.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
8	Neosn BS4	XZ	Xolo	Xolo Play BX-1100	Android 4.2.2	NA	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
9	Neosn BS4	XZ	LAVA	LAVA XAL	Android 4.4.4	NA	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
10	Neosn BS4	XZ	Lenovo	Lenovo ZUK Z1	Android 5.1.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
11	Neosn BS4	XZ	HTC	HTC one X9	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
12	Neosn BS4	XZ	Agnesse	Agnesse S66	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
13	Neosn BS4	XZ	Sony	Sony Xperia XA	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
14	Neosn BS4	XZ	LG	G3	Android 4.4.2	NA	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
15	Neosn BS4	XZ	HTC	Desire 830	Android 5.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
16	Neosn BS4	XZ	Neusis	Neusis 5	Android 7.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
17	Neosn BS4	XZ	Neusis	Neusis 3x	Android 7.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
18	Neosn BS4	XZ	Levi	Le TuLe eco le 2)	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
19	Neosn BS4	XZ	Motorola	Moto G3	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
20	Neosn BS4	XZ	OPPO	OPPO F15	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
21	Neosn BS4	XZ	Huawei	Honor 6	Android 5.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
22	Neosn BS4	XZ	Zenfone 3	Zenfone 3	Android 4.4.2	NA	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
23	Neosn BS4	XZ	Motor	Moto G4 Plus	Android 7.1.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
24	Neosn BS4	XZ	Google	Pixel XL	Android 7.1.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
25	Neosn BS4	XZ	Micromax	Micromax Canvas 6	Android 5.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
26	Neosn BS4	XZ	Motorola	Moto M	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
27	Neosn BS4	XZ	Samsung	Samungs Galaxy A5	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
28	Neosn BS4	XZ	Lenovo	Vibe X3	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
29	Neosn BS4	XZ	Panasonic	Eluga Arc 2	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
30	Neosn BS4	XZ	Microsoft	Lumia 730	10.0 14993.693	NA	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
31	Neosn BS4	XZ	Motorola	Moto S Turbo	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
32	Neosn BS4	XZ	Samsung	Galaxy ON Pro	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
33	Neosn BS4	XZ	Lenovo	Lenovo View K4	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
34	Neosn BS4	XZ	Motorola	Moto g5 Plus	Android 7.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
35	Neosn BS4	XZ	Sony	Sony xperia Xzs	Android 7.1.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
36	Neosn BS4	XZ	Gamee A3	Gamee A3	Android 7.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
37	Neosn BS4	XZ	Oppo	Oppo F3 Plus	Android 6.0.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
38	Neosn BS4	XZ	Vivo	Vivo 1713	Android 6.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
39	Neosn BS4	XZ	Honor	Honor 5 8e	Android 7.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
40	Neosn BS4	XZ	One Plus 3T	One Plus 3T	Android 7.1.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	Song not audible after releasing the fast forward button	✓	✓	✓	✓	NAUL	NULL	NULL
41	Neosn BS4	XZ	HTC	HTC U10	Android 7.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
42	Neosn BS4	XZ	LG	LG G5	Android 7.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
43	Neosn BS4	XZ	Samsung	Galaxy S8	Android 7.0	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
44	Neosn BS4	XZ	Oppo	IT selfie	Android 5.1	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
45	Neosn BS4	XZ	Xiaomi	Redmi Note 1	Android 4.4	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
46	Neosn BS4	XZ	Zenfone 3s Max ZC521TL	Zenfone 3s Max ZC521TL	7.0 (N9N-Phone-14.02.1801.29)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
47	Neosn BS4	XZ	GIONEE	X15	4.0 (X15_0401_V5625)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
48	Neosn BS4	XZ	Google	Pixel 2	8.0 (OPM6-17.019.029)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
49	Neosn BS4	XZ	9 LR LLD-AL10	9 LR LLD-AL10	8.0.0 (L10-AL10 8.0.0.160(C675))	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
50	Neosn BS4	XZ	HTC	Desire 626G+	4.4.2 (1.08.707.1)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
51	Neosn BS4	XZ	LAVA	Z60	7.0 (Lava_260_V1.0_S131_20171120)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
52	Neosn BS4	XZ	Lenovo	K8 Note XT1902-3	6.0.0 (OMB27-43-20)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
53	Neosn BS4	XZ	Lenovo	K8 Plus XT1902-2	7.1.1 (NMC26-74-45)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
54	Neosn BS4	XZ	Lenovo	Moto C Plus XT1721	7.0 (NRPD9M-01.038)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
55	Neosn BS4	XZ	Lenovo	Moto E4 Plus XT1770	7.1.1 (NMA26-42-142)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
56	Neosn BS4	XZ	Lenovo	Moto G5S Plus XT1804	7.1.1 (NPS226-116-419)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
57	Neosn BS4	XZ	Lenovo	Moto Z2 Force XT1739-36	8.0.0 (OPM27-109-447)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
58	Neosn BS4	XZ	LG	V30+ H990DS	7.1.2 (V30-IND-XX)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
59	Neosn BS4	XZ	Micromax	Canvas Infinity HS2	6.0 (Q402-SW_V14_V14_HW_V2.0_20170804)	✓	NA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	FW FRW not working properly	✓	✓	✓	✓	NAUL	NULL	NULL
60	Neosn BS4	XZ	Micromax	Canvas Infinity HS2	7.1.2																							

[illegible]

[illegible]

[illegible]

